

## G14Q3

80C93	BLOWER - PURGE(80 60 40 100)	G14Q3
38F92	BLOWER-PURGE(80 60 40)	G14Q3
21C52	BOOT-CAPACITOR(80 60 40 100)	G14Q3
39H58	CAPACITOR(100)	G14Q3
39H89	CAPACITOR(80 100)	G14Q3
59C92	CAPACITOR-BLR MTR(80 60 40)	G14Q3
59C93	CAPACITOR-BLR MTR(80 60 40)	G14Q3
96C77	CARRIER-FUSE(60 40)	G14Q3
T6-1608	CONTROL-F&L(100)	G14Q3
10F46	CONTROL-F&L(60)	G14Q3
15F71	CONTROL-F&L(60)	G14Q3
86G60	CONTROL-F&L(60)	G14Q3
T6-1546	CONTROL-F&L(60)	G14Q3
T6-1547	CONTROL-F&L(80 100)	G14Q3
77C88	CONTROL-F&L(80 40)	G14Q3
T6-1548	CONTROL-F&L(80 40)	G14Q3
38F90	CONTROL-F&L(80 60 40)	G14Q3
15F72	CONTROL-F&L(80)	G14Q3
99C97	CONTROL-PRIMARY(60 40)	G14Q3
60J00	CONTROL-PRIMARY(80 60 40 100)	G14Q3
54G93	COUPLING-EXHAUST(80 60 40)	G14Q3
20H84	DECOUPLER-GAS(80 60 40)	G14Q3
20H85	DECOUPLER-GAS(80 60 40)	G14Q3
20H58	DIAPHRAGM ASSY-AIR(40)	G14Q3
20H61	DIAPHRAGM ASSY-AIR(40)	G14Q3
24G41	DIAPHRAGM ASSY-AIR(40)	G14Q3
35G77	DIAPHRAGM ASSY-AIR(40)	G14Q3
27F47	DIAPHRAGM ASSY-AIR(60 40)	G14Q3
20H59	DIAPHRAGM ASSY-AIR(60)	G14Q3
84G24	DIAPHRAGM ASSY-AIR(80 60 40)	G14Q3
27F48	DIAPHRAGM ASSY-AIR(80 60)	G14Q3
12G78	DIAPHRAGM ASSY-AIR(80)	G14Q3
20H60	DIAPHRAGM ASSY-AIR(80)	G14Q3
27F46	DIAPHRAGM ASSY-GAS(60 40)	G14Q3
34G83	DIAPHRAGM ASSY-GAS(80 60 40)	G14Q3
83F47	DRIP LEG PKG(40)	G14Q3
83F48	DRIP LEG PKG(80 60)	G14Q3
59436	FILTER(100)	G14Q3
30335	FILTER(80 60 40)	G14Q3
32F22	FILTER-AIR(60 40)	G14Q3
32F24	FUSE(60 40)	G14Q3
96C78	FUSE(60 40)	G14Q3
67171	FUSE(80 60 40)	G14Q3
21G46	FUSE(80 60 40)	G14Q3
74G26	GAS DECOUPLER(80 60 40 100)	G14Q3
LB-45	GAS DIAGRAM ASS'Y(80 60 40)	G14Q3
LB-56	GAS DIAPHRAGM ASS'Y(80 40)	G14Q3
60579	HOLDER-FUSE(60 40)	G14Q3

96C76	HOLDER-FUSE(60 40)	G14Q3
LB-51599CA	LEAD - IGNITION(100)	G14Q3
39G09	LEAD(100)	G14Q3
LB-51599CA	LEAD(60 40)	G14Q3
14F53	LEAD(80 60 40)	G14Q3
14H70	LEAD(80 60 40)	G14Q3
53H61	LEAD-IGNITION(40)	G14Q3
LB-51599CA	LEAD-IGNITION(60 40)	G14Q3
14F55	LEAD-IGNITION(80 60 40)	G14Q3
39F35	LEAD-IGNITION(80 60 40)	G14Q3
72G95	LEAD-IGNITION(80 60 40)	G14Q3
96G34	LEAD-IGNITION(80 60 40)	G14Q3
LB-51599CA	LEAD-IGNITION(80 60 40)	G14Q3
LB-51599CA	LEAD-IGNITION(80)	G14Q3
13K30	LP/NAT REG CONV KIT(80 60 40 100)	G14Q3
13K29	LP/NAT TUNE-UP KIT(100)	G14Q3
13K26	LP/NAT TUNE-UP KIT(40)	G14Q3
13K27	LP/NAT TUNE-UP KIT(60)	G14Q3
13K28	LP/NAT TUNE-UP KIT(80)	G14Q3
28F01	MOTOR-BLOWER(100)	G14Q3
67F15	MOTOR-BLOWER(80 60 100)	G14Q3
15B45	MOTOR-BLOWER(80 60 40)	G14Q3
57C25	MOTOR-BLOWER(80 60 40)	G14Q3
32904	MOTOR-BLOWER(80 60)	G14Q3
67F81	MUFFLER(80 60 40)	G14Q3
37G75	ORIFICE(100)	G14Q3
76G29	ORIFICE(100)	G14Q3
38G42	ORIFICE(40)	G14Q3
LB-5128BAL	ORIFICE(40)	G14Q3
44G78	ORIFICE(60)	G14Q3
44H14	ORIFICE(80)	G14Q3
76G28	ORIFICE(80)	G14Q3
29G72	ORIFICE-BURNER(100)	G14Q3
LB-54338D	ORIFICE-BURNER(100)	G14Q3
37G67	ORIFICE-BURNER(40)	G14Q3
37G68	ORIFICE-BURNER(40)	G14Q3
37G69	ORIFICE-BURNER(40)	G14Q3
74G17	ORIFICE-BURNER(40)	G14Q3
88G19	ORIFICE-BURNER(40)	G14Q3
LB-47	ORIFICE-BURNER(40)	G14Q3
LB-54	ORIFICE-BURNER(40)	G14Q3
LB-55	ORIFICE-BURNER(40)	G14Q3
LB-58	ORIFICE-BURNER(40)	G14Q3
38G44	ORIFICE-BURNER(60 40)	G14Q3
37G70	ORIFICE-BURNER(60)	G14Q3
37G83	ORIFICE-BURNER(60)	G14Q3
42F19	ORIFICE-BURNER(60)	G14Q3
90K05	ORIFICE-BURNER(60)	G14Q3
LB-59	ORIFICE-BURNER(60)	G14Q3
38G46	ORIFICE-BURNER(80 60)	G14Q3
37G82	ORIFICE-BURNER(80)	G14Q3

44G59	ORIFICE-BURNER(80)	G14Q3
47F24	ORIFICE-BURNER(80)	G14Q3
60G09	ORIFICE-BURNER(80)	G14Q3
LB-15	ORIFICE-BURNER(80)	G14Q3
LB-57	ORIFICE-BURNER(80)	G14Q3
43G62	PLUG - IGNITION(80 60 40 100)	G14Q3
64K60	PLUG - SENSOR(80 60 40 100)	G14Q3
83C64	PLUG-SPARK(80 60 40)	G14Q3
59C70	RELAY(60 40)	G14Q3
59C71	RELAY(60 40)	G14Q3
66C67	RELAY(80 60 40 100)	G14Q3
67750	RELAY(80 60 40)	G14Q3
54H13	SWITCH(100)	G14Q3
54G48	SWITCH(60 40)	G14Q3
23G13	SWITCH(60)	G14Q3
28G13	SWITCH(80 60 40)	G14Q3
28G12	SWITCH(80)	G14Q3
T6-2029	SWITCH-INTERLOCK(100)	G14Q3
41C42	SWITCH-INTERLOCK(80 60 40)	G14Q3
58H32	SWITCH-PRESS(100)	G14Q3
32F13	SWITCH-PRESS(40)	G14Q3
58H30	SWITCH-PRESS(60 40)	G14Q3
17F14	SWITCH-PRESS(80 60 40)	G14Q3
32F14	SWITCH-PRESS(80 60)	G14Q3
58H31	SWITCH-PRESS(80 60)	G14Q3
32F39	TERMINAL BOARD(80 40)	G14Q3
T6-1460	TERMINAL(80 40)	G14Q3
77C24	TERMINAL(80 60 40 100)	G14Q3
96C79	TRANSFORMER(60 40)	G14Q3
40F16	TRANSFORMER(80 40)	G14Q3
38631	TRANSFORMER(80 60 40 100)	G14Q3
50F49	TUBE-AIR(80 60 40)	G14Q3
LB-49995CA	VALVE-AIR(100)	G14Q3
LB-49995CA	VALVE-AIR(40)	G14Q3
LB-49995CA	VALVE-AIR(60)	G14Q3
LB-49995CB	VALVE-AIR(80)	G14Q3
51H60	VALVE-GAS(100)	G14Q3
24F97	VALVE-GAS(40)	G14Q3
26G91	VALVE-GAS(40)	G14Q3
11G29	VALVE-GAS(80 60 40)	G14Q3
28G14	VALVE-GAS(80 60 40)	G14Q3
33G90	VALVE-GAS(80 60 40)	G14Q3
51H25	VALVE-GAS(80 60 40)	G14Q3
54G28	VALVE-GAS(80 60 40)	G14Q3
77C17	VALVE-GAS(80 60)	G14Q3
T6-16	VALVE-GAS(80)	G14Q3
87A62	WHEEL-BLOWER(100)	G14Q3
21708	WHEEL-BLOWER(80 60 40 100)	G14Q3
32A73	WHEEL-BLOWER(80 60 40)	G14Q3
66F37	WHEEL-BLOWER(80 60 40)	G14Q3
82F76	WHEEL-BLOWER(80 60)	G14Q3

## G14Q4

15H21	AIR DECOUPLER BOX(80 60)	G14Q4
TC-30833	AIR DECOUPLER BOX(80 60)	G14Q4
LB-45918CC	AIR DIAPHRAGM ASS'Y(60)	G14Q4
LB-45918CB	AIR DIAPHRAGM ASS'Y(80 60)	G14Q4
LB-45918CD	AIR DIAPHRAGM ASS'Y(80)	G14Q4
LB-45918CE	AIR DIAPHRAGM ASS'Y(80)	G14Q4
LB-45918CT	AIR DIAPHRAGM ASS'Y(80)	G14Q4
80C93	BLOWER - PURGE(80 60)	G14Q4
78F25	BLOWER DECK(60)	G14Q4
TC-30778	BLOWER DECK(80 60)	G14Q4
38F92	BLOWER-PURGE(80 60)	G14Q4
21C52	BOOT-CAPACITOR(80 60)	G14Q4
39H89	CAPACITOR(80)	G14Q4
59C92	CAPACITOR-BLR MTR(80 60)	G14Q4
59C93	CAPACITOR-BLR MTR(80 60)	G14Q4
96C77	CARRIER-FUSE(60)	G14Q4
10F46	CONTROL-F&L(60)	G14Q4
15F71	CONTROL-F&L(60)	G14Q4
86G60	CONTROL-F&L(60)	G14Q4
T6-1546	CONTROL-F&L(60)	G14Q4
38F90	CONTROL-F&L(80 60)	G14Q4
15F72	CONTROL-F&L(80)	G14Q4
77C88	CONTROL-F&L(80)	G14Q4
T6-1547	CONTROL-F&L(80)	G14Q4
T6-1548	CONTROL-F&L(80)	G14Q4
99C97	CONTROL-PRIMARY(60)	G14Q4
60J00	CONTROL-PRIMARY(80 60)	G14Q4
20H85	DECOUPLER-GAS(60)	G14Q4
20H84	DECOUPLER-GAS(80 60)	G14Q4
20H59	DIAPHRAGM ASSY-AIR(60)	G14Q4
27F47	DIAPHRAGM ASSY-AIR(60)	G14Q4
27F48	DIAPHRAGM ASSY-AIR(80 60)	G14Q4
84G24	DIAPHRAGM ASSY-AIR(80 60)	G14Q4
12G78	DIAPHRAGM ASSY-AIR(80)	G14Q4
20H60	DIAPHRAGM ASSY-AIR(80)	G14Q4
27F46	DIAPHRAGM ASSY-GAS(60)	G14Q4
34G83	DIAPHRAGM ASSY-GAS(80 60)	G14Q4
LB-58163DA	DIAPHRAGM(80 60)	G14Q4
TC-30808	DRIP LEG ASS'Y(80 60)	G14Q4
83F48	DRIP LEG PKG(80 60)	G14Q4
38G47	E(80 60)	G14Q4
59611	ELBOW(80 60)	G14Q4
30335	FILTER(80 60)	G14Q4
32F22	FILTER-AIR(60)	G14Q4
32F24	FUSE(60)	G14Q4
96C78	FUSE(60)	G14Q4
21G46	FUSE(80 60)	G14Q4
67171	FUSE(80)	G14Q4

74G26	GAS DECOUPLER(80 60)	G14Q4
LB-45807DA	GAS DIAGRAM ASS'Y(80)	G14Q4
LB-56048DA	GAS DIAPHRAGM ASS'Y(80 60)	G14Q4
LB-51599CA	LEAD(60)	G14Q4
14F53	LEAD(80 60)	G14Q4
14H70	LEAD(80 60)	G14Q4
53H61	LEAD-IGNITION(60)	G14Q4
LB-51599CA	LEAD-IGNITION(60)	G14Q4
14F55	LEAD-IGNITION(80 60)	G14Q4
39F35	LEAD-IGNITION(80 60)	G14Q4
72G95	LEAD-IGNITION(80 60)	G14Q4
96G34	LEAD-IGNITION(80 60)	G14Q4
LB-51599CA	LEAD-IGNITION(80 60)	G14Q4
13K30	LP/NAT REG CONV KIT(80 60)	G14Q4
13K27	LP/NAT TUNE-UP KIT(60)	G14Q4
13K28	LP/NAT TUNE-UP KIT(80)	G14Q4
32904	MOTOR-BLOWER(80 60)	G14Q4
15B45	MOTOR-BLOWER(80 60)	G14Q4
57C25	MOTOR-BLOWER(80 60)	G14Q4
67F15	MOTOR-BLOWER(80 60)	G14Q4
LB-35721D	MOUNT-MOTOR(80 60)	G14Q4
67F81	MUFFLER(80 60)	G14Q4
44G78	ORIFICE(60)	G14Q4
44H14	ORIFICE(80)	G14Q4
76G28	ORIFICE(80)	G14Q4
37G70	ORIFICE-BURNER(60)	G14Q4
37G83	ORIFICE-BURNER(60)	G14Q4
38G44	ORIFICE-BURNER(60)	G14Q4
47F23	ORIFICE-BURNER(60)	G14Q4
90K05	ORIFICE-BURNER(60)	G14Q4
LB-57240D	ORIFICE-BURNER(60)	G14Q4
38G46	ORIFICE-BURNER(80 60)	G14Q4
37G82	ORIFICE-BURNER(80)	G14Q4
44G59	ORIFICE-BURNER(80)	G14Q4
47F24	ORIFICE-BURNER(80)	G14Q4
60G09	ORIFICE-BURNER(80)	G14Q4
LB-53443D	ORIFICE-BURNER(80)	G14Q4
LB-59142D	ORIFICE-BURNER(80)	G14Q4
77C25	O-RING(80 60)	G14Q4
43G62	PLUG - IGNITION(80 60)	G14Q4
64K60	PLUG - SENSOR(80 60)	G14Q4
83C64	PLUG-SPARK(80 60)	G14Q4
59C70	RELAY(60)	G14Q4
59C71	RELAY(60)	G14Q4
67750	RELAY(80 60)	G14Q4
66C67	RELAY(80 60)	G14Q4
LB-45795D	RETAINER-INSUL(80 60)	G14Q4
TC-30765	RETAINER-INSUL(80 60)	G14Q4
35G42	SCREW(80 60)	G14Q4
14F44	SEAL(80 60)	G14Q4
14F46	SEAL(80 60)	G14Q4

40G04	SEAL(80 60)	G14Q4
38538	STRIP TERMINAL(80 60)	G14Q4
54G48	SWITCH(60)	G14Q4
28G13	SWITCH(80 60)	G14Q4
28G12	SWITCH(80)	G14Q4
41C42	SWITCH-INTERLOCK(80 60)	G14Q4
58H30	SWITCH-PRESS(60)	G14Q4
17F14	SWITCH-PRESS(80 60)	G14Q4
32F14	SWITCH-PRESS(80 60)	G14Q4
58H31	SWITCH-PRESS(80 60)	G14Q4
32F39	TERMINAL BOARD(80)	G14Q4
77C24	TERMINAL(80 60)	G14Q4
T6-1460	TERMINAL(80)	G14Q4
96C79	TRANSFORMER(60)	G14Q4
38631	TRANSFORMER(80 60)	G14Q4
40F16	TRANSFORMER(80)	G14Q4
50F49	TUBE-AIR(80 60)	G14Q4
LB-49995CA	VALVE-AIR(60)	G14Q4
LB-49995CB	VALVE-AIR(80)	G14Q4
T6-1630	VALVE-GAS(60)	G14Q4
11G29	VALVE-GAS(80 60)	G14Q4
28G14	VALVE-GAS(80 60)	G14Q4
33G90	VALVE-GAS(80 60)	G14Q4
51H25	VALVE-GAS(80 60)	G14Q4
54G28	VALVE-GAS(80 60)	G14Q4
77C17	VALVE-GAS(80 60)	G14Q4
21708	WHEEL-BLOWER(80 60)	G14Q4
32A73	WHEEL-BLOWER(80 60)	G14Q4
66F37	WHEEL-BLOWER(80 60)	G14Q4
82F76	WHEEL-BLOWER(80 60)	G14Q4

### **G14Q4/5**

80C93	BLOWER - PURGE(100)	G14Q4/5
21C5201	BOOT-CAPACITOR(100)	G14Q4/5
39H5801	CAPACITOR(100)	G14Q4/5
39H89	CAPACITOR(100)	G14Q4/5
TC-30848	CAP-CABINET(100)	G14Q4/5
T6-1547	CONTROL-F&L(100)	G14Q4/5
T6-1608	CONTROL-F&L(100)	G14Q4/5
60J00	CONTROL-PRIMARY(100)	G14Q4/5
LB-58163DA	DIAPHRAGM(100)	G14Q4/5
TC-30808	DRIP LEG ASS'Y(100)	G14Q4/5
59436	FILTER(100)	G14Q4/5
32F23	FITTING(100)	G14Q4/5
74G26	GAS DECOUPLER(100)	G14Q4/5
28G82	GROMMET-RUBBER(100)	G14Q4/5
LB-51599CA	LEAD - IGNITION(100)	G14Q4/5
39G09	LEAD(100)	G14Q4/5
28F0101	MOTOR-BLOWER(100)	G14Q4/5
67F15	MOTOR-BLOWER(100)	G14Q4/5

29G72	ORIFICE-BURNER(100)	G14Q4/5
LB-54338D	ORIFICE-BURNER(100)	G14Q4/5
43G62	PLUG - IGNITION(100)	G14Q4/5
64K60	PLUG - SENSOR(100)	G14Q4/5
66C67	RELAY(100)	G14Q4/5
T6-2074	RETAINER-INSUL.(100)	G14Q4/5
54H13	SWITCH(100)	G14Q4/5
T6-2029	SWITCH-INTERLOCK(100)	G14Q4/5
58H32	SWITCH-PRESS(100)	G14Q4/5
38631	TRANSFORMER(100)	G14Q4/5
51H60	VALVE-GAS(100)	G14Q4/5
21708	WHEEL-BLOWER(100)	G14Q4/5
87A62	WHEEL-BLOWER(100)	G14Q4/5

### G14Q5

80C93	BLOWER - PURGE(80 100)	G14Q5
84F06	BLOWER DECK(80 130 100)	G14Q5
78F25	BLOWER DECK(80)	G14Q5
78F02	BLOWER-PURGE(130)	G14Q5
38F92	BLOWER-PURGE(80 130 100)	G14Q5
96C48	CAPACITOR(80 130 100)	G14Q5
39H89	CAPACITOR(80)	G14Q5
59C93	CAPACITOR-BLR MTR(80 100)	G14Q5
96C52	CAPACITOR-BLR MTR(80 130 100)	G14Q5
59C92	CAPACITOR-BLR MTR(80)	G14Q5
96C77	CARRIER-FUSE(80 130 100)	G14Q5
66857	CONNECTOR(80 130 100)	G14Q5
11F65	CONNECTOR(80 130 100)	G14Q5
14F31	CONNECTOR(80 130 100)	G14Q5
10F46	CONTROL-F&L(100)	G14Q5
78F00	CONTROL-F&L(100)	G14Q5
15F72	CONTROL-F&L(80 100)	G14Q5
38F90	CONTROL-F&L(80 130 100)	G14Q5
77C88	CONTROL-F&L(80 130 100)	G14Q5
60J00	CONTROL-PRIMARY(80 130 100)	G14Q5
99C97	CONTROL-PRIMARY(80 130 100)	G14Q5
44H24	COUPLING-EXHAUST(130 100)	G14Q5
54G93	COUPLING-EXHAUST(80)	G14Q5
20H84	DECOUPLER-GAS(80 130 100)	G14Q5
20H85	DECOUPLER-GAS(80)	G14Q5
44G64	DIAPHRAGM ASSY-AIR(100)	G14Q5
49G36	DIAPHRAGM ASSY-AIR(100)	G14Q5
84G25	DIAPHRAGM ASSY-AIR(100)	G14Q5
31F06	DIAPHRAGM ASSY-AIR(130)	G14Q5
87F02	DIAPHRAGM ASSY-AIR(130)	G14Q5
11G30	DIAPHRAGM ASSY-AIR(80)	G14Q5
12G78	DIAPHRAGM ASSY-AIR(80)	G14Q5
20H60	DIAPHRAGM ASSY-AIR(80)	G14Q5
27F48	DIAPHRAGM ASSY-AIR(80)	G14Q5
68F89	DIAPHRAGM ASSY-AIR(80)	G14Q5

84G24	DIAPHRAGM ASSY-AIR(80)	G14Q5
31F04	DIAPHRAGM ASSY-GAS(130 100)	G14Q5
34G83	DIAPHRAGM ASSY-GAS(80 100)	G14Q5
27F46	DIAPHRAGM ASSY-GAS(80)	G14Q5
LB-58163DA	DIAPHRAGM(80 100)	G14Q5
34G56	DRIP LEG PKG(100)	G14Q5
83F49	DRIP LEG PKG(130 100)	G14Q5
10G78	DRIP LEG PKG(80)	G14Q5
83F48	DRIP LEG PKG(80)	G14Q5
59436	FILTER(80 130 100)	G14Q5
30335	FILTER(80)	G14Q5
32F22	FILTER-AIR(80)	G14Q5
32F23	FITTING(80 100)	G14Q5
21G46	FUSE(80 130 100)	G14Q5
32F24	FUSE(80 130 100)	G14Q5
96C78	FUSE(80 130 100)	G14Q5
LB-48	GASKET(100)	G14Q5
50F89	GASKET(130 100)	G14Q5
14F53	LEAD(80 130 100)	G14Q5
14H70	LEAD(80)	G14Q5
14F55	LEAD-IGNITION(80 130 100)	G14Q5
39F35	LEAD-IGNITION(80 130 100)	G14Q5
72G95	LEAD-IGNITION(80)	G14Q5
96G34	LEAD-IGNITION(80)	G14Q5
LB-51599CA	LEAD-IGNITION(80)	G14Q5
13K30	LP/NAT REG CONV KIT(80 100)	G14Q5
13K29	LP/NAT TUNE-UP KIT(100)	G14Q5
13K28	LP/NAT TUNE-UP KIT(80)	G14Q5
32904	MOTOR-BLOWER(80 100)	G14Q5
67F15	MOTOR-BLOWER(80 100)	G14Q5
28F01	MOTOR-BLOWER(80 130 100)	G14Q5
49C10	MOTOR-BLOWER(80 130 100)	G14Q5
15B45	MOTOR-BLOWER(80)	G14Q5
57C25	MOTOR-BLOWER(80)	G14Q5
67F81	MUFFLER(80 130 100)	G14Q5
37G75	ORIFICE(100)	G14Q5
76G29	ORIFICE(100)	G14Q5
44H14	ORIFICE(80)	G14Q5
37G76	ORIFICE-BURNER(100)	G14Q5
37G77	ORIFICE-BURNER(100)	G14Q5
37G84	ORIFICE-BURNER(100)	G14Q5
37G78	ORIFICE-BURNER(130)	G14Q5
37G79	ORIFICE-BURNER(130)	G14Q5
37G72	ORIFICE-BURNER(80)	G14Q5
37G80	ORIFICE-BURNER(80)	G14Q5
37G81	ORIFICE-BURNER(80)	G14Q5
37G82	ORIFICE-BURNER(80)	G14Q5
38G46	ORIFICE-BURNER(80)	G14Q5
60G09	ORIFICE-BURNER(80)	G14Q5
LB-51	ORIFICE-BURNER(80)	G14Q5
LB-51	ORIFICE-BURNER(80)	G14Q5



43G62	PLUG - IGNITION(80 100)	G14Q5
64K60	PLUG - SENSOR(80 130 100)	G14Q5
83C64	PLUG-SPARK(80 130 100)	G14Q5
66C67	RELAY(100)	G14Q5
67750	RELAY(80 130 100)	G14Q5
59C70	RELAY(80 130 100)	G14Q5
59C71	RELAY(80 130 100)	G14Q5
28G13	SWITCH(80 100)	G14Q5
41C42	SWITCH-INTERLOCK(80 130 100)	G14Q5
58H32	SWITCH-PRESS(100)	G14Q5
31F45	SWITCH-PRESS(130 100)	G14Q5
32F13	SWITCH-PRESS(130 100)	G14Q5
17F14	SWITCH-PRESS(80)	G14Q5
32F14	SWITCH-PRESS(80)	G14Q5
58H31	SWITCH-PRESS(80)	G14Q5
38631	TRANSFORMER(80 130 100)	G14Q5
96C79	TRANSFORMER(80 130 100)	G14Q5
LB-49995CA	VALVE-AIR(100)	G14Q5
LB-49995CB	VALVE-AIR(80)	G14Q5
73F70	VALVE-GAS(100)	G14Q5
78F01	VALVE-GAS(130 100)	G14Q5
28G14	VALVE-GAS(80 100)	G14Q5
33G90	VALVE-GAS(80 100)	G14Q5
11G29	VALVE-GAS(80)	G14Q5
51H25	VALVE-GAS(80)	G14Q5
54G28	VALVE-GAS(80)	G14Q5
77C17	VALVE-GAS(80)	G14Q5
21708	WHEEL-BLOWER(80 100)	G14Q5
87A62	WHEEL-BLOWER(80 130 100)	G14Q5
66F37	WHEEL-BLOWER(80)	G14Q5
66F37	WHEEL-BLOWER(80)	G14Q5
82F76	WHEEL-BLOWER(80)	G14Q5

### **G15D2E**

73F84	BURNER-MAIN(50)	G15D2E
73F85	BURNER-MAIN(50)	G15D2E
74F01	CABLE(50)	G15D2E
32588	CONTROL-F&L(50)	G15D2E
73F91	CONTROL-IGN(50)	G15D2E
74F00	DAMPER(50)	G15D2E
73F82	DIVERTER(50)	G15D2E
73F83	DIVERTER(50)	G15D2E
73F88	FLAME SPREADER(50)	G15D2E
73F92	FUSE(50)	G15D2E
73F90	LEAD(50)	G15D2E
73F93	LEAD-IGNITION(50)	G15D2E
73F86	MANIFOLD-GAS(50)	G15D2E
32662	MOTOR-BLOWER(50)	G15D2E
73F87	ORIFICE-BURNER(50)	G15D2E
38276	RELAY(50)	G15D2E

78F75	STRIKE(50)	G15D2E
72C96	SWITCH-INTERLOCK(50)	G15D2E
73F94	TRANSFORMER(50)	G15D2E
73F89	VALVE-GAS(50)	G15D2E
47A40	WHEEL-BLOWER(50)	G15D2E

### **G15Q3.5E**

73F99	ACTUATOR-DAMPER(60)	G15Q3.5E
73F84	BURNER-MAIN(60)	G15Q3.5E
73F85	BURNER-MAIN(60)	G15Q3.5E
74F01	CABLE(60)	G15Q3.5E
81A38	CAPACITOR-FAN MTR(60)	G15Q3.5E
89A02	CONTROL-F&L(60)	G15Q3.5E
73F91	CONTROL-IGN(60)	G15Q3.5E
74F00	DAMPER(60)	G15Q3.5E
74F08	DIVERTER(60)	G15Q3.5E
74F09	DIVERTER(60)	G15Q3.5E
74F12	FLAME SPREADER(60)	G15Q3.5E
73F92	FUSE(60)	G15Q3.5E
73F90	LEAD(60)	G15Q3.5E
73F93	LEAD-IGNITION(60)	G15Q3.5E
74F10	MANIFOLD-GAS(60)	G15Q3.5E
32663	MOTOR-BLOWER(60)	G15Q3.5E
74F11	ORIFICE-BURNER(60)	G15Q3.5E
38276	RELAY(60)	G15Q3.5E
78F75	STRIKE(60)	G15Q3.5E
74F06	STRIP-TOP(60)	G15Q3.5E
72C96	SWITCH-INTERLOCK(60)	G15Q3.5E
73F94	TRANSFORMER(60)	G15Q3.5E
74F13	VALVE-GAS(60)	G15Q3.5E
74F16	WHEEL-BLOWER(60)	G15Q3.5E

### **G15Q4E**

73F99	ACTUATOR-DAMPER(100)	G15Q4E
73F84	BURNER-MAIN(100)	G15Q4E
73F85	BURNER-MAIN(100)	G15Q4E
74F01	CABLE(100)	G15Q4E
74F02	CABLE(100)	G15Q4E
81A40	CAPACITOR(100)	G15Q4E
32588	CONTROL-F&L(100)	G15Q4E
73F91	CONTROL-IGN(100)	G15Q4E
74F31	DAMPER(100)	G15Q4E
74F24	DIVERTER(100)	G15Q4E
74F25	DIVERTER(100)	G15Q4E
74F27	FLAME SPREADER(100)	G15Q4E
73F92	FUSE(100)	G15Q4E
73F90	LEAD(100)	G15Q4E
73F93	LEAD-IGNITION(100)	G15Q4E
32904	MOTOR-BLOWER(100)	G15Q4E

73F87	ORIFICE-BURNER(100)	G15Q4E
38276	RELAY(100)	G15Q4E
78F75	STRIKE(100)	G15Q4E
72C96	SWITCH-INTERLOCK(100)	G15Q4E
73F94	TRANSFORMER(100)	G15Q4E
74F13	VALVE-GAS(100)	G15Q4E
74F30	WHEEL-BLOWER(100)	G15Q4E

### **G15Q5E**

73F99	ACTUATOR-DAMPER(125)	G15Q5E
73F84	BURNER-MAIN(125)	G15Q5E
73F85	BURNER-MAIN(125)	G15Q5E
74F02	CABLE(125)	G15Q5E
74F46	CABLE(125)	G15Q5E
81A42	CAPACITOR-BLR MTR(125)	G15Q5E
87316	CONTROL-F&L(125)	G15Q5E
73F91	CONTROL-IGN(125)	G15Q5E
74F31	DAMPER(125)	G15Q5E
74F37	DIVERTER(125)	G15Q5E
74F38	DIVERTER(125)	G15Q5E
74F40	FLAME SPREADER(125)	G15Q5E
73F92	FUSE(125)	G15Q5E
73F90	LEAD(125)	G15Q5E
73F93	LEAD-IGNITION(125)	G15Q5E
74F43	MOTOR-BLOWER(125)	G15Q5E
73F87	ORIFICE-BURNER(125)	G15Q5E
38276	RELAY(125)	G15Q5E
78F75	STRIKE(125)	G15Q5E
72C96	SWITCH-INTERLOCK(125)	G15Q5E
73F94	TRANSFORMER(125)	G15Q5E
74F13	VALVE-GAS(125)	G15Q5E
40F85	WHEEL-BLOWER(125)	G15Q5E

### **G16**

32865	ARM-MOTOR MOUNT(75)	G16
46G02	BAFFLE - FLUE(75 50 100)	G16
LB-15	BAFFLE(75)	G16
24G64	BAFFLE-FLUE(100)	G16
LB-52	BAFFLE-FLUE(75 50)	G16
32866	BAND-MOTOR(75)	G16
70G23	BLOWER - EXHAUST(75 100)	G16
70G24	BLOWER - EXHAUST(75 100)	G16
TC-31	BLOWER - EXHAUST(75 100)	G16
47H12	BLOWER-INDUCED DRAFT(75 50 100)	G16
51G78	BLOWER-INDUCED DRAFT(75 50 100)	G16
99G96	BLOWER-INDUCED DRAFT(75 50 100)	G16
21C52	BOOT-CAPACITOR(75 100)	G16
LB-55	BRACKET(75 50 100)	G16
12H68	BURNER - MAIN(75 100)	G16

18G90	BURNER - PILOT(75 50 100)	G16
50F60	BURNER - PILOT(75 50 100)	G16
35H93	BURNER-MAIN(100)	G16
12H69	BURNER-MAIN(75 100)	G16
34G61	BURNER-MAIN(75 50 100)	G16
34G62	BURNER-MAIN(75 50 100)	G16
81F94	BURNER-MAIN(75 50 100)	G16
82F60	BURNER-MAIN(75 50 100)	G16
61478	BURNER-PILOT(75 50 100)	G16
43G82	BURNER-PILOT(75 50 100)	G16
86012	BUSHING-SNAP(75 50 100)	G16
10H57	CAP - CABINET(100)	G16
TC-30	CAP - CABINET(100)	G16
TC-30	CAP - CABINET(100)	G16
10H56	CAP - CABINET(75)	G16
TC-30	CAP - CABINET(75)	G16
81A39	CAPACITOR(100)	G16
96C48	CAPACITOR(100)	G16
59C93	CAPACITOR-BLR MTR(75 100)	G16
59C92	CAPACITOR-BLR MTR(75 50)	G16
53H32	CAPACITOR-FAN MTR(100)	G16
81A38	CAPACITOR-FAN MTR(50)	G16
46G72	CAP-CABINET(75 100)	G16
88F17	CAP-CABINET(75 100)	G16
11G17	CAP-CABINET(75 50)	G16
62G48	CAP-CABINET(75 50)	G16
75G85	CAP-CABINET(75)	G16
40H35	CLAMP - FILTER(75 100)	G16
70G15	CONTROL - RESET(75 100)	G16
46G45	CONTROL (-50 ONLY)(100)	G16
70G16	CONTROL(75 100)	G16
T6-16	CONTROL(75)	G16
70F90	CONTROL-F&L(100)	G16
78F06	CONTROL-F&L(100)	G16
13B85	CONTROL-F&L(50)	G16
78F11	CONTROL-F&L(50)	G16
91E64	CONTROL-F&L(75 100)	G16
78F08	CONTROL-F&L(75 50 100)	G16
70C83	CONTROL-F&L(75 50)	G16
70F89	CONTROL-F&L(75 50)	G16
78F07	CONTROL-F&L(75 50)	G16
13H65	CONTROL-F&L(75)	G16
17G31	CONTROL-IGN(75 50 100)	G16
18G91	CONTROL-IGN(75 50 100)	G16
20H77	CONTROL-IGN(75 50 100)	G16
TC-30	COVER - CONTROL BOX(75 100)	G16
51F12	COVER-CONTROL BOX(75 50 100)	G16
86501	COVER-POUCH(100)	G16
38G65	COVER-POUCH(100)	G16
64G49	COVER-POUCH(100)	G16
LB-52	COVER-POUCH(100)	G16

LB-62	COVER-POUCH(100)	G16
LB-62	COVER-POUCH(100)	G16
LB-62	COVER-POUCH(50)	G16
LB-62	COVER-POUCH(50)	G16
61701	COVER-POUCH(75 50)	G16
39G29	COVER-POUCH(75 50)	G16
LB-51	COVER-POUCH(75 50)	G16
LB-52	COVER-POUCH(75 50)	G16
50H15	COVER-POUCH(75)	G16
LB-62	COVER-POUCH(75)	G16
30G95	DIVERTER(100)	G16
50G06	DIVERTER(100)	G16
11G80	DIVERTER(75 50)	G16
56G53	DIVERTER(75 50)	G16
43G28	DIVERTER(75)	G16
TC-30	DOOR - BLOWER(100)	G16
TC-30	DOOR - BLOWER(75)	G16
88F16	DOOR - LOUVRE(100)	G16
TC-30	DOOR - LOUVRE(100)	G16
TC-30	DOOR - LOUVRE(100)	G16
86F88	DOOR - LOUVRE(75 50)	G16
15H11	DOOR - LOUVRE(75)	G16
88G00	DOOR - LOUVRE(75)	G16
TC-30	FLUE TRANSITION(100)	G16
TC-30	FLUE TRANSITION(100)	G16
TC-30	FLUE TRANSITION(75)	G16
TC-30	FLUE TRANSITION(75)	G16
67171	FUSE(75 100)	G16
32F24	FUSE(75 50 100)	G16
85A66	GAS VALVE(75 50 100)	G16
24G62	GASKET - FLUE(100)	G16
13G05	GASKET - TRANSITION(75 50 100)	G16
46G01	GASKET(75 50 100)	G16
46G04	GASKET(75 50 100)	G16
87F17	GASKET(75 50 100)	G16
24G63	GASKET(75 50)	G16
77C15	HANDLE-DOOR(75 50 100)	G16
20H31	HEAT EXCHANGER(100)	G16
27G91	HEAT EXCHANGER(100)	G16
41G26	HEAT EXCHANGER(100)	G16
73F75	HEAT EXCHANGER(100)	G16
LB-17	HEAT EXCHANGER(100)	G16
TC-30	HEAT EXCHANGER(100)	G16
TC-30	HEAT EXCHANGER(100)	G16
41G22	HEAT EXCHANGER(50)	G16
41G23	HEAT EXCHANGER(50)	G16
73F72	HEAT EXCHANGER(50)	G16
41G24	HEAT EXCHANGER(75)	G16
41G25	HEAT EXCHANGER(75)	G16
73F73	HEAT EXCHANGER(75)	G16
73F74	HEAT EXCHANGER(75)	G16

LB-17	HEAT EXCHANGER(75)	G16
TC-30	HEAT EXCHANGER(75)	G16
TC-30	HEAT EXCHANGER(75)	G16
TC-31	HEAT EXCHANGER(75)	G16
60579	HOLDER-FUSE(75 50 100)	G16
90G74	HOUSING BLOWER(75 100)	G16
21838	HOUSING-BLOWER(100)	G16
LB-17	HOUSING-BLOWER(100)	G16
85C33	HOUSING-BLOWER(50)	G16
22F20	HOUSING-BLOWER(75 50)	G16
53H02	KIT-CAPACITOR(75 100)	G16
96G23	KIT-UPDATE(75 50 100)	G16
WO822	LEAD(100)	G16
38G26	LEAD(75 50 100)	G16
88A12	LEAD(75 50)	G16
54J41	LEAD-IGNITION(75 50 100)	G16
14H16	MANIFOLD - GAS(100)	G16
TC-30	MANIFOLD - GAS(100)	G16
59H74	MANIFOLD - GAS(75)	G16
TC-30	MANIFOLD - GAS(75)	G16
61589	MANIFOLD-GAS(100)	G16
56C52	MANIFOLD-GAS(50)	G16
39C23	MANIFOLD-GAS(75)	G16
LB-17	MEDIA - FILTER(100)	G16
59A69	MEDIA-FILTER(75 100)	G16
26G42	MOTOR - EXHAUST(75 100)	G16
51F07	MOTOR - EXHAUST(75 100)	G16
28F01	MOTOR-BLOWER(100)	G16
67F15	MOTOR-BLOWER(75 100)	G16
67F14	MOTOR-BLOWER(75 50)	G16
79A52	MOTOR-BLOWER(75 50)	G16
32904	MOTOR-BLOWER(75)	G16
89C36	MOTOR-BLOWER(75)	G16
78A18	MOUNT-MOTOR(100)	G16
86851	MOUNT-MOTOR(75)	G16
83G13	ORIFICE(100)	G16
83G11	ORIFICE(75 100)	G16
78A25	ORIFICE(75)	G16
TC-31	ORIFICE(75)	G16
60334	ORIFICE-BURNER(75 50 100)	G16
LB-13	ORIFICE-BURNER(75 50 100)	G16
12F22	ORIFICE-PILOT(75 50 100)	G16
29G35	PANEL(100)	G16
70G21	PANEL(100)	G16
74G46	PANEL(100)	G16
86F33	PANEL(100)	G16
LB-56	PANEL(100)	G16
LB-56	PANEL(50)	G16
39G33	PANEL(75 100)	G16
49G98	PANEL(75 100)	G16
77H46	PANEL(75 100)	G16

25G66	PANEL(75 50 100)	G16
LB-51	PANEL(75 50)	G16
29G36	PANEL(75)	G16
84G41	PANEL(75)	G16
21917	PLATE-CUTOFF(100)	G16
LB-01	PLATE-CUTOFF(100)	G16
53928	PLATE-CUTOFF(50)	G16
50279	PLATE-CUTOFF(75 100)	G16
53A30	PLATE-CUTOFF(75 50)	G16
TC-30	POUCH - FLUE(100)	G16
TC-31	POUCH - FLUE(100)	G16
TC-30	POUCH - FLUE(75)	G16
TC-31	POUCH - FLUE(75)	G16
86815	RACK - FILTER(100)	G16
TC-30	RACK - FILTER(100)	G16
TC-30	RACK - FILTER(100)	G16
TC-30	RACK - FILTER(75)	G16
TC-30	RACK - FILTER(75)	G16
86818	RACK-FILTER(75 100)	G16
53536	RACK-FILTER(75 50)	G16
37648	RELAY(75 50 100)	G16
59510	RELAY(75 50 100)	G16
67750	RELAY(75 50 100)	G16
48G95	RELAY(75 50 100)	G16
66C67	RELAY(75 50 100)	G16
48G96	RELAY(75)	G16
89F95	ROD(75 50 100)	G16
12F19	SENSOR-FLAME(75 50 100)	G16
18G89	SENSOR-FLAME(75 50 100)	G16
24G75	SEQUENCER(75 100)	G16
85980	SHUTTER-AIR(75 50 100)	G16
28G23	SPRING(75 50 100)	G16
73F19	SPRING(75 50 100)	G16
87129	SUPPORT(75 50 100)	G16
57C24	SUPPORT-CABLE(75 50 100)	G16
26H92	SWITCH(75 50 100)	G16
41C42	SWITCH-INTERLOCK(75 50 100)	G16
41C59	SWITCH-INTERLOCK(75 50 100)	G16
28G91	SWITCH-PRESS(100)	G16
51F10	SWITCH-PRESS(50)	G16
46H51	SWITCH-PRESS(75 100)	G16
46H52	SWITCH-PRESS(75 100)	G16
46H53	SWITCH-PRESS(75 100)	G16
28G00	SWITCH-PRESS(75 50 100)	G16
51F11	SWITCH-PRESS(75 50 100)	G16
93G19	SWITCH-PRESS(75 50 100)	G16
78F37	SWITCH-PRESS(75)	G16
77C24	TERMINAL(75 50)	G16
38631	TRANSFORMER(75 50 100)	G16
60G10	TUBING(50 100)	G16
TC-30	TUBING(75 100)	G16

15G46	TUBING(75 50 100)	G16
12H22	TUBING(75 50)	G16
19H26	TUBING(75)	G16
12B57	VALVE-GAS(75 50 100)	G16
17G28	VALVE-GAS(75 50 100)	G16
18G88	VALVE-GAS(75 50 100)	G16
31193	VALVE-SHUTOFF(75 50 100)	G16
T6-16	VENT - PIPE(75 100)	G16
TC-31	VENT BOX(75 100)	G16
32A73	WHEEL-BLOWER(100)	G16
87A62	WHEEL-BLOWER(100)	G16
21708	WHEEL-BLOWER(75 100)	G16
P-5-1	WHEEL-BLOWER(75 50)	G16
P-5-2	WHEEL-BLOWER(75 50)	G16

### G16Q2

47H12	BLOWER-INDUCED DRAFT(50)	G16Q2
51G78	BLOWER-INDUCED DRAFT(50)	G16Q2
99G96	BLOWER-INDUCED DRAFT(50)	G16Q2
18G90	BURNER - PILOT(50)	G16Q2
50F60	BURNER - PILOT(50)	G16Q2
34G61	BURNER-MAIN(50)	G16Q2
34G62	BURNER-MAIN(50)	G16Q2
81F94	BURNER-MAIN(50)	G16Q2
82F60	BURNER-MAIN(50)	G16Q2
61478	BURNER-PILOT(50)	G16Q2
43G82	BURNER-PILOT(50)	G16Q2
59C92	CAPACITOR-BLR MTR(50)	G16Q2
81A38	CAPACITOR-FAN MTR(50)	G16Q2
13B85	CONTROL-F&L(50)	G16Q2
70C83	CONTROL-F&L(50)	G16Q2
70F89	CONTROL-F&L(50)	G16Q2
78F07	CONTROL-F&L(50)	G16Q2
78F08	CONTROL-F&L(50)	G16Q2
78F11	CONTROL-F&L(50)	G16Q2
17G31	CONTROL-IGN(50)	G16Q2
18G91	CONTROL-IGN(50)	G16Q2
20H77	CONTROL-IGN(50)	G16Q2
11G80	DIVERTER(50)	G16Q2
56G53	DIVERTER(50)	G16Q2
32F24	FUSE(50)	G16Q2
85A66	GAS VALVE(50)	G16Q2
60579	HOLDER-FUSE(50)	G16Q2
38G26	LEAD(50)	G16Q2
88A12	LEAD(50)	G16Q2
54J41	LEAD-IGNITION(50)	G16Q2
67F14	MOTOR-BLOWER(50)	G16Q2
79A52	MOTOR-BLOWER(50)	G16Q2
60334	ORIFICE-BURNER(50)	G16Q2
LB-13437DA	ORIFICE-BURNER(50)	G16Q2



12F22	ORIFICE-PILOT(50)	G16Q2
37648	RELAY(50)	G16Q2
59510	RELAY(50)	G16Q2
67750	RELAY(50)	G16Q2
48G95	RELAY(50)	G16Q2
66C67	RELAY(50)	G16Q2
89F95	ROD(50)	G16Q2
12F19	SENSOR-FLAME(50)	G16Q2
18G89	SENSOR-FLAME(50)	G16Q2
85980	SHUTTER-AIR(50)	G16Q2
28G23	SPRING(50)	G16Q2
73F19	SPRING(50)	G16Q2
26H92	SWITCH(50)	G16Q2
41C42	SWITCH-INTERLOCK(50)	G16Q2
41C59	SWITCH-INTERLOCK(50)	G16Q2
28G00	SWITCH-PRESS(50)	G16Q2
51F10	SWITCH-PRESS(50)	G16Q2
51F11	SWITCH-PRESS(50)	G16Q2
93G19	SWITCH-PRESS(50)	G16Q2
38631	TRANSFORMER(50)	G16Q2
12B57	VALVE-GAS(50)	G16Q2
17G28	VALVE-GAS(50)	G16Q2
18G88	VALVE-GAS(50)	G16Q2
P-5-172	WHEEL-BLOWER(50)	G16Q2
P-5-226	WHEEL-BLOWER(50)	G16Q2

G16Q2H

70G24	BLOWER - EXHAUST(75 50)	G16Q2H
TC-31	BLOWER - EXHAUST(75 50)	G16Q2H
70G23	BLOWER - EXHAUST(75)	G16Q2H
21C52	BOOT-CAPACITOR(75 50)	G16Q2H
12H68	BURNER - MAIN(75 50)	G16Q2H
18G90	BURNER - PILOT(75 50)	G16Q2H
50F60	BURNER - PILOT(75 50)	G16Q2H
12H69	BURNER-MAIN(75 50)	G16Q2H
40H35	CLAMP - FILTER(75 50)	G16Q2H
70G15	CONTROL - RESET(75 50)	G16Q2H
46G43	CONTROL(50)	G16Q2H
70G16	CONTROL(75 50)	G16Q2H
91E64	CONTROL-F&L(75 50)	G16Q2H
13H65	CONTROL-F&L(75)	G16Q2H
18G91	CONTROL-IGN(75 50)	G16Q2H
67171	FUSE(75 50)	G16Q2H
32F24	FUSE(75 50)	G16Q2H
85A66	GAS VALVE(75 50)	G16Q2H
60579	HOLDER-FUSE(75 50)	G16Q2H
53H02	KIT-CAPACITOR(75 50)	G16Q2H
59A69	MEDIA-FILTER(75 50)	G16Q2H
26G42	MOTOR - EXHAUST(75 50)	G16Q2H
51F07	MOTOR - EXHAUST(75 50)	G16Q2H

67F14	MOTOR-BLOWER(75 50)	G16Q2H
89C36	MOTOR-BLOWER(75 50)	G16Q2H
83G11	ORIFICE(75)	G16Q2H
LB-13437DA	ORIFICE-BURNER(75 50)	G16Q2H
59510	RELAY(75 50)	G16Q2H
48G96	RELAY(75 50)	G16Q2H
66C67	RELAY(75 50)	G16Q2H
12F19	SENSOR-FLAME(75 50)	G16Q2H
18G89	SENSOR-FLAME(75 50)	G16Q2H
24G75	SEQUENCER(75 50)	G16Q2H
41C42	SWITCH-INTERLOCK(75 50)	G16Q2H
46H51	SWITCH-PRESS(75 50)	G16Q2H
46H52	SWITCH-PRESS(75 50)	G16Q2H
46H53	SWITCH-PRESS(75 50)	G16Q2H
38G31	TRANSFORMER(75 50)	G16Q2H
18G88	VALVE-GAS(75 50)	G16Q2H
P-5-172	WHEEL-BLOWER(75 50)	G16Q2H
P-5-226	WHEEL-BLOWER(75 50)	G16Q2H

### **G16Q2X**

47H12	BLOWER-INDUCED DRAFT(50)	G16Q2X
51G78	BLOWER-INDUCED DRAFT(50)	G16Q2X
99G96	BLOWER-INDUCED DRAFT(50)	G16Q2X
18G90	BURNER - PILOT(50)	G16Q2X
50F60	BURNER - PILOT(50)	G16Q2X
34G61	BURNER-MAIN(50)	G16Q2X
34G62	BURNER-MAIN(50)	G16Q2X
81F94	BURNER-MAIN(50)	G16Q2X
82F60	BURNER-MAIN(50)	G16Q2X
61478	BURNER-PILOT(50)	G16Q2X
43G82	BURNER-PILOT(50)	G16Q2X
59C92	CAPACITOR-BLR MTR(50)	G16Q2X
81A38	CAPACITOR-FAN MTR(50)	G16Q2X
13B85	CONTROL-F&L(50)	G16Q2X
70C83	CONTROL-F&L(50)	G16Q2X
70F89	CONTROL-F&L(50)	G16Q2X
78F07	CONTROL-F&L(50)	G16Q2X
78F08	CONTROL-F&L(50)	G16Q2X
78F11	CONTROL-F&L(50)	G16Q2X
17G31	CONTROL-IGN(50)	G16Q2X
18G91	CONTROL-IGN(50)	G16Q2X
20H77	CONTROL-IGN(50)	G16Q2X
11G80	DIVERTER(50)	G16Q2X
56G53	DIVERTER(50)	G16Q2X
32F24	FUSE(50)	G16Q2X
85A66	GAS VALVE(50)	G16Q2X
60579	HOLDER-FUSE(50)	G16Q2X
38G26	LEAD(50)	G16Q2X
88A12	LEAD(50)	G16Q2X
54J41	LEAD-IGNITION(50)	G16Q2X

67F14	MOTOR-BLOWER(50)	G16Q2X
79A52	MOTOR-BLOWER(50)	G16Q2X
60334	ORIFICE-BURNER(50)	G16Q2X
LB-13437DA	ORIFICE-BURNER(50)	G16Q2X
12F22	ORIFICE-PILOT(50)	G16Q2X
37648	RELAY(50)	G16Q2X
59510	RELAY(50)	G16Q2X
67750	RELAY(50)	G16Q2X
48G95	RELAY(50)	G16Q2X
66C67	RELAY(50)	G16Q2X
89F95	ROD(50)	G16Q2X
12F19	SENSOR-FLAME(50)	G16Q2X
18G89	SENSOR-FLAME(50)	G16Q2X
85980	SHUTTER-AIR(50)	G16Q2X
28G23	SPRING(50)	G16Q2X
73F19	SPRING(50)	G16Q2X
26H92	SWITCH(50)	G16Q2X
41C42	SWITCH-INTERLOCK(50)	G16Q2X
41C59	SWITCH-INTERLOCK(50)	G16Q2X
28G00	SWITCH-PRESS(50)	G16Q2X
51F10	SWITCH-PRESS(50)	G16Q2X
51F11	SWITCH-PRESS(50)	G16Q2X
93G19	SWITCH-PRESS(50)	G16Q2X
38631	TRANSFORMER(50)	G16Q2X
12B57	VALVE-GAS(50)	G16Q2X
17G28	VALVE-GAS(50)	G16Q2X
18G88	VALVE-GAS(50)	G16Q2X
P-5-172	WHEEL-BLOWER(50)	G16Q2X
P-5-226	WHEEL-BLOWER(50)	G16Q2X

### G16Q3

47H12	BLOWER-INDUCED DRAFT(75 50)	G16Q3
51G78	BLOWER-INDUCED DRAFT(75 50)	G16Q3
99G96	BLOWER-INDUCED DRAFT(75 50)	G16Q3
18G90	BURNER - PILOT(75 50)	G16Q3
50F60	BURNER - PILOT(75 50)	G16Q3
34G61	BURNER-MAIN(75 50)	G16Q3
34G62	BURNER-MAIN(75 50)	G16Q3
81F94	BURNER-MAIN(75 50)	G16Q3
82F60	BURNER-MAIN(75 50)	G16Q3
61478	BURNER-PILOT(75 50)	G16Q3
43G82	BURNER-PILOT(75 50)	G16Q3
59C92	CAPACITOR-BLR MTR(75 50)	G16Q3
59C93	CAPACITOR-BLR MTR(75)	G16Q3
81A38	CAPACITOR-FAN MTR(50)	G16Q3
13B85	CONTROL-F&L(50)	G16Q3
78F11	CONTROL-F&L(50)	G16Q3
70C83	CONTROL-F&L(75 50)	G16Q3
70F89	CONTROL-F&L(75 50)	G16Q3
78F07	CONTROL-F&L(75 50)	G16Q3

78F08	CONTROL-F&L(75 50)	G16Q3
17G31	CONTROL-IGN(75 50)	G16Q3
18G91	CONTROL-IGN(75 50)	G16Q3
20H77	CONTROL-IGN(75 50)	G16Q3
11G80	DIVERTER(75 50)	G16Q3
56G53	DIVERTER(75 50)	G16Q3
43G28	DIVERTER(75)	G16Q3
32F24	FUSE(75 50)	G16Q3
85A66	GAS VALVE(75 50)	G16Q3
13G05	GASKET - TRANSITION(75 50)	G16Q3
60579	HOLDER-FUSE(75 50)	G16Q3
38G26	LEAD(75 50)	G16Q3
88A12	LEAD(75 50)	G16Q3
54J41	LEAD-IGNITION(75 50)	G16Q3
67F14	MOTOR-BLOWER(50)	G16Q3
79A52	MOTOR-BLOWER(75 50)	G16Q3
32904	MOTOR-BLOWER(75)	G16Q3
67F15	MOTOR-BLOWER(75)	G16Q3
86851	MOUNT-MOTOR(75)	G16Q3
78A25	ORIFICE(75)	G16Q3
60334	ORIFICE-BURNER(75 50)	G16Q3
LB-13437DA	ORIFICE-BURNER(75 50)	G16Q3
12F22	ORIFICE-PILOT(75 50)	G16Q3
37648	RELAY(75 50)	G16Q3
59510	RELAY(75 50)	G16Q3
67750	RELAY(75 50)	G16Q3
48G95	RELAY(75 50)	G16Q3
66C67	RELAY(75 50)	G16Q3
89F95	ROD(75 50)	G16Q3
12F19	SENSOR-FLAME(75 50)	G16Q3
18G89	SENSOR-FLAME(75 50)	G16Q3
85980	SHUTTER-AIR(75 50)	G16Q3
28G23	SPRING(75 50)	G16Q3
73F19	SPRING(75 50)	G16Q3
26H92	SWITCH(75 50)	G16Q3
41C42	SWITCH-INTERLOCK(75 50)	G16Q3
41C59	SWITCH-INTERLOCK(75 50)	G16Q3
51F10	SWITCH-PRESS(50)	G16Q3
28G00	SWITCH-PRESS(75 50)	G16Q3
51F11	SWITCH-PRESS(75 50)	G16Q3
93G19	SWITCH-PRESS(75 50)	G16Q3
78F37	SWITCH-PRESS(75)	G16Q3
38631	TRANSFORMER(75 50)	G16Q3
12B57	VALVE-GAS(75 50)	G16Q3
17G28	VALVE-GAS(75 50)	G16Q3
18G88	VALVE-GAS(75 50)	G16Q3
31193	VALVE-SHUTOFF(75 50)	G16Q3
P-5-172	WHEEL-BLOWER(50)	G16Q3
P-5-226	WHEEL-BLOWER(75 50)	G16Q3
21708	WHEEL-BLOWER(75)	G16Q3

## G16Q3/4

51G78	BLOWER-INDUCED DRAFT(100)	G16Q3/4
99G96	BLOWER-INDUCED DRAFT(100)	G16Q3/4
18G90	BURNER - PILOT(100)	G16Q3/4
50F60	BURNER - PILOT(100)	G16Q3/4
34G62	BURNER-MAIN(100)	G16Q3/4
35H93	BURNER-MAIN(100)	G16Q3/4
81F94	BURNER-MAIN(100)	G16Q3/4
82F60	BURNER-MAIN(100)	G16Q3/4
61478	BURNER-PILOT(100)	G16Q3/4
59C93	CAPACITOR-BLR MTR(100)	G16Q3/4
78F08	CONTROL-F&L(100)	G16Q3/4
17G31	CONTROL-IGN(100)	G16Q3/4
18G91	CONTROL-IGN(100)	G16Q3/4
50G06	DIVERTER(100)	G16Q3/4
54J41	LEAD-IGNITION(100)	G16Q3/4
61589	MANIFOLD-GAS(100)	G16Q3/4
67F15	MOTOR-BLOWER(100)	G16Q3/4
60334	ORIFICE-BURNER(100)	G16Q3/4
LB-13	ORIFICE-BURNER(100)	G16Q3/4
59510	RELAY(100)	G16Q3/4
48G95	RELAY(100)	G16Q3/4
66C67	RELAY(100)	G16Q3/4
89F95	ROD(100)	G16Q3/4
12F19	SENSOR-FLAME(100)	G16Q3/4
18G89	SENSOR-FLAME(100)	G16Q3/4
85980	SHUTTER-AIR(100)	G16Q3/4
28G23	SPRING(100)	G16Q3/4
73F19	SPRING(100)	G16Q3/4
26H92	SWITCH(100)	G16Q3/4
41C42	SWITCH-INTERLOCK(100)	G16Q3/4
41C59	SWITCH-INTERLOCK(100)	G16Q3/4
28G00	SWITCH-PRESS(100)	G16Q3/4
93G19	SWITCH-PRESS(100)	G16Q3/4
38631	TRANSFORMER(100)	G16Q3/4
17G28	VALVE-GAS(100)	G16Q3/4
18G88	VALVE-GAS(100)	G16Q3/4
21708	WHEEL-BLOWER(100)	G16Q3/4

## G16Q3/4H

70G23	BLOWER - EXHAUST(100)	G16Q3/4H
70G24	BLOWER - EXHAUST(100)	G16Q3/4H
12H68	BURNER - MAIN(100)	G16Q3/4H
18G90	BURNER - PILOT(100)	G16Q3/4H
50F60	BURNER - PILOT(100)	G16Q3/4H
12H69	BURNER-MAIN(100)	G16Q3/4H
53H32	CAPACITOR-FAN MTR(100)	G16Q3/4H
88F17	CAP-CABINET(100)	G16Q3/4H
40H35	CLAMP - FILTER(100)	G16Q3/4H

70G15	CONTROL - RESET(100)	G16Q3/4H
46G45	CONTROL (-50 ONLY)(100)	G16Q3/4H
70G16	CONTROL(100)	G16Q3/4H
91E64	CONTROL-F&L(100)	G16Q3/4H
18G91	CONTROL-IGN(100)	G16Q3/4H
TC-30	COVER - CONTROL BOX(100)	G16Q3/4H
TC-30	DOOR - BLOWER(100)	G16Q3/4H
88F16	DOOR - LOUVRE(100)	G16Q3/4H
67171	FUSE(100)	G16Q3/4H
32F24	FUSE(100)	G16Q3/4H
85A66	GAS VALVE(100)	G16Q3/4H
LB-17566	MEDIA - FILTER(100)	G16Q3/4H
59A69	MEDIA-FILTER(100)	G16Q3/4H
26G42	MOTOR - EXHAUST(100)	G16Q3/4H
51F07	MOTOR - EXHAUST(100)	G16Q3/4H
67F15	MOTOR-BLOWER(100)	G16Q3/4H
83G11	ORIFICE(100)	G16Q3/4H
83G13	ORIFICE(100)	G16Q3/4H
LB-13	ORIFICE-BURNER(100)	G16Q3/4H
37648	RELAY(100)	G16Q3/4H
59510	RELAY(100)	G16Q3/4H
67750	RELAY(100)	G16Q3/4H
66C67	RELAY(100)	G16Q3/4H
12F19	SENSOR-FLAME(100)	G16Q3/4H
18G89	SENSOR-FLAME(100)	G16Q3/4H
24G75	SEQUENCER(100)	G16Q3/4H
41C42	SWITCH-INTERLOCK(100)	G16Q3/4H
46H51	SWITCH-PRESS(100)	G16Q3/4H
46H52	SWITCH-PRESS(100)	G16Q3/4H
46H53	SWITCH-PRESS(100)	G16Q3/4H
38631	TRANSFORMER(100)	G16Q3/4H
18G88	VALVE-GAS(100)	G16Q3/4H
32A73	WHEEL-BLOWER(100)	G16Q3/4H

### **G16Q3/4X**

51G78	BLOWER-INDUCED DRAFT(100)	G16Q3/4X
99G96	BLOWER-INDUCED DRAFT(100)	G16Q3/4X
18G90	BURNER - PILOT(100)	G16Q3/4X
50F60	BURNER - PILOT(100)	G16Q3/4X
34G62	BURNER-MAIN(100)	G16Q3/4X
35H93	BURNER-MAIN(100)	G16Q3/4X
81F94	BURNER-MAIN(100)	G16Q3/4X
82F60	BURNER-MAIN(100)	G16Q3/4X
61478	BURNER-PILOT(100)	G16Q3/4X
86012	BUSHING-SNAP(100)	G16Q3/4X
59C93	CAPACITOR-BLR MTR(100)	G16Q3/4X
78F08	CONTROL-F&L(100)	G16Q3/4X
17G31	CONTROL-IGN(100)	G16Q3/4X
18G91	CONTROL-IGN(100)	G16Q3/4X
50G06	DIVERTER(100)	G16Q3/4X

67F15	MOTOR-BLOWER(100)	G16Q3/4X
60334	ORIFICE-BURNER(100)	G16Q3/4X
LB-13437DA	ORIFICE-BURNER(100)	G16Q3/4X
59510	RELAY(100)	G16Q3/4X
48G95	RELAY(100)	G16Q3/4X
66C67	RELAY(100)	G16Q3/4X
89F95	ROD(100)	G16Q3/4X
12F19	SENSOR-FLAME(100)	G16Q3/4X
18G89	SENSOR-FLAME(100)	G16Q3/4X
85980	SHUTTER-AIR(100)	G16Q3/4X
28G23	SPRING(100)	G16Q3/4X
73F19	SPRING(100)	G16Q3/4X
26H92	SWITCH(100)	G16Q3/4X
41C42	SWITCH-INTERLOCK(100)	G16Q3/4X
41C59	SWITCH-INTERLOCK(100)	G16Q3/4X
28G00	SWITCH-PRESS(100)	G16Q3/4X
93G19	SWITCH-PRESS(100)	G16Q3/4X
38631	TRANSFORMER(100)	G16Q3/4X
17G28	VALVE-GAS(100)	G16Q3/4X
18G88	VALVE-GAS(100)	G16Q3/4X
21708	WHEEL-BLOWER(100)	G16Q3/4X

### G16Q3H

70G24	BLOWER - EXHAUST(75 50)	G16Q3H
70G23	BLOWER - EXHAUST(75)	G16Q3H
21C52	BOOT-CAPACITOR(75 50)	G16Q3H
12H68	BURNER - MAIN(75 50)	G16Q3H
18G90	BURNER - PILOT(75 50)	G16Q3H
50F60	BURNER - PILOT(75 50)	G16Q3H
12H69	BURNER-MAIN(75 50)	G16Q3H
70G15	CONTROL - RESET(75 50)	G16Q3H
46G43	CONTROL(50)	G16Q3H
70G16	CONTROL(75 50)	G16Q3H
91E64	CONTROL-F&L(75 50)	G16Q3H
13H65	CONTROL-F&L(75)	G16Q3H
18G91	CONTROL-IGN(75 50)	G16Q3H
67171	FUSE(75 50)	G16Q3H
32F24	FUSE(75 50)	G16Q3H
85A66	GAS VALVE(75 50)	G16Q3H
59A69	MEDIA-FILTER(75 50)	G16Q3H
26G42	MOTOR - EXHAUST(75 50)	G16Q3H
51F07	MOTOR - EXHAUST(75 50)	G16Q3H
67F14	MOTOR-BLOWER(75 50)	G16Q3H
89C36	MOTOR-BLOWER(75 50)	G16Q3H
83G11	ORIFICE(75)	G16Q3H
LB-13437DA	ORIFICE-BURNER(75 50)	G16Q3H
59510	RELAY(75 50)	G16Q3H
48G96	RELAY(75 50)	G16Q3H
66C67	RELAY(75 50)	G16Q3H
12F19	SENSOR-FLAME(75 50)	G16Q3H

18G89	SENSOR-FLAME(75 50)	G16Q3H
24G75	SEQUENCER(75 50)	G16Q3H
41C42	SWITCH-INTERLOCK(75 50)	G16Q3H
46H51	SWITCH-PRESS(75 50)	G16Q3H
46H52	SWITCH-PRESS(75 50)	G16Q3H
46H53	SWITCH-PRESS(75 50)	G16Q3H
38631	TRANSFORMER(75 50)	G16Q3H
18G88	VALVE-GAS(75 50)	G16Q3H
P-5-172	WHEEL-BLOWER(75 50)	G16Q3H
P-5-226	WHEEL-BLOWER(75 50)	G16Q3H

### **G16Q3X**

47H12	BLOWER-INDUCED DRAFT(75 50)	G16Q3X
51G78	BLOWER-INDUCED DRAFT(75 50)	G16Q3X
99G96	BLOWER-INDUCED DRAFT(75 50)	G16Q3X
18G90	BURNER - PILOT(75 50)	G16Q3X
50F60	BURNER - PILOT(75 50)	G16Q3X
34G61	BURNER-MAIN(75 50)	G16Q3X
34G62	BURNER-MAIN(75 50)	G16Q3X
81F94	BURNER-MAIN(75 50)	G16Q3X
82F60	BURNER-MAIN(75 50)	G16Q3X
61478	BURNER-PILOT(75 50)	G16Q3X
43G82	BURNER-PILOT(75 50)	G16Q3X
86012	BUSHING-SNAP(75 50)	G16Q3X
59C92	CAPACITOR-BLR MTR(75 50)	G16Q3X
59C93	CAPACITOR-BLR MTR(75)	G16Q3X
81A38	CAPACITOR-FAN MTR(50)	G16Q3X
13B85	CONTROL-F&L(50)	G16Q3X
78F11	CONTROL-F&L(50)	G16Q3X
70C83	CONTROL-F&L(75 50)	G16Q3X
70F89	CONTROL-F&L(75 50)	G16Q3X
78F07	CONTROL-F&L(75 50)	G16Q3X
78F08	CONTROL-F&L(75 50)	G16Q3X
17G31	CONTROL-IGN(75 50)	G16Q3X
18G91	CONTROL-IGN(75 50)	G16Q3X
20H77	CONTROL-IGN(75 50)	G16Q3X
11G80	DIVERTER(75 50)	G16Q3X
56G53	DIVERTER(75 50)	G16Q3X
43G28	DIVERTER(75)	G16Q3X
32F24	FUSE(75 50)	G16Q3X
85A66	GAS VALVE(75 50)	G16Q3X
38G26	LEAD(75 50)	G16Q3X
88A12	LEAD(75 50)	G16Q3X
54J41	LEAD-IGNITION(75 50)	G16Q3X
56C52	MANIFOLD-GAS(50)	G16Q3X
39C23	MANIFOLD-GAS(75)	G16Q3X
67F14	MOTOR-BLOWER(50)	G16Q3X
79A52	MOTOR-BLOWER(75 50)	G16Q3X
32904	MOTOR-BLOWER(75)	G16Q3X
67F15	MOTOR-BLOWER(75)	G16Q3X



86851	MOUNT-MOTOR(75)	G16Q3X
78A25	ORIFICE(75)	G16Q3X
60334	ORIFICE-BURNER(75 50)	G16Q3X
LB-13437DA	ORIFICE-BURNER(75 50)	G16Q3X
12F22	ORIFICE-PILOT(75 50)	G16Q3X
37648	RELAY(75 50)	G16Q3X
59510	RELAY(75 50)	G16Q3X
67750	RELAY(75 50)	G16Q3X
48G95	RELAY(75 50)	G16Q3X
66C67	RELAY(75 50)	G16Q3X
89F95	ROD(75 50)	G16Q3X
12F19	SENSOR-FLAME(75 50)	G16Q3X
18G89	SENSOR-FLAME(75 50)	G16Q3X
85980	SHUTTER-AIR(75 50)	G16Q3X
28G23	SPRING(75 50)	G16Q3X
73F19	SPRING(75 50)	G16Q3X
26H92	SWITCH(75 50)	G16Q3X
41C42	SWITCH-INTERLOCK(75 50)	G16Q3X
41C59	SWITCH-INTERLOCK(75 50)	G16Q3X
51F10	SWITCH-PRESS(50)	G16Q3X
28G00	SWITCH-PRESS(75 50)	G16Q3X
51F11	SWITCH-PRESS(75 50)	G16Q3X
93G19	SWITCH-PRESS(75 50)	G16Q3X
78F37	SWITCH-PRESS(75)	G16Q3X
38631	TRANSFORMER(75 50)	G16Q3X
12B57	VALVE-GAS(75 50)	G16Q3X
17G28	VALVE-GAS(75 50)	G16Q3X
18G88	VALVE-GAS(75 50)	G16Q3X
31193	VALVE-SHUTOFF(75 50)	G16Q3X
P-5-172	WHEEL-BLOWER(50)	G16Q3X
P-5-226	WHEEL-BLOWER(75 50)	G16Q3X
21708	WHEEL-BLOWER(75)	G16Q3X

### G16Q4

47H12	BLOWER-INDUCED DRAFT(75 100)	G16Q4
51G78	BLOWER-INDUCED DRAFT(75 100)	G16Q4
99G96	BLOWER-INDUCED DRAFT(75 100)	G16Q4
18G90	BURNER - PILOT(75 100)	G16Q4
50F60	BURNER - PILOT(75 100)	G16Q4
34G61	BURNER-MAIN(75 100)	G16Q4
34G62	BURNER-MAIN(75 100)	G16Q4
81F94	BURNER-MAIN(75 100)	G16Q4
82F60	BURNER-MAIN(75 100)	G16Q4
61478	BURNER-PILOT(75 100)	G16Q4
43G82	BURNER-PILOT(75 100)	G16Q4
86012	BUSHING-SNAP(75 100)	G16Q4
81A39	CAPACITOR(100)	G16Q4
96C48	CAPACITOR(100)	G16Q4
59C92	CAPACITOR-BLR MTR(75)	G16Q4
59C93	CAPACITOR-BLR MTR(75)	G16Q4

13B85	CONTROL-F&L(100)	G16Q4
70F90	CONTROL-F&L(100)	G16Q4
78F06	CONTROL-F&L(100)	G16Q4
78F08	CONTROL-F&L(75 100)	G16Q4
70C83	CONTROL-F&L(75)	G16Q4
70F89	CONTROL-F&L(75)	G16Q4
78F07	CONTROL-F&L(75)	G16Q4
17G31	CONTROL-IGN(75 100)	G16Q4
18G91	CONTROL-IGN(75 100)	G16Q4
20H77	CONTROL-IGN(75 100)	G16Q4
30G95	DIVERTER(100)	G16Q4
50G06	DIVERTER(100)	G16Q4
11G80	DIVERTER(75)	G16Q4
43G28	DIVERTER(75)	G16Q4
56G53	DIVERTER(75)	G16Q4
32F24	FUSE(75 100)	G16Q4
85A66	GAS VALVE(75 100)	G16Q4
60579	HOLDER-FUSE(75 100)	G16Q4
38G26	LEAD(75 100)	G16Q4
88A12	LEAD(75)	G16Q4
54J41	LEAD-IGNITION(75 100)	G16Q4
28F01	MOTOR-BLOWER(100)	G16Q4
67F15	MOTOR-BLOWER(75 100)	G16Q4
32904	MOTOR-BLOWER(75)	G16Q4
79A52	MOTOR-BLOWER(75)	G16Q4
78A25	ORIFICE(75)	G16Q4
60334	ORIFICE-BURNER(75 100)	G16Q4
LB-13437DA	ORIFICE-BURNER(75 100)	G16Q4
12F22	ORIFICE-PILOT(75 100)	G16Q4
37648	RELAY(75 100)	G16Q4
59510	RELAY(75 100)	G16Q4
67750	RELAY(75 100)	G16Q4
48G95	RELAY(75 100)	G16Q4
66C67	RELAY(75 100)	G16Q4
89F95	ROD(75 100)	G16Q4
12F19	SENSOR-FLAME(75 100)	G16Q4
18G89	SENSOR-FLAME(75 100)	G16Q4
85980	SHUTTER-AIR(75 100)	G16Q4
28G23	SPRING(75 100)	G16Q4
73F19	SPRING(75 100)	G16Q4
87129	SUPPORT(75)	G16Q4
57C24	SUPPORT-CABLE(75 100)	G16Q4
26H92	SWITCH(75)	G16Q4
41C42	SWITCH-INTERLOCK(75 100)	G16Q4
41C59	SWITCH-INTERLOCK(75 100)	G16Q4
28G91	SWITCH-PRESS(100)	G16Q4
28G00	SWITCH-PRESS(75 100)	G16Q4
51F11	SWITCH-PRESS(75 100)	G16Q4
93G19	SWITCH-PRESS(75 100)	G16Q4
78F37	SWITCH-PRESS(75)	G16Q4
38631	TRANSFORMER(75 100)	G16Q4

12B57	VALVE-GAS(75 100)	G16Q4
17G28	VALVE-GAS(75 100)	G16Q4
18G88	VALVE-GAS(75 100)	G16Q4
87A62	WHEEL-BLOWER(100)	G16Q4
21708	WHEEL-BLOWER(75 100)	G16Q4
P-5-226	WHEEL-BLOWER(75)	G16Q4

### **G16Q4/5**

51G78	BLOWER-INDUCED DRAFT(125)	G16Q4/5
18G90	BURNER - PILOT(125)	G16Q4/5
50F60	BURNER - PILOT(125)	G16Q4/5
34G61	BURNER-MAIN(125)	G16Q4/5
35H93	BURNER-MAIN(125)	G16Q4/5
81F94	BURNER-MAIN(125)	G16Q4/5
82F60	BURNER-MAIN(125)	G16Q4/5
61478	BURNER-PILOT(125)	G16Q4/5
86012	BUSHING-SNAP(125)	G16Q4/5
96C48	CAPACITOR(125)	G16Q4/5
78F08	CONTROL-F&L(125)	G16Q4/5
17G31	CONTROL-IGN(125)	G16Q4/5
18G91	CONTROL-IGN(125)	G16Q4/5
50G06	DIVERTER(125)	G16Q4/5
88F16	DOOR - LOUVRE(125)	G16Q4/5
24G62	GASKET - FLUE(125)	G16Q4/5
46G01	GASKET(125)	G16Q4/5
46G04	GASKET(125)	G16Q4/5
54J41	LEAD-IGNITION(125)	G16Q4/5
61590	MANIFOLD-GAS(125)	G16Q4/5
28F01	MOTOR-BLOWER(125)	G16Q4/5
LB-47831D	MOUNT-MOTOR(125)	G16Q4/5
60334	ORIFICE-BURNER(125)	G16Q4/5
LB-13437DA	ORIFICE-BURNER(125)	G16Q4/5
59510	RELAY(125)	G16Q4/5
66C67	RELAY(125)	G16Q4/5
89F95	ROD(125)	G16Q4/5
12F19	SENSOR-FLAME(125)	G16Q4/5
18G89	SENSOR-FLAME(125)	G16Q4/5
85980	SHUTTER-AIR(125)	G16Q4/5
26H92	SWITCH(125)	G16Q4/5
41C42	SWITCH-INTERLOCK(125)	G16Q4/5
41C59	SWITCH-INTERLOCK(125)	G16Q4/5
28G00	SWITCH-PRESS(125)	G16Q4/5
38631	TRANSFORMER(125)	G16Q4/5
17G28	VALVE-GAS(125)	G16Q4/5
18G88	VALVE-GAS(125)	G16Q4/5
P-5-223	WHEEL - BLOWER(125)	G16Q4/5

### **G16Q4/5H**

21C52	BOOT-CAPACITOR(125)	G16Q4/5H
-------	---------------------	----------

18G90	BURNER - PILOT(125)	G16Q4/5H
12H69	BURNER-MAIN(125)	G16Q4/5H
90G76	BURNER-MAIN(125)	G16Q4/5H
53H01	CAPACITOR(125)	G16Q4/5H
40H35	CLAMP - FILTER(125)	G16Q4/5H
70G15	CONTROL - RESET(125)	G16Q4/5H
70G16	CONTROL(125)	G16Q4/5H
91E64	CONTROL-F&L(125)	G16Q4/5H
18G91	CONTROL-IGN(125)	G16Q4/5H
26G42	MOTOR - EXHAUST(125)	G16Q4/5H
28F01	MOTOR-BLOWER(125)	G16Q4/5H
60328	ORIFICE-BURNER(125)	G16Q4/5H
LB-13437DA	ORIFICE-BURNER(125)	G16Q4/5H
59510	RELAY(125)	G16Q4/5H
66C67	RELAY(125)	G16Q4/5H
18G89	SENSOR-FLAME(125)	G16Q4/5H
41C42	SWITCH-INTERLOCK(125)	G16Q4/5H
46H51	SWITCH-PRESS(125)	G16Q4/5H
38631	TRANSFORMER(125)	G16Q4/5H
18G88	VALVE-GAS(125)	G16Q4/5H
P-5-223	WHEEL - BLOWER(125)	G16Q4/5H

### **G16Q4/5X**

51G78	BLOWER-INDUCED DRAFT(125)	G16Q4/5X
18G90	BURNER - PILOT(125)	G16Q4/5X
50F60	BURNER - PILOT(125)	G16Q4/5X
34G61	BURNER-MAIN(125)	G16Q4/5X
35H93	BURNER-MAIN(125)	G16Q4/5X
81F94	BURNER-MAIN(125)	G16Q4/5X
82F60	BURNER-MAIN(125)	G16Q4/5X
61478	BURNER-PILOT(125)	G16Q4/5X
86012	BUSHING-SNAP(125)	G16Q4/5X
96C48	CAPACITOR(125)	G16Q4/5X
78F08	CONTROL-F&L(125)	G16Q4/5X
17G31	CONTROL-IGN(125)	G16Q4/5X
18G91	CONTROL-IGN(125)	G16Q4/5X
50G06	DIVERTER(125)	G16Q4/5X
54J41	LEAD-IGNITION(125)	G16Q4/5X
61590	MANIFOLD-GAS(125)	G16Q4/5X
28F01	MOTOR-BLOWER(125)	G16Q4/5X
LB-47831D	MOUNT-MOTOR(125)	G16Q4/5X
60334	ORIFICE-BURNER(125)	G16Q4/5X
LB-13437DA	ORIFICE-BURNER(125)	G16Q4/5X
59510	RELAY(125)	G16Q4/5X
66C67	RELAY(125)	G16Q4/5X
89F95	ROD(125)	G16Q4/5X
12F19	SENSOR-FLAME(125)	G16Q4/5X
18G89	SENSOR-FLAME(125)	G16Q4/5X
26H92	SWITCH(125)	G16Q4/5X
41C42	SWITCH-INTERLOCK(125)	G16Q4/5X

41C59	SWITCH-INTERLOCK(125)	G16Q4/5X
28G00	SWITCH-PRESS(125)	G16Q4/5X
38G31	TRANSFORMER(125)	G16Q4/5X
17G28	VALVE-GAS(125)	G16Q4/5X
18G88	VALVE-GAS(125)	G16Q4/5X
P-5-223	WHEEL - BLOWER(125)	G16Q4/5X

### G16Q4X

47H12	BLOWER-INDUCED DRAFT(75 100)	G16Q4X
51G78	BLOWER-INDUCED DRAFT(75 100)	G16Q4X
99G96	BLOWER-INDUCED DRAFT(75 100)	G16Q4X
18G90	BURNER - PILOT(75 100)	G16Q4X
50F60	BURNER - PILOT(75 100)	G16Q4X
34G61	BURNER-MAIN(75 100)	G16Q4X
34G62	BURNER-MAIN(75 100)	G16Q4X
81F94	BURNER-MAIN(75 100)	G16Q4X
82F60	BURNER-MAIN(75 100)	G16Q4X
61478	BURNER-PILOT(75 100)	G16Q4X
43G82	BURNER-PILOT(75 100)	G16Q4X
81A39	CAPACITOR(100)	G16Q4X
96C48	CAPACITOR(100)	G16Q4X
59C92	CAPACITOR-BLR MTR(75)	G16Q4X
59C93	CAPACITOR-BLR MTR(75)	G16Q4X
13B85	CONTROL-F&L(100)	G16Q4X
70F90	CONTROL-F&L(100)	G16Q4X
78F06	CONTROL-F&L(100)	G16Q4X
78F08	CONTROL-F&L(75 100)	G16Q4X
70C83	CONTROL-F&L(75)	G16Q4X
70F89	CONTROL-F&L(75)	G16Q4X
78F07	CONTROL-F&L(75)	G16Q4X
17G31	CONTROL-IGN(75 100)	G16Q4X
18G91	CONTROL-IGN(75 100)	G16Q4X
20H77	CONTROL-IGN(75 100)	G16Q4X
30G95	DIVERTER(100)	G16Q4X
50G06	DIVERTER(100)	G16Q4X
11G80	DIVERTER(75)	G16Q4X
43G28	DIVERTER(75)	G16Q4X
56G53	DIVERTER(75)	G16Q4X
32F24	FUSE(75 100)	G16Q4X
85A66	GAS VALVE(75 100)	G16Q4X
38G26	LEAD(75 100)	G16Q4X
88A12	LEAD(75)	G16Q4X
54J41	LEAD-IGNITION(75 100)	G16Q4X
28F01	MOTOR-BLOWER(100)	G16Q4X
67F15	MOTOR-BLOWER(75 100)	G16Q4X
32904	MOTOR-BLOWER(75)	G16Q4X
79A52	MOTOR-BLOWER(75)	G16Q4X
78A25	ORIFICE(75)	G16Q4X
60334	ORIFICE-BURNER(75 100)	G16Q4X

LB-13437DA	ORIFICE-BURNER(75 100)	G16Q4X
12F22	ORIFICE-PILOT(75 100)	G16Q4X
37648	RELAY(75 100)	G16Q4X
59510	RELAY(75 100)	G16Q4X
67750	RELAY(75 100)	G16Q4X
48G95	RELAY(75 100)	G16Q4X
66C67	RELAY(75 100)	G16Q4X
89F95	ROD(75 100)	G16Q4X
12F19	SENSOR-FLAME(75 100)	G16Q4X
18G89	SENSOR-FLAME(75 100)	G16Q4X
85980	SHUTTER-AIR(75 100)	G16Q4X
28G23	SPRING(75 100)	G16Q4X
73F19	SPRING(75 100)	G16Q4X
87129	SUPPORT(75)	G16Q4X
57C24	SUPPORT-CABLE(75 100)	G16Q4X
26H92	SWITCH(75)	G16Q4X
41C42	SWITCH-INTERLOCK(75 100)	G16Q4X
41C59	SWITCH-INTERLOCK(75 100)	G16Q4X
28G91	SWITCH-PRESS(100)	G16Q4X
28G00	SWITCH-PRESS(75 100)	G16Q4X
51F11	SWITCH-PRESS(75 100)	G16Q4X
93G19	SWITCH-PRESS(75 100)	G16Q4X
78F37	SWITCH-PRESS(75)	G16Q4X
38631	TRANSFORMER(75 100)	G16Q4X
12B57	VALVE-GAS(75 100)	G16Q4X
17G28	VALVE-GAS(75 100)	G16Q4X
18G88	VALVE-GAS(75 100)	G16Q4X
87A62	WHEEL-BLOWER(100)	G16Q4X
21708	WHEEL-BLOWER(75 100)	G16Q4X
P-5-226	WHEEL-BLOWER(75)	G16Q4X

### G16Q5

47H12	BLOWER-INDUCED DRAFT(100)	G16Q5
51G78	BLOWER-INDUCED DRAFT(100)	G16Q5
99G96	BLOWER-INDUCED DRAFT(100)	G16Q5
18G90	BURNER - PILOT(100)	G16Q5
50F60	BURNER - PILOT(100)	G16Q5
34G61	BURNER-MAIN(100)	G16Q5
34G62	BURNER-MAIN(100)	G16Q5
81F94	BURNER-MAIN(100)	G16Q5
82F60	BURNER-MAIN(100)	G16Q5
61478	BURNER-PILOT(100)	G16Q5
43G82	BURNER-PILOT(100)	G16Q5
81A39	CAPACITOR(100)	G16Q5
96C48	CAPACITOR(100)	G16Q5
13B85	CONTROL-F&L(100)	G16Q5
70F90	CONTROL-F&L(100)	G16Q5
78F06	CONTROL-F&L(100)	G16Q5
78F08	CONTROL-F&L(100)	G16Q5
17G31	CONTROL-IGN(100)	G16Q5

18G91	CONTROL-IGN(100)	G16Q5
20H77	CONTROL-IGN(100)	G16Q5
30G95	DIVERTER(100)	G16Q5
50G06	DIVERTER(100)	G16Q5
32F24	FUSE(100)	G16Q5
85A66	GAS VALVE(100)	G16Q5
38G26	LEAD(100)	G16Q5
54J41	LEAD-IGNITION(100)	G16Q5
28F01	MOTOR-BLOWER(100)	G16Q5
67F15	MOTOR-BLOWER(100)	G16Q5
60334	ORIFICE-BURNER(100)	G16Q5
LB-13	ORIFICE-BURNER(100)	G16Q5
12F22	ORIFICE-PILOT(100)	G16Q5
37648	RELAY(100)	G16Q5
59510	RELAY(100)	G16Q5
67750	RELAY(100)	G16Q5
48G95	RELAY(100)	G16Q5
66C67	RELAY(100)	G16Q5
89F95	ROD(100)	G16Q5
12F19	SENSOR-FLAME(100)	G16Q5
18G89	SENSOR-FLAME(100)	G16Q5
85980	SHUTTER-AIR(100)	G16Q5
28G23	SPRING(100)	G16Q5
73F19	SPRING(100)	G16Q5
41C42	SWITCH-INTERLOCK(100)	G16Q5
41C59	SWITCH-INTERLOCK(100)	G16Q5
28G00	SWITCH-PRESS(100)	G16Q5
28G91	SWITCH-PRESS(100)	G16Q5
51F11	SWITCH-PRESS(100)	G16Q5
93G19	SWITCH-PRESS(100)	G16Q5
38631	TRANSFORMER(100)	G16Q5
12B57	VALVE-GAS(100)	G16Q5
17G28	VALVE-GAS(100)	G16Q5
18G88	VALVE-GAS(100)	G16Q5
21708	WHEEL-BLOWER(100)	G16Q5
87A62	WHEEL-BLOWER(100)	G16Q5

### **G16Q5X**

47H12	BLOWER-INDUCED DRAFT(100)	G16Q5X
51G78	BLOWER-INDUCED DRAFT(100)	G16Q5X
99G96	BLOWER-INDUCED DRAFT(100)	G16Q5X
18G90	BURNER - PILOT(100)	G16Q5X
50F60	BURNER - PILOT(100)	G16Q5X
34G61	BURNER-MAIN(100)	G16Q5X
34G62	BURNER-MAIN(100)	G16Q5X
81F94	BURNER-MAIN(100)	G16Q5X
82F60	BURNER-MAIN(100)	G16Q5X
61478	BURNER-PILOT(100)	G16Q5X
43G82	BURNER-PILOT(100)	G16Q5X
86012	BUSHING-SNAP(100)	G16Q5X

81A39	CAPACITOR(100)	G16Q5X
96C48	CAPACITOR(100)	G16Q5X
13B85	CONTROL-F&L(100)	G16Q5X
70F90	CONTROL-F&L(100)	G16Q5X
78F06	CONTROL-F&L(100)	G16Q5X
78F08	CONTROL-F&L(100)	G16Q5X
17G31	CONTROL-IGN(100)	G16Q5X
18G91	CONTROL-IGN(100)	G16Q5X
20H77	CONTROL-IGN(100)	G16Q5X
30G95	DIVERTER(100)	G16Q5X
50G06	DIVERTER(100)	G16Q5X
32F24	FUSE(100)	G16Q5X
85A66	GAS VALVE(100)	G16Q5X
60579	HOLDER-FUSE(100)	G16Q5X
21838	HOUSING-BLOWER(100)	G16Q5X
LB-17609C	HOUSING-BLOWER(100)	G16Q5X
38G26	LEAD(100)	G16Q5X
54J41	LEAD-IGNITION(100)	G16Q5X
28F01	MOTOR-BLOWER(100)	G16Q5X
67F15	MOTOR-BLOWER(100)	G16Q5X
60334	ORIFICE-BURNER(100)	G16Q5X
LB-13437DA	ORIFICE-BURNER(100)	G16Q5X
12F22	ORIFICE-PILOT(100)	G16Q5X
37648	RELAY(100)	G16Q5X
59510	RELAY(100)	G16Q5X
67750	RELAY(100)	G16Q5X
48G95	RELAY(100)	G16Q5X
66C67	RELAY(100)	G16Q5X
89F95	ROD(100)	G16Q5X
12F19	SENSOR-FLAME(100)	G16Q5X
18G89	SENSOR-FLAME(100)	G16Q5X
85980	SHUTTER-AIR(100)	G16Q5X
28G23	SPRING(100)	G16Q5X
73F19	SPRING(100)	G16Q5X
41C42	SWITCH-INTERLOCK(100)	G16Q5X
41C59	SWITCH-INTERLOCK(100)	G16Q5X
28G00	SWITCH-PRESS(100)	G16Q5X
28G91	SWITCH-PRESS(100)	G16Q5X
51F11	SWITCH-PRESS(100)	G16Q5X
93G19	SWITCH-PRESS(100)	G16Q5X
38631	TRANSFORMER(100)	G16Q5X
12B57	VALVE-GAS(100)	G16Q5X
17G28	VALVE-GAS(100)	G16Q5X
18G88	VALVE-GAS(100)	G16Q5X
21708	WHEEL-BLOWER(100)	G16Q5X
87A62	WHEEL-BLOWER(100)	G16Q5X

### G16R

47H12	BLOWER-INDUCED DRAFT(75 50 100)	G16R
51G78	BLOWER-INDUCED DRAFT(75 50 100)	G16R



99G96	BLOWER-INDUCED DRAFT(75 50 100)	G16R
18G90	BURNER - PILOT(75 50 100)	G16R
50F60	BURNER - PILOT(75 50 100)	G16R
34G61	BURNER-MAIN(75 50 100)	G16R
34G62	BURNER-MAIN(75 50 100)	G16R
81F94	BURNER-MAIN(75 50 100)	G16R
82F60	BURNER-MAIN(75 50 100)	G16R
61478	BURNER-PILOT(75 50 100)	G16R
43G82	BURNER-PILOT(75 50 100)	G16R
39H89	CAPACITOR(100)	G16R
59C93	CAPACITOR-BLR MTR(100)	G16R
59C92	CAPACITOR-BLR MTR(75 50)	G16R
35C00	CONTROL-F&L(100)	G16R
78F07	CONTROL-F&L(100)	G16R
13B85	CONTROL-F&L(50)	G16R
78F08	CONTROL-F&L(50)	G16R
77C88	CONTROL-F&L(75)	G16R
84F15	CONTROL-F&L(75)	G16R
17G31	CONTROL-IGN(75 50 100)	G16R
18G91	CONTROL-IGN(75 50 100)	G16R
20H77	CONTROL-IGN(75 50 100)	G16R
43G54	CONTROL-LIMIT(100)	G16R
48G07	CONTROL-LIMIT(50)	G16R
87F16	CONTROL-LIMIT(75 50 100)	G16R
30G95	DIVERTER(100)	G16R
50G06	DIVERTER(100)	G16R
11G80	DIVERTER(75 50)	G16R
56G53	DIVERTER(75 50)	G16R
87F74	FILTER-AIR(100)	G16R
82F97	FILTER-AIR(75 50)	G16R
32F24	FUSE(75 50 100)	G16R
36G00	FUSE(75 50 100)	G16R
85A66	GAS VALVE(75 50 100)	G16R
60579	HOLDER-FUSE(75 50 100)	G16R
54J41	LEAD-IGNITION(75 50 100)	G16R
67F15	MOTOR-BLOWER(100)	G16R
79A52	MOTOR-BLOWER(75 50)	G16R
60334	ORIFICE-BURNER(75 50 100)	G16R
LB-13	ORIFICE-BURNER(75 50 100)	G16R
12F22	ORIFICE-PILOT(75 50 100)	G16R
59510	RELAY(75 50 100)	G16R
67750	RELAY(75 50 100)	G16R
48G95	RELAY(75 50 100)	G16R
66C67	RELAY(75 50 100)	G16R
89F95	ROD(75 50 100)	G16R
12F19	SENSOR-FLAME(75 50 100)	G16R
18G89	SENSOR-FLAME(75 50 100)	G16R
85980	SHUTTER-AIR(75 50 100)	G16R
26H92	SWITCH(75 50 100)	G16R
41C42	SWITCH-INTERLOCK(75 50 100)	G16R
41C59	SWITCH-INTERLOCK(75 50)	G16R

51F11	SWITCH-PRESS(100)	G16R
51F10	SWITCH-PRESS(50)	G16R
28G00	SWITCH-PRESS(75 50 100)	G16R
43H01	SWITCH-PRESS(75 50 100)	G16R
79I58	SWITCH-PRESS(75 50 100)	G16R
78F37	SWITCH-PRESS(75)	G16R
38631	TRANSFORMER(75 50 100)	G16R
12B57	VALVE-GAS(75 50 100)	G16R
17G28	VALVE-GAS(75 50 100)	G16R
18G88	VALVE-GAS(75 50 100)	G16R
82F76	WHEEL-BLOWER(100)	G16R
P-5-226	WHEEL-BLOWER(50)	G16R
21708	WHEEL-BLOWER(75)	G16R

### **G16RQ3**

47H12	BLOWER-INDUCED DRAFT(75 50)	G16RQ3
51G78	BLOWER-INDUCED DRAFT(75 50)	G16RQ3
99G96	BLOWER-INDUCED DRAFT(75 50)	G16RQ3
18G90	BURNER - PILOT(75 50)	G16RQ3
50F60	BURNER - PILOT(75 50)	G16RQ3
34G61	BURNER-MAIN(75 50)	G16RQ3
34G62	BURNER-MAIN(75 50)	G16RQ3
81F94	BURNER-MAIN(75 50)	G16RQ3
82F60	BURNER-MAIN(75 50)	G16RQ3
61478	BURNER-PILOT(75 50)	G16RQ3
43G82	BURNER-PILOT(75 50)	G16RQ3
59C92	CAPACITOR-BLR MTR(75 50)	G16RQ3
13B85	CONTROL-F&L(50)	G16RQ3
78F08	CONTROL-F&L(50)	G16RQ3
77C88	CONTROL-F&L(75)	G16RQ3
84F15	CONTROL-F&L(75)	G16RQ3
17G31	CONTROL-IGN(75 50)	G16RQ3
18G91	CONTROL-IGN(75 50)	G16RQ3
20H77	CONTROL-IGN(75 50)	G16RQ3
48G07	CONTROL-LIMIT(50)	G16RQ3
87F16	CONTROL-LIMIT(75 50)	G16RQ3
11G80	DIVERTER(75 50)	G16RQ3
56G53	DIVERTER(75 50)	G16RQ3
82F97	FILTER-AIR(75 50)	G16RQ3
32F24	FUSE(75 50)	G16RQ3
36G00	FUSE(75 50)	G16RQ3
85A66	GAS VALVE(75 50)	G16RQ3
54J41	LEAD-IGNITION(75 50)	G16RQ3
79A52	MOTOR-BLOWER(75 50)	G16RQ3
60334	ORIFICE-BURNER(75 50)	G16RQ3
LB-13437DA	ORIFICE-BURNER(75 50)	G16RQ3
12F22	ORIFICE-PILOT(75 50)	G16RQ3
68G16	RAIL-FILTER(75 50)	G16RQ3
59510	RELAY(75 50)	G16RQ3
67750	RELAY(75 50)	G16RQ3

48G95	RELAY(75 50)	G16RQ3
66C67	RELAY(75 50)	G16RQ3
89F95	ROD(75 50)	G16RQ3
12F19	SENSOR-FLAME(75 50)	G16RQ3
18G89	SENSOR-FLAME(75 50)	G16RQ3
85980	SHUTTER-AIR(75 50)	G16RQ3
28G23	SPRING(75 50)	G16RQ3
73F19	SPRING(75 50)	G16RQ3
26H92	SWITCH(75 50)	G16RQ3
41C42	SWITCH-INTERLOCK(75 50)	G16RQ3
41C59	SWITCH-INTERLOCK(75 50)	G16RQ3
51F10	SWITCH-PRESS(50)	G16RQ3
28G00	SWITCH-PRESS(75 50)	G16RQ3
43H01	SWITCH-PRESS(75 50)	G16RQ3
79I58	SWITCH-PRESS(75 50)	G16RQ3
78F37	SWITCH-PRESS(75)	G16RQ3
38631	TRANSFORMER(75 50)	G16RQ3
12B57	VALVE-GAS(75 50)	G16RQ3
17G28	VALVE-GAS(75 50)	G16RQ3
18G88	VALVE-GAS(75 50)	G16RQ3
P-5-226	WHEEL-BLOWER(50)	G16RQ3
21708	WHEEL-BLOWER(75)	G16RQ3

### **G16RQ3X**

47H12	BLOWER-INDUCED DRAFT(75 50)	G16RQ3X
51G78	BLOWER-INDUCED DRAFT(75 50)	G16RQ3X
99G96	BLOWER-INDUCED DRAFT(75 50)	G16RQ3X
18G90	BURNER - PILOT(75 50)	G16RQ3X
50F60	BURNER - PILOT(75 50)	G16RQ3X
34G61	BURNER-MAIN(75 50)	G16RQ3X
34G62	BURNER-MAIN(75 50)	G16RQ3X
81F94	BURNER-MAIN(75 50)	G16RQ3X
82F60	BURNER-MAIN(75 50)	G16RQ3X
61478	BURNER-PILOT(75 50)	G16RQ3X
43G82	BURNER-PILOT(75 50)	G16RQ3X
59C92	CAPACITOR-BLR MTR(75 50)	G16RQ3X
13B85	CONTROL-F&L(50)	G16RQ3X
78F08	CONTROL-F&L(50)	G16RQ3X
77C88	CONTROL-F&L(75)	G16RQ3X
84F15	CONTROL-F&L(75)	G16RQ3X
17G31	CONTROL-IGN(75 50)	G16RQ3X
18G91	CONTROL-IGN(75 50)	G16RQ3X
20H77	CONTROL-IGN(75 50)	G16RQ3X
48G07	CONTROL-LIMIT(50)	G16RQ3X
87F16	CONTROL-LIMIT(75 50)	G16RQ3X
11G80	DIVERTER(75 50)	G16RQ3X
56G53	DIVERTER(75 50)	G16RQ3X
82F97	FILTER-AIR(75 50)	G16RQ3X
32F24	FUSE(75 50)	G16RQ3X
36G00	FUSE(75 50)	G16RQ3X

85A66	GAS VALVE(75 50)	G16RQ3X
54J41	LEAD-IGNITION(75 50)	G16RQ3X
56C52	MANIFOLD-GAS(50)	G16RQ3X
39C23	MANIFOLD-GAS(75)	G16RQ3X
79A52	MOTOR-BLOWER(75 50)	G16RQ3X
60334	ORIFICE-BURNER(75 50)	G16RQ3X
LB-13437DA	ORIFICE-BURNER(75 50)	G16RQ3X
12F22	ORIFICE-PILOT(75 50)	G16RQ3X
59510	RELAY(75 50)	G16RQ3X
67750	RELAY(75 50)	G16RQ3X
48G95	RELAY(75 50)	G16RQ3X
66C67	RELAY(75 50)	G16RQ3X
89F95	ROD(75 50)	G16RQ3X
12F19	SENSOR-FLAME(75 50)	G16RQ3X
18G89	SENSOR-FLAME(75 50)	G16RQ3X
85980	SHUTTER-AIR(75 50)	G16RQ3X
28G23	SPRING(75 50)	G16RQ3X
73F19	SPRING(75 50)	G16RQ3X
26H92	SWITCH(75 50)	G16RQ3X
41C42	SWITCH-INTERLOCK(75 50)	G16RQ3X
41C59	SWITCH-INTERLOCK(75 50)	G16RQ3X
51F10	SWITCH-PRESS(50)	G16RQ3X
28G00	SWITCH-PRESS(75 50)	G16RQ3X
43H01	SWITCH-PRESS(75 50)	G16RQ3X
79I58	SWITCH-PRESS(75 50)	G16RQ3X
78F37	SWITCH-PRESS(75)	G16RQ3X
38631	TRANSFORMER(75 50)	G16RQ3X
12B57	VALVE-GAS(75 50)	G16RQ3X
17G28	VALVE-GAS(75 50)	G16RQ3X
18G88	VALVE-GAS(75 50)	G16RQ3X
P-5-226	WHEEL-BLOWER(50)	G16RQ3X
21708	WHEEL-BLOWER(75)	G16RQ3X

### **G16RQ4**

47H12	BLOWER-INDUCED DRAFT(100)	G16RQ4
51G78	BLOWER-INDUCED DRAFT(100)	G16RQ4
99G96	BLOWER-INDUCED DRAFT(100)	G16RQ4
18G90	BURNER - PILOT(100)	G16RQ4
50F60	BURNER - PILOT(100)	G16RQ4
34G61	BURNER-MAIN(100)	G16RQ4
34G62	BURNER-MAIN(100)	G16RQ4
81F94	BURNER-MAIN(100)	G16RQ4
82F60	BURNER-MAIN(100)	G16RQ4
61478	BURNER-PILOT(100)	G16RQ4
43G82	BURNER-PILOT(100)	G16RQ4
86012	BUSHING-SNAP(100)	G16RQ4
39H89	CAPACITOR(100)	G16RQ4
59C93	CAPACITOR-BLR MTR(100)	G16RQ4
35C00	CONTROL-F&L(100)	G16RQ4
78F07	CONTROL-F&L(100)	G16RQ4

17G31	CONTROL-IGN(100)	G16RQ4
18G91	CONTROL-IGN(100)	G16RQ4
20H77	CONTROL-IGN(100)	G16RQ4
43G54	CONTROL-LIMIT(100)	G16RQ4
87F16	CONTROL-LIMIT(100)	G16RQ4
30G95	DIVERTER(100)	G16RQ4
50G06	DIVERTER(100)	G16RQ4
87F74	FILTER-AIR(100)	G16RQ4
32F24	FUSE(100)	G16RQ4
36G00	FUSE(100)	G16RQ4
85A66	GAS VALVE(100)	G16RQ4
60579	HOLDER-FUSE(100)	G16RQ4
38G35	HOUSING-BLOWER(100)	G16RQ4
54J41	LEAD-IGNITION(100)	G16RQ4
67F15	MOTOR-BLOWER(100)	G16RQ4
60334	ORIFICE-BURNER(100)	G16RQ4
LB-13	ORIFICE-BURNER(100)	G16RQ4
12F22	ORIFICE-PILOT(100)	G16RQ4
59510	RELAY(100)	G16RQ4
67750	RELAY(100)	G16RQ4
48G95	RELAY(100)	G16RQ4
66C67	RELAY(100)	G16RQ4
89F95	ROD(100)	G16RQ4
12F19	SENSOR-FLAME(100)	G16RQ4
18G89	SENSOR-FLAME(100)	G16RQ4
85980	SHUTTER-AIR(100)	G16RQ4
28G23	SPRING(100)	G16RQ4
73F19	SPRING(100)	G16RQ4
26H92	SWITCH(100)	G16RQ4
41C42	SWITCH-INTERLOCK(100)	G16RQ4
28G00	SWITCH-PRESS(100)	G16RQ4
43H01	SWITCH-PRESS(100)	G16RQ4
51F11	SWITCH-PRESS(100)	G16RQ4
79I58	SWITCH-PRESS(100)	G16RQ4
38631	TRANSFORMER(100)	G16RQ4
12B57	VALVE-GAS(100)	G16RQ4
17G28	VALVE-GAS(100)	G16RQ4
18G88	VALVE-GAS(100)	G16RQ4
82F76	WHEEL-BLOWER(100)	G16RQ4

### **G16RQ4/5**

LB-55074AE	BLOWER-INDUCED DRAFT(125)	G16RQ4/5
18G90	BURNER - PILOT(125)	G16RQ4/5
50F60	BURNER - PILOT(125)	G16RQ4/5
34G61	BURNER-MAIN(125)	G16RQ4/5
34G62	BURNER-MAIN(125)	G16RQ4/5
81F94	BURNER-MAIN(125)	G16RQ4/5
82F60	BURNER-MAIN(125)	G16RQ4/5
61478	BURNER-PILOT(125)	G16RQ4/5
96C48	CAPACITOR(125)	G16RQ4/5

78F05	CONTROL-F&L(125)	G16RQ4/5
17G31	CONTROL-IGN(125)	G16RQ4/5
18G91	CONTROL-IGN(125)	G16RQ4/5
10G52	CONTROL-LIMIT(125)	G16RQ4/5
11G55	CONTROL-LIMIT(125)	G16RQ4/5
33G72	CONTROL-LIMIT(125)	G16RQ4/5
43G54	CONTROL-LIMIT(125)	G16RQ4/5
50G06	DIVERTER(125)	G16RQ4/5
30334	FILTER-AIR(125)	G16RQ4/5
36G00	FUSE(125)	G16RQ4/5
60579	HOLDER-FUSE(125)	G16RQ4/5
54J41	LEAD-IGNITION(125)	G16RQ4/5
28F01	MOTOR-BLOWER(125)	G16RQ4/5
60334	ORIFICE-BURNER(125)	G16RQ4/5
LB-13437DA	ORIFICE-BURNER(125)	G16RQ4/5
59510	RELAY(125)	G16RQ4/5
66C67	RELAY(125)	G16RQ4/5
89F95	ROD(125)	G16RQ4/5
12F19	SENSOR-FLAME(125)	G16RQ4/5
18G89	SENSOR-FLAME(125)	G16RQ4/5
85980	SHUTTER-AIR(125)	G16RQ4/5
26H92	SWITCH(125)	G16RQ4/5
41C42	SWITCH-INTERLOCK(125)	G16RQ4/5
28G00	SWITCH-PRESS(125)	G16RQ4/5
43H01	SWITCH-PRESS(125)	G16RQ4/5
38631	TRANSFORMER(125)	G16RQ4/5
17G28	VALVE-GAS(125)	G16RQ4/5
18G88	VALVE-GAS(125)	G16RQ4/5
87A62	WHEEL-BLOWER(125)	G16RQ4/5

### **G16RQ4/5X**

LB-55	BLOWER-INDUCED DRAFT(125)	G16RQ4/5X
18G90	BURNER - PILOT(125)	G16RQ4/5X
50F60	BURNER - PILOT(125)	G16RQ4/5X
34G61	BURNER-MAIN(125)	G16RQ4/5X
34G62	BURNER-MAIN(125)	G16RQ4/5X
81F94	BURNER-MAIN(125)	G16RQ4/5X
82F60	BURNER-MAIN(125)	G16RQ4/5X
61478	BURNER-PILOT(125)	G16RQ4/5X
96C48	CAPACITOR(125)	G16RQ4/5X
78F05	CONTROL-F&L(125)	G16RQ4/5X
17G31	CONTROL-IGN(125)	G16RQ4/5X
18G91	CONTROL-IGN(125)	G16RQ4/5X
10G52	CONTROL-LIMIT(125)	G16RQ4/5X
11G55	CONTROL-LIMIT(125)	G16RQ4/5X
33G72	CONTROL-LIMIT(125)	G16RQ4/5X
43G54	CONTROL-LIMIT(125)	G16RQ4/5X
50G06	DIVERTER(125)	G16RQ4/5X
30334	FILTER-AIR(125)	G16RQ4/5X
36G00	FUSE(125)	G16RQ4/5X

60579	HOLDER-FUSE(125)	G16RQ4/5X
21841	HOUSING-BLOWER(125)	G16RQ4/5X
54J41	LEAD-IGNITION(125)	G16RQ4/5X
28F01	MOTOR-BLOWER(125)	G16RQ4/5X
60334	ORIFICE-BURNER(125)	G16RQ4/5X
LB-13437DA	ORIFICE-BURNER(125)	G16RQ4/5X
59510	RELAY(125)	G16RQ4/5X
66C67	RELAY(125)	G16RQ4/5X
89F95	ROD(125)	G16RQ4/5X
12F19	SENSOR-FLAME(125)	G16RQ4/5X
18G89	SENSOR-FLAME(125)	G16RQ4/5X
85980	SHUTTER-AIR(125)	G16RQ4/5X
26H92	SWITCH(125)	G16RQ4/5X
41C42	SWITCH-INTERLOCK(125)	G16RQ4/5X
28G00	SWITCH-PRESS(125)	G16RQ4/5X
43H01	SWITCH-PRESS(125)	G16RQ4/5X
38631	TRANSFORMER(125)	G16RQ4/5X
17G28	VALVE-GAS(125)	G16RQ4/5X
18G88	VALVE-GAS(125)	G16RQ4/5X
87A62	WHEEL-BLOWER(125)	G16RQ4/5X

### **G16RQ4X**

47H12	BLOWER-INDUCED DRAFT(100)	G16RQ4X
51G78	BLOWER-INDUCED DRAFT(100)	G16RQ4X
99G96	BLOWER-INDUCED DRAFT(100)	G16RQ4X
18G90	BURNER - PILOT(100)	G16RQ4X
50F60	BURNER - PILOT(100)	G16RQ4X
34G61	BURNER-MAIN(100)	G16RQ4X
34G62	BURNER-MAIN(100)	G16RQ4X
81F94	BURNER-MAIN(100)	G16RQ4X
82F60	BURNER-MAIN(100)	G16RQ4X
61478	BURNER-PILOT(100)	G16RQ4X
43G82	BURNER-PILOT(100)	G16RQ4X
39H89	CAPACITOR(100)	G16RQ4X
59C93	CAPACITOR-BLR MTR(100)	G16RQ4X
35C00	CONTROL-F&L(100)	G16RQ4X
78F07	CONTROL-F&L(100)	G16RQ4X
17G31	CONTROL-IGN(100)	G16RQ4X
18G91	CONTROL-IGN(100)	G16RQ4X
20H77	CONTROL-IGN(100)	G16RQ4X
43G54	CONTROL-LIMIT(100)	G16RQ4X
87F16	CONTROL-LIMIT(100)	G16RQ4X
30G95	DIVERTER(100)	G16RQ4X
50G06	DIVERTER(100)	G16RQ4X
87F74	FILTER-AIR(100)	G16RQ4X
32F24	FUSE(100)	G16RQ4X
36G00	FUSE(100)	G16RQ4X
85A66	GAS VALVE(100)	G16RQ4X
60579	HOLDER-FUSE(100)	G16RQ4X
54J41	LEAD-IGNITION(100)	G16RQ4X

61589	MANIFOLD-GAS(100)	G16RQ4X
67F15	MOTOR-BLOWER(100)	G16RQ4X
60334	ORIFICE-BURNER(100)	G16RQ4X
LB-13	ORIFICE-BURNER(100)	G16RQ4X
12F22	ORIFICE-PILOT(100)	G16RQ4X
59510	RELAY(100)	G16RQ4X
67750	RELAY(100)	G16RQ4X
48G95	RELAY(100)	G16RQ4X
66C67	RELAY(100)	G16RQ4X
89F95	ROD(100)	G16RQ4X
12F19	SENSOR-FLAME(100)	G16RQ4X
18G89	SENSOR-FLAME(100)	G16RQ4X
85980	SHUTTER-AIR(100)	G16RQ4X
28G23	SPRING(100)	G16RQ4X
73F19	SPRING(100)	G16RQ4X
26H92	SWITCH(100)	G16RQ4X
41C42	SWITCH-INTERLOCK(100)	G16RQ4X
28G00	SWITCH-PRESS(100)	G16RQ4X
43H01	SWITCH-PRESS(100)	G16RQ4X
51F11	SWITCH-PRESS(100)	G16RQ4X
79I58	SWITCH-PRESS(100)	G16RQ4X
38631	TRANSFORMER(100)	G16RQ4X
12B57	VALVE-GAS(100)	G16RQ4X
17G28	VALVE-GAS(100)	G16RQ4X
18G88	VALVE-GAS(100)	G16RQ4X
31193	VALVE-SHUTOFF(100)	G16RQ4X
82F76	WHEEL-BLOWER(100)	G16RQ4X

### **G16RX**

47H12	BLOWER-INDUCED DRAFT(75 50 100)	G16RX
51G78	BLOWER-INDUCED DRAFT(75 50 100)	G16RX
99G96	BLOWER-INDUCED DRAFT(75 50 100)	G16RX
18G90	BURNER - PILOT(75 50 100)	G16RX
50F60	BURNER - PILOT(75 50 100)	G16RX
34G61	BURNER-MAIN(75 50 100)	G16RX
34G62	BURNER-MAIN(75 50 100)	G16RX
81F94	BURNER-MAIN(75 50 100)	G16RX
82F60	BURNER-MAIN(75 50 100)	G16RX
61478	BURNER-PILOT(75 50 100)	G16RX
43G82	BURNER-PILOT(75 50 100)	G16RX
86012	BUSHING-SNAP(75 50 100)	G16RX
39H89	CAPACITOR(100)	G16RX
59C93	CAPACITOR-BLR MTR(100)	G16RX
59C92	CAPACITOR-BLR MTR(75 50)	G16RX
35C00	CONTROL-F&L(100)	G16RX
78F07	CONTROL-F&L(100)	G16RX
13B85	CONTROL-F&L(50)	G16RX
78F08	CONTROL-F&L(50)	G16RX
77C88	CONTROL-F&L(75)	G16RX
84F15	CONTROL-F&L(75)	G16RX



17G31	CONTROL-IGN(75 50 100)	G16RX
18G91	CONTROL-IGN(75 50 100)	G16RX
20H77	CONTROL-IGN(75 50 100)	G16RX
43G54	CONTROL-LIMIT(100)	G16RX
48G07	CONTROL-LIMIT(50)	G16RX
87F16	CONTROL-LIMIT(75 50 100)	G16RX
30G95	DIVERTER(100)	G16RX
50G06	DIVERTER(100)	G16RX
11G80	DIVERTER(75 50)	G16RX
56G53	DIVERTER(75 50)	G16RX
87F74	FILTER-AIR(100)	G16RX
82F97	FILTER-AIR(75 50)	G16RX
32F24	FUSE(75 50 100)	G16RX
36G00	FUSE(75 50 100)	G16RX
85A66	GAS VALVE(75 50 100)	G16RX
60579	HOLDER-FUSE(75 50 100)	G16RX
54J41	LEAD-IGNITION(75 50 100)	G16RX
67F15	MOTOR-BLOWER(100)	G16RX
79A52	MOTOR-BLOWER(75 50)	G16RX
60334	ORIFICE-BURNER(75 50 100)	G16RX
LB-13437DA	ORIFICE-BURNER(75 50 100)	G16RX
12F22	ORIFICE-PILOT(75 50 100)	G16RX
59510	RELAY(75 50 100)	G16RX
67750	RELAY(75 50 100)	G16RX
48G95	RELAY(75 50 100)	G16RX
66C67	RELAY(75 50 100)	G16RX
89F95	ROD(75 50 100)	G16RX
12F19	SENSOR-FLAME(75 50 100)	G16RX
18G89	SENSOR-FLAME(75 50 100)	G16RX
85980	SHUTTER-AIR(75 50 100)	G16RX
28G23	SPRING(75 50 100)	G16RX
73F19	SPRING(75 50 100)	G16RX
26H92	SWITCH(75 50 100)	G16RX
41C42	SWITCH-INTERLOCK(75 50 100)	G16RX
41C59	SWITCH-INTERLOCK(75 50)	G16RX
51F11	SWITCH-PRESS(100)	G16RX
51F10	SWITCH-PRESS(50)	G16RX
28G00	SWITCH-PRESS(75 50 100)	G16RX
43H01	SWITCH-PRESS(75 50 100)	G16RX
79I58	SWITCH-PRESS(75 50 100)	G16RX
78F37	SWITCH-PRESS(75)	G16RX
38631	TRANSFORMER(75 50 100)	G16RX
12B57	VALVE-GAS(75 50 100)	G16RX
17G28	VALVE-GAS(75 50 100)	G16RX
18G88	VALVE-GAS(75 50 100)	G16RX
82F76	WHEEL-BLOWER(100)	G16RX
P-5-226	WHEEL-BLOWER(50)	G16RX
21708	WHEEL-BLOWER(75)	G16RX

**G16X**

47H12	BLOWER-INDUCED DRAFT(75 50 100)	G16X
51G78	BLOWER-INDUCED DRAFT(75 50 100)	G16X
99G96	BLOWER-INDUCED DRAFT(75 50 100)	G16X
18G90	BURNER - PILOT(75 50 100)	G16X
50F60	BURNER - PILOT(75 50 100)	G16X
35H93	BURNER-MAIN(100)	G16X
34G61	BURNER-MAIN(75 50 100)	G16X
34G62	BURNER-MAIN(75 50 100)	G16X
81F94	BURNER-MAIN(75 50 100)	G16X
82F60	BURNER-MAIN(75 50 100)	G16X
61478	BURNER-PILOT(75 50 100)	G16X
43G82	BURNER-PILOT(75 50 100)	G16X
86012	BUSHING-SNAP(75 50 100)	G16X
81A39	CAPACITOR(100)	G16X
96C48	CAPACITOR(100)	G16X
59C93	CAPACITOR-BLR MTR(75 100)	G16X
59C92	CAPACITOR-BLR MTR(75 50)	G16X
81A38	CAPACITOR-FAN MTR(50)	G16X
70F90	CONTROL-F&L(100)	G16X
78F06	CONTROL-F&L(100)	G16X
13B85	CONTROL-F&L(50 100)	G16X
78F11	CONTROL-F&L(50)	G16X
78F08	CONTROL-F&L(75 50 100)	G16X
70C83	CONTROL-F&L(75 50)	G16X
70F89	CONTROL-F&L(75 50)	G16X
78F07	CONTROL-F&L(75 50)	G16X
17G31	CONTROL-IGN(75 50 100)	G16X
18G91	CONTROL-IGN(75 50 100)	G16X
20H77	CONTROL-IGN(75 50 100)	G16X
30G95	DIVERTER(100)	G16X
50G06	DIVERTER(100)	G16X
11G80	DIVERTER(75 50)	G16X
56G53	DIVERTER(75 50)	G16X
43G28	DIVERTER(75)	G16X
32F24	FUSE(75 50 100)	G16X
85A66	GAS VALVE(75 50 100)	G16X
60579	HOLDER-FUSE(75 50 100)	G16X
38G26	LEAD(75 50 100)	G16X
88A12	LEAD(75 50)	G16X
54J41	LEAD-IGNITION(75 50 100)	G16X
28F01	MOTOR-BLOWER(100)	G16X
67F14	MOTOR-BLOWER(50)	G16X
67F15	MOTOR-BLOWER(75 100)	G16X
79A52	MOTOR-BLOWER(75 50)	G16X
32904	MOTOR-BLOWER(75)	G16X
78A25	ORIFICE(75)	G16X
60334	ORIFICE-BURNER(75 50 100)	G16X
LB-13437DA	ORIFICE-BURNER(75 50 100)	G16X
12F22	ORIFICE-PILOT(75 50 100)	G16X
37648	RELAY(75 50 100)	G16X
59510	RELAY(75 50 100)	G16X

67750	RELAY(75 50 100)	G16X
48G95	RELAY(75 50 100)	G16X
66C67	RELAY(75 50 100)	G16X
89F95	ROD(75 50 100)	G16X
12F19	SENSOR-FLAME(75 50 100)	G16X
18G89	SENSOR-FLAME(75 50 100)	G16X
85980	SHUTTER-AIR(75 50 100)	G16X
28G23	SPRING(75 50 100)	G16X
73F19	SPRING(75 50 100)	G16X
41C42	SWITCH-INTERLOCK(75 50 100)	G16X
41C59	SWITCH-INTERLOCK(75 50 100)	G16X
28G91	SWITCH-PRESS(100)	G16X
51F10	SWITCH-PRESS(50)	G16X
28G00	SWITCH-PRESS(75 50 100)	G16X
51F11	SWITCH-PRESS(75 50 100)	G16X
93G19	SWITCH-PRESS(75 50 100)	G16X
78F37	SWITCH-PRESS(75)	G16X
38631	TRANSFORMER(75 50 100)	G16X
12B57	VALVE-GAS(75 50 100)	G16X
17G28	VALVE-GAS(75 50 100)	G16X
18G88	VALVE-GAS(75 50 100)	G16X
31193	VALVE-SHUTOFF(75 50 100)	G16X
87A62	WHEEL-BLOWER(100)	G16X
P-5-172	WHEEL-BLOWER(50)	G16X
21708	WHEEL-BLOWER(75 100)	G16X
P-5-226	WHEEL-BLOWER(75 50)	G16X

## **G17Q2**

LB-63	BLADE-DAMPER(50)	G17Q2
68H08	BOARD-CIRCUIT(50)	G17Q2
18G90	BURNER - PILOT(50)	G17Q2
34G61	BURNER-MAIN(50)	G17Q2
34G62	BURNER-MAIN(50)	G17Q2
81F94	BURNER-MAIN(50)	G17Q2
82F60	BURNER-MAIN(50)	G17Q2
61478	BURNER-PILOT(50)	G17Q2
86795	BUSHING-SNAP(50)	G17Q2
59C92	CAPACITOR-BLR MTR(50)	G17Q2
18G91	CONTROL-IGN(50)	G17Q2
97H04	CONTROL-IGN(50)	G17Q2
10G52	CONTROL-LIMIT(50)	G17Q2
LB-63098G	DIVERTER(50)	G17Q2
26H84	FILTER(50)	G17Q2
45H30	MOTOR-BLOWER(50)	G17Q2
97H57	MOTOR-BLOWER(50)	G17Q2
51H74	MOTOR-DAMPER(50)	G17Q2
94H80	ORIFICE-BURNER(50)	G17Q2
LB-13437DA	ORIFICE-BURNER(50)	G17Q2
89F95	ROD(50)	G17Q2
18G89	SENSOR-FLAME(50)	G17Q2

85980	SHUTTER-AIR(50)	G17Q2
26H73	SPRING(50)	G17Q2
73F19	SPRING(50)	G17Q2
97H76	SPRING(50)	G17Q2
26H61	SWITCH(50)	G17Q2
26H78	SWITCH(50)	G17Q2
28G13	SWITCH(50)	G17Q2
71G17	SWITCH(50)	G17Q2
38631	TRANSFORMER(50)	G17Q2
78H55	TRANSFORMER(50)	G17Q2
18G88	VALVE-GAS(50)	G17Q2
51H30	VALVE-GAS(50)	G17Q2
97H05	VALVE-GAS(50)	G17Q2
32624	WHEEL-BLOWER(50)	G17Q2

### G17Q2X

LB-63086A	BLADE-DAMPER(50)	G17Q2X
68H08	BOARD-CIRCUIT(50)	G17Q2X
18G90	BURNER - PILOT(50)	G17Q2X
34G61	BURNER-MAIN(50)	G17Q2X
34G62	BURNER-MAIN(50)	G17Q2X
81F94	BURNER-MAIN(50)	G17Q2X
82F60	BURNER-MAIN(50)	G17Q2X
61478	BURNER-PILOT(50)	G17Q2X
59C92	CAPACITOR-BLR MTR(50)	G17Q2X
18G91	CONTROL-IGN(50)	G17Q2X
97H04	CONTROL-IGN(50)	G17Q2X
10G52	CONTROL-LIMIT(50)	G17Q2X
LB-63098G	DIVERTER(50)	G17Q2X
26H84	FILTER(50)	G17Q2X
45H30	MOTOR-BLOWER(50)	G17Q2X
97H57	MOTOR-BLOWER(50)	G17Q2X
51H74	MOTOR-DAMPER(50)	G17Q2X
94H80	ORIFICE-BURNER(50)	G17Q2X
LB-13437DA	ORIFICE-BURNER(50)	G17Q2X
89F95	ROD(50)	G17Q2X
44H32	SEAL(50)	G17Q2X
91H39	SEAL(50)	G17Q2X
18G89	SENSOR-FLAME(50)	G17Q2X
85980	SHUTTER-AIR(50)	G17Q2X
26H73	SPRING(50)	G17Q2X
73F19	SPRING(50)	G17Q2X
97H76	SPRING(50)	G17Q2X
26H61	SWITCH(50)	G17Q2X
26H78	SWITCH(50)	G17Q2X
28G13	SWITCH(50)	G17Q2X
71G17	SWITCH(50)	G17Q2X
38631	TRANSFORMER(50)	G17Q2X
78H55	TRANSFORMER(50)	G17Q2X
18G88	VALVE-GAS(50)	G17Q2X

51H30	VALVE-GAS(50)	G17Q2X
97H05	VALVE-GAS(50)	G17Q2X
32624	WHEEL-BLOWER(50)	G17Q2X

### G17Q3

LB-63	BLADE-DAMPER(75)	G17Q3
68H08	BOARD-CIRCUIT(75)	G17Q3
18G90	BURNER - PILOT(75)	G17Q3
34G61	BURNER-MAIN(75)	G17Q3
34G62	BURNER-MAIN(75)	G17Q3
81F94	BURNER-MAIN(75)	G17Q3
82F60	BURNER-MAIN(75)	G17Q3
61478	BURNER-PILOT(75)	G17Q3
39H89	CAPACITOR(75)	G17Q3
59C92	CAPACITOR-BLR MTR(75)	G17Q3
18G91	CONTROL-IGN(75)	G17Q3
97H04	CONTROL-IGN(75)	G17Q3
26H66	CONTROL-LIMIT(75)	G17Q3
37H73	CONTROL-LIMIT(75)	G17Q3
52H33	DIVERTER(75)	G17Q3
26H84	FILTER(75)	G17Q3
45H31	MOTOR-BLOWER(75)	G17Q3
45H32	MOTOR-BLOWER(75)	G17Q3
51H74	MOTOR-DAMPER(75)	G17Q3
94H80	ORIFICE-BURNER(75)	G17Q3
LB-13437DA	ORIFICE-BURNER(75)	G17Q3
89F95	ROD(75)	G17Q3
18G89	SENSOR-FLAME(75)	G17Q3
85980	SHUTTER-AIR(75)	G17Q3
26H61	SWITCH(75)	G17Q3
26H78	SWITCH(75)	G17Q3
28G13	SWITCH(75)	G17Q3
71G17	SWITCH(75)	G17Q3
38631	TRANSFORMER(75)	G17Q3
78H55	TRANSFORMER(75)	G17Q3
18G88	VALVE-GAS(75)	G17Q3
51H30	VALVE-GAS(75)	G17Q3
97H05	VALVE-GAS(75)	G17Q3
21708	WHEEL-BLOWER(75)	G17Q3
21709	WHEEL-BLOWER(75)	G17Q3

### G17Q3/4

LB-63086B	BLADE-DAMPER(100)	G17Q3/4
68H08	BOARD-CIRCUIT(100)	G17Q3/4
42G11	BRACKET(100)	G17Q3/4
63H43	BRACKET(100)	G17Q3/4
18G90	BURNER - PILOT(100)	G17Q3/4
34G61	BURNER-MAIN(100)	G17Q3/4
34G62	BURNER-MAIN(100)	G17Q3/4

81F94	BURNER-MAIN(100)	G17Q3/4
82F60	BURNER-MAIN(100)	G17Q3/4
61478	BURNER-PILOT(100)	G17Q3/4
39H58	CAPACITOR(100)	G17Q3/4
39H89	CAPACITOR(100)	G17Q3/4
18G91	CONTROL-IGN(100)	G17Q3/4
97H04	CONTROL-IGN(100)	G17Q3/4
26H65	CONTROL-LIMIT(100)	G17Q3/4
37H72	CONTROL-LIMIT(100)	G17Q3/4
52H34	DIVERTER(100)	G17Q3/4
26H84	FILTER(100)	G17Q3/4
26H83	FILTER-AIR(100)	G17Q3/4
78H69	FILTER-AIR(100)	G17Q3/4
45H32	MOTOR-BLOWER(100)	G17Q3/4
45H33	MOTOR-BLOWER(100)	G17Q3/4
51H74	MOTOR-DAMPER(100)	G17Q3/4
94H80	ORIFICE-BURNER(100)	G17Q3/4
LB-13	ORIFICE-BURNER(100)	G17Q3/4
89F95	ROD(100)	G17Q3/4
91H39	SEAL(100)	G17Q3/4
96H94	SEAL(100)	G17Q3/4
18G89	SENSOR-FLAME(100)	G17Q3/4
85980	SHUTTER-AIR(100)	G17Q3/4
26H73	SPRING(100)	G17Q3/4
73F19	SPRING(100)	G17Q3/4
97H76	SPRING(100)	G17Q3/4
26H61	SWITCH(100)	G17Q3/4
28G13	SWITCH(100)	G17Q3/4
71G17	SWITCH(100)	G17Q3/4
38631	TRANSFORMER(100)	G17Q3/4
78H55	TRANSFORMER(100)	G17Q3/4
18G88	VALVE-GAS(100)	G17Q3/4
51H30	VALVE-GAS(100)	G17Q3/4
97H05	VALVE-GAS(100)	G17Q3/4
21708	WHEEL-BLOWER(100)	G17Q3/4
87A62	WHEEL-BLOWER(100)	G17Q3/4

### **G17Q3/4X**

LB-63086B	BLADE-DAMPER(100)	G17Q3/4X
68H08	BOARD-CIRCUIT(100)	G17Q3/4X
18G90	BURNER - PILOT(100)	G17Q3/4X
34G61	BURNER-MAIN(100)	G17Q3/4X
34G62	BURNER-MAIN(100)	G17Q3/4X
81F94	BURNER-MAIN(100)	G17Q3/4X
82F60	BURNER-MAIN(100)	G17Q3/4X
61478	BURNER-PILOT(100)	G17Q3/4X
39H58	CAPACITOR(100)	G17Q3/4X
39H89	CAPACITOR(100)	G17Q3/4X
18G91	CONTROL-IGN(100)	G17Q3/4X
97H04	CONTROL-IGN(100)	G17Q3/4X

26H65	CONTROL-LIMIT(100)	G17Q3/4X
37H72	CONTROL-LIMIT(100)	G17Q3/4X
39H23	COUPLING(100)	G17Q3/4X
39H24	COUPLING(100)	G17Q3/4X
52H34	DIVERTER(100)	G17Q3/4X
26H84	FILTER(100)	G17Q3/4X
26H83	FILTER-AIR(100)	G17Q3/4X
78H69	FILTER-AIR(100)	G17Q3/4X
45H32	MOTOR-BLOWER(100)	G17Q3/4X
45H33	MOTOR-BLOWER(100)	G17Q3/4X
51H74	MOTOR-DAMPER(100)	G17Q3/4X
78A18	MOUNT-MOTOR(100)	G17Q3/4X
94H80	ORIFICE-BURNER(100)	G17Q3/4X
LB-13	ORIFICE-BURNER(100)	G17Q3/4X
89F95	ROD(100)	G17Q3/4X
91H39	SEAL(100)	G17Q3/4X
96H94	SEAL(100)	G17Q3/4X
18G89	SENSOR-FLAME(100)	G17Q3/4X
85980	SHUTTER-AIR(100)	G17Q3/4X
26H73	SPRING(100)	G17Q3/4X
73F19	SPRING(100)	G17Q3/4X
97H76	SPRING(100)	G17Q3/4X
26H61	SWITCH(100)	G17Q3/4X
28G13	SWITCH(100)	G17Q3/4X
71G17	SWITCH(100)	G17Q3/4X
38631	TRANSFORMER(100)	G17Q3/4X
78H55	TRANSFORMER(100)	G17Q3/4X
18G88	VALVE-GAS(100)	G17Q3/4X
51H30	VALVE-GAS(100)	G17Q3/4X
97H05	VALVE-GAS(100)	G17Q3/4X
21708	WHEEL-BLOWER(100)	G17Q3/4X
87A62	WHEEL-BLOWER(100)	G17Q3/4X

### **G17Q3X**

LB-63086A	BLADE-DAMPER(75)	G17Q3X
68H08	BOARD-CIRCUIT(75)	G17Q3X
18G90	BURNER - PILOT(75)	G17Q3X
34G61	BURNER-MAIN(75)	G17Q3X
34G62	BURNER-MAIN(75)	G17Q3X
81F94	BURNER-MAIN(75)	G17Q3X
82F60	BURNER-MAIN(75)	G17Q3X
61478	BURNER-PILOT(75)	G17Q3X
39H89	CAPACITOR(75)	G17Q3X
59C92	CAPACITOR-BLR MTR(75)	G17Q3X
18G91	CONTROL-IGN(75)	G17Q3X
97H04	CONTROL-IGN(75)	G17Q3X
26H66	CONTROL-LIMIT(75)	G17Q3X
37H73	CONTROL-LIMIT(75)	G17Q3X
52H33	DIVERTER(75)	G17Q3X
26H84	FILTER(75)	G17Q3X

W0822	LEAD(75)	G17Q3X
39C23	MANIFOLD-GAS(75)	G17Q3X
45H31	MOTOR-BLOWER(75)	G17Q3X
45H32	MOTOR-BLOWER(75)	G17Q3X
51H74	MOTOR-DAMPER(75)	G17Q3X
94H80	ORIFICE-BURNER(75)	G17Q3X
LB-13	ORIFICE-BURNER(75)	G17Q3X
89F95	ROD(75)	G17Q3X
44H32	SEAL(75)	G17Q3X
91H39	SEAL(75)	G17Q3X
18G89	SENSOR-FLAME(75)	G17Q3X
85980	SHUTTER-AIR(75)	G17Q3X
26H61	SWITCH(75)	G17Q3X
26H78	SWITCH(75)	G17Q3X
28G13	SWITCH(75)	G17Q3X
71G17	SWITCH(75)	G17Q3X
38631	TRANSFORMER(75)	G17Q3X
78H55	TRANSFORMER(75)	G17Q3X
18G88	VALVE-GAS(75)	G17Q3X
51H30	VALVE-GAS(75)	G17Q3X
97H05	VALVE-GAS(75)	G17Q3X
21708	WHEEL-BLOWER(75)	G17Q3X
21709	WHEEL-BLOWER(75)	G17Q3X

### G17Q4

LB-63086A	BLADE-DAMPER(75)	G17Q4
68H08	BOARD-CIRCUIT(75)	G17Q4
18G90	BURNER - PILOT(75)	G17Q4
34G61	BURNER-MAIN(75)	G17Q4
34G62	BURNER-MAIN(75)	G17Q4
81F94	BURNER-MAIN(75)	G17Q4
82F60	BURNER-MAIN(75)	G17Q4
61478	BURNER-PILOT(75)	G17Q4
39H89	CAPACITOR(75)	G17Q4
59C92	CAPACITOR-BLR MTR(75)	G17Q4
18G91	CONTROL-IGN(75)	G17Q4
97H04	CONTROL-IGN(75)	G17Q4
26H66	CONTROL-LIMIT(75)	G17Q4
37H73	CONTROL-LIMIT(75)	G17Q4
52H33	DIVERTER(75)	G17Q4
26H84	FILTER(75)	G17Q4
26H80	GROMMET(75)	G17Q4
26H81	GROMMET(75)	G17Q4
45H31	MOTOR-BLOWER(75)	G17Q4
45H32	MOTOR-BLOWER(75)	G17Q4
51H74	MOTOR-DAMPER(75)	G17Q4
94H80	ORIFICE-BURNER(75)	G17Q4
LB-13437DA	ORIFICE-BURNER(75)	G17Q4
89F95	ROD(75)	G17Q4
44H32	SEAL(75)	G17Q4



91H39	SEAL(75)	G17Q4
18G89	SENSOR-FLAME(75)	G17Q4
85980	SHUTTER-AIR(75)	G17Q4
26H61	SWITCH(75)	G17Q4
26H78	SWITCH(75)	G17Q4
28G13	SWITCH(75)	G17Q4
71G17	SWITCH(75)	G17Q4
38631	TRANSFORMER(75)	G17Q4
78H55	TRANSFORMER(75)	G17Q4
18G88	VALVE-GAS(75)	G17Q4
51H30	VALVE-GAS(75)	G17Q4
97H05	VALVE-GAS(75)	G17Q4
21708	WHEEL-BLOWER(75)	G17Q4
21709	WHEEL-BLOWER(75)	G17Q4

### **G17Q4X**

LB-63	BLADE-DAMPER(75)	G17Q4X
68H08	BOARD-CIRCUIT(75)	G17Q4X
18G90	BURNER - PILOT(75)	G17Q4X
34G61	BURNER-MAIN(75)	G17Q4X
34G62	BURNER-MAIN(75)	G17Q4X
81F94	BURNER-MAIN(75)	G17Q4X
82F60	BURNER-MAIN(75)	G17Q4X
61478	BURNER-PILOT(75)	G17Q4X
39H89	CAPACITOR(75)	G17Q4X
59C92	CAPACITOR-BLR MTR(75)	G17Q4X
18G91	CONTROL-IGN(75)	G17Q4X
97H04	CONTROL-IGN(75)	G17Q4X
26H66	CONTROL-LIMIT(75)	G17Q4X
37H73	CONTROL-LIMIT(75)	G17Q4X
52H33	DIVERTER(75)	G17Q4X
26H84	FILTER(75)	G17Q4X
26H80	GROMMET(75)	G17Q4X
26H81	GROMMET(75)	G17Q4X
45H31	MOTOR-BLOWER(75)	G17Q4X
45H32	MOTOR-BLOWER(75)	G17Q4X
51H74	MOTOR-DAMPER(75)	G17Q4X
94H80	ORIFICE-BURNER(75)	G17Q4X
LB-13437DA	ORIFICE-BURNER(75)	G17Q4X
89F95	ROD(75)	G17Q4X
44H32	SEAL(75)	G17Q4X
91H39	SEAL(75)	G17Q4X
18G89	SENSOR-FLAME(75)	G17Q4X
85980	SHUTTER-AIR(75)	G17Q4X
26H73	SPRING(75)	G17Q4X
73F19	SPRING(75)	G17Q4X
97H76	SPRING(75)	G17Q4X
26H61	SWITCH(75)	G17Q4X
26H78	SWITCH(75)	G17Q4X
28G13	SWITCH(75)	G17Q4X

71G17	SWITCH(75)	G17Q4X
38631	TRANSFORMER(75)	G17Q4X
78H55	TRANSFORMER(75)	G17Q4X
18G88	VALVE-GAS(75)	G17Q4X
51H30	VALVE-GAS(75)	G17Q4X
97H05	VALVE-GAS(75)	G17Q4X
21708	WHEEL-BLOWER(75)	G17Q4X
21709	WHEEL-BLOWER(75)	G17Q4X

### **G17Q5/6**

LB-63086B	BLADE-DAMPER(100)	G17Q5/6
LB-63086C	BLADE-DAMPER(125)	G17Q5/6
68H08	BOARD-CIRCUIT(125 100)	G17Q5/6
18G90	BURNER - PILOT(125 100)	G17Q5/6
34G61	BURNER-MAIN(100)	G17Q5/6
34G62	BURNER-MAIN(100)	G17Q5/6
81F94	BURNER-MAIN(125 100)	G17Q5/6
82F60	BURNER-MAIN(125 100)	G17Q5/6
61478	BURNER-PILOT(125 100)	G17Q5/6
39H89	CAPACITOR(100)	G17Q5/6
39H58	CAPACITOR(125 100)	G17Q5/6
18G91	CONTROL-IGN(125 100)	G17Q5/6
97H04	CONTROL-IGN(125 100)	G17Q5/6
37H72	CONTROL-LIMIT(100)	G17Q5/6
26H65	CONTROL-LIMIT(125 100)	G17Q5/6
52H34	DIVERTER(100)	G17Q5/6
52H35	DIVERTER(125)	G17Q5/6
26H84	FILTER(100)	G17Q5/6
78H69	FILTER-AIR(100)	G17Q5/6
26H83	FILTER-AIR(125 100)	G17Q5/6
45H32	MOTOR-BLOWER(100)	G17Q5/6
45H33	MOTOR-BLOWER(125 100)	G17Q5/6
51H74	MOTOR-DAMPER(125 100)	G17Q5/6
78A18	MOUNT-MOTOR(125 100)	G17Q5/6
94H80	ORIFICE-BURNER(125 100)	G17Q5/6
LB-13437DA	ORIFICE-BURNER(125 100)	G17Q5/6
89F95	ROD(100)	G17Q5/6
96H94	SEAL(100)	G17Q5/6
91H39	SEAL(125 100)	G17Q5/6
24J30	SEAL(125)	G17Q5/6
18G89	SENSOR-FLAME(125 100)	G17Q5/6
85980	SHUTTER-AIR(125 100)	G17Q5/6
26H61	SWITCH(125 100)	G17Q5/6
28G13	SWITCH(125 100)	G17Q5/6
71G17	SWITCH(125 100)	G17Q5/6
38631	TRANSFORMER(125 100)	G17Q5/6
78H55	TRANSFORMER(125 100)	G17Q5/6
18G88	VALVE-GAS(125 100)	G17Q5/6
51H30	VALVE-GAS(125 100)	G17Q5/6
97H05	VALVE-GAS(125 100)	G17Q5/6

21708	WHEEL-BLOWER(100)	G17Q5/6
87A62	WHEEL-BLOWER(125 100)	G17Q5/6

### **G17Q5/6X**

LB-63086B	BLADE-DAMPER(100)	G17Q5/6X
68H08	BOARD-CIRCUIT(100)	G17Q5/6X
18G90	BURNER - PILOT(100)	G17Q5/6X
34G61	BURNER-MAIN(100)	G17Q5/6X
34G62	BURNER-MAIN(100)	G17Q5/6X
81F94	BURNER-MAIN(100)	G17Q5/6X
82F60	BURNER-MAIN(100)	G17Q5/6X
61478	BURNER-PILOT(100)	G17Q5/6X
39H58	CAPACITOR(100)	G17Q5/6X
39H89	CAPACITOR(100)	G17Q5/6X
18G91	CONTROL-IGN(100)	G17Q5/6X
97H04	CONTROL-IGN(100)	G17Q5/6X
26H65	CONTROL-LIMIT(100)	G17Q5/6X
37H72	CONTROL-LIMIT(100)	G17Q5/6X
52H34	DIVERTER(100)	G17Q5/6X
26H84	FILTER(100)	G17Q5/6X
26H83	FILTER-AIR(100)	G17Q5/6X
78H69	FILTER-AIR(100)	G17Q5/6X
45H32	MOTOR-BLOWER(100)	G17Q5/6X
45H33	MOTOR-BLOWER(100)	G17Q5/6X
51H74	MOTOR-DAMPER(100)	G17Q5/6X
78A18	MOUNT-MOTOR(100)	G17Q5/6X
94H80	ORIFICE-BURNER(100)	G17Q5/6X
LB-13437DA	ORIFICE-BURNER(100)	G17Q5/6X
89F95	ROD(100)	G17Q5/6X
91H39	SEAL(100)	G17Q5/6X
96H94	SEAL(100)	G17Q5/6X
18G89	SENSOR-FLAME(100)	G17Q5/6X
85980	SHUTTER-AIR(100)	G17Q5/6X
26H61	SWITCH(100)	G17Q5/6X
28G13	SWITCH(100)	G17Q5/6X
71G17	SWITCH(100)	G17Q5/6X
38631	TRANSFORMER(100)	G17Q5/6X
78H55	TRANSFORMER(100)	G17Q5/6X
18G88	VALVE-GAS(100)	G17Q5/6X
51H30	VALVE-GAS(100)	G17Q5/6X
97H05	VALVE-GAS(100)	G17Q5/6X
21708	WHEEL-BLOWER(100)	G17Q5/6X
87A62	WHEEL-BLOWER(100)	G17Q5/6X

### **G17RQ2/3**

LB-63	BLADE-DAMPER(50)	G17RQ2/3
68H08	BOARD-CIRCUIT(50)	G17RQ2/3
18G90	BURNER - PILOT(50)	G17RQ2/3
81F94	BURNER-MAIN(50)	G17RQ2/3

82F60	BURNER-MAIN(50)	G17RQ2/3
61478	BURNER-PILOT(50)	G17RQ2/3
59C92	CAPACITOR-BLR MTR(50)	G17RQ2/3
18G91	CONTROL-IGN(50)	G17RQ2/3
97H04	CONTROL-IGN(50)	G17RQ2/3
45H83	CONTROL-LIMIT(50)	G17RQ2/3
87F16	CONTROL-LIMIT(50)	G17RQ2/3
56H44	DIVERTER(50)	G17RQ2/3
82F97	FILTER-AIR(50)	G17RQ2/3
32J13	LEAD(50)	G17RQ2/3
45H31	MOTOR-BLOWER(50)	G17RQ2/3
51H74	MOTOR-DAMPER(50)	G17RQ2/3
94H80	ORIFICE-BURNER(50)	G17RQ2/3
LB-13	ORIFICE-BURNER(50)	G17RQ2/3
LB-62	RESTRICTOR(50)	G17RQ2/3
18G89	SENSOR-FLAME(50)	G17RQ2/3
85980	SHUTTER-AIR(50)	G17RQ2/3
26H61	SWITCH(50)	G17RQ2/3
26H78	SWITCH(50)	G17RQ2/3
71G15	SWITCH(50)	G17RQ2/3
58H33	SWITCH-INTERLOCK(50)	G17RQ2/3
38631	TRANSFORMER(50)	G17RQ2/3
78H55	TRANSFORMER(50)	G17RQ2/3
18G88	VALVE-GAS(50)	G17RQ2/3
51H30	VALVE-GAS(50)	G17RQ2/3
97H05	VALVE-GAS(50)	G17RQ2/3
21708	WHEEL-BLOWER(50)	G17RQ2/3

### **G17RQ3**

LB-63	BLADE-DAMPER(75)	G17RQ3
68H08	BOARD-CIRCUIT(75)	G17RQ3
18G90	BURNER - PILOT(75)	G17RQ3
81F94	BURNER-MAIN(75)	G17RQ3
82F60	BURNER-MAIN(75)	G17RQ3
61478	BURNER-PILOT(75)	G17RQ3
59C92	CAPACITOR-BLR MTR(75)	G17RQ3
18G91	CONTROL-IGN(75)	G17RQ3
97H04	CONTROL-IGN(75)	G17RQ3
45H83	CONTROL-LIMIT(75)	G17RQ3
87F16	CONTROL-LIMIT(75)	G17RQ3
52H33	DIVERTER(75)	G17RQ3
82F97	FILTER-AIR(75)	G17RQ3
32J13	LEAD(75)	G17RQ3
45H31	MOTOR-BLOWER(75)	G17RQ3
51H74	MOTOR-DAMPER(75)	G17RQ3
94H80	ORIFICE-BURNER(75)	G17RQ3
LB-13437DA	ORIFICE-BURNER(75)	G17RQ3
18G89	SENSOR-FLAME(75)	G17RQ3
85980	SHUTTER-AIR(75)	G17RQ3
26H61	SWITCH(75)	G17RQ3

26H78	SWITCH(75)	G17RQ3
71G15	SWITCH(75)	G17RQ3
58H33	SWITCH-INTERLOCK(75)	G17RQ3
38631	TRANSFORMER(75)	G17RQ3
78H55	TRANSFORMER(75)	G17RQ3
18G88	VALVE-GAS(75)	G17RQ3
51H30	VALVE-GAS(75)	G17RQ3
97H05	VALVE-GAS(75)	G17RQ3
21708	WHEEL-BLOWER(75)	G17RQ3

### **G17RQ3/4**

LB-63	BLADE-DAMPER(100)	G17RQ3/4
68H08	BOARD-CIRCUIT(100)	G17RQ3/4
18G90	BURNER - PILOT(100)	G17RQ3/4
81F94	BURNER-MAIN(100)	G17RQ3/4
82F60	BURNER-MAIN(100)	G17RQ3/4
61478	BURNER-PILOT(100)	G17RQ3/4
39H58	CAPACITOR(100)	G17RQ3/4
39H89	CAPACITOR(100)	G17RQ3/4
18G91	CONTROL-IGN(100)	G17RQ3/4
97H04	CONTROL-IGN(100)	G17RQ3/4
11G87	CONTROL-LIMIT(100)	G17RQ3/4
26H64	CONTROL-LIMIT(100)	G17RQ3/4
48G07	CONTROL-LIMIT(100)	G17RQ3/4
69H13	CONTROL-LIMIT(100)	G17RQ3/4
87F16	CONTROL-LIMIT(100)	G17RQ3/4
52H34	DIVERTER(100)	G17RQ3/4
51H17	FILTER-AIR(100)	G17RQ3/4
87F74	FILTER-AIR(100)	G17RQ3/4
32J13	LEAD(100)	G17RQ3/4
45H32	MOTOR-BLOWER(100)	G17RQ3/4
45H33	MOTOR-BLOWER(100)	G17RQ3/4
51H74	MOTOR-DAMPER(100)	G17RQ3/4
94H80	ORIFICE-BURNER(100)	G17RQ3/4
LB-13437DA	ORIFICE-BURNER(100)	G17RQ3/4
18G89	SENSOR-FLAME(100)	G17RQ3/4
85980	SHUTTER-AIR(100)	G17RQ3/4
26H61	SWITCH(100)	G17RQ3/4
71G15	SWITCH(100)	G17RQ3/4
71G17	SWITCH(100)	G17RQ3/4
58H33	SWITCH-INTERLOCK(100)	G17RQ3/4
38631	TRANSFORMER(100)	G17RQ3/4
78H55	TRANSFORMER(100)	G17RQ3/4
18G88	VALVE-GAS(100)	G17RQ3/4
51H30	VALVE-GAS(100)	G17RQ3/4
97H05	VALVE-GAS(100)	G17RQ3/4
10G44	WHEEL-BLOWER(100)	G17RQ3/4
87A62	WHEEL-BLOWER(100)	G17RQ3/4

### **G17RQ4/5**

LB-63086C	BLADE-DAMPER(125)	G17RQ4/5
68H08	BOARD-CIRCUIT(125)	G17RQ4/5
18G90	BURNER - PILOT(125)	G17RQ4/5
81F94	BURNER-MAIN(125)	G17RQ4/5
82F60	BURNER-MAIN(125)	G17RQ4/5
61478	BURNER-PILOT(125)	G17RQ4/5
39H58	CAPACITOR(125)	G17RQ4/5
18G91	CONTROL-IGN(125)	G17RQ4/5
97H04	CONTROL-IGN(125)	G17RQ4/5
11G87	CONTROL-LIMIT(125)	G17RQ4/5
48G07	CONTROL-LIMIT(125)	G17RQ4/5
69H17	CONTROL-LIMIT(125)	G17RQ4/5
52H35	DIVERTER(125)	G17RQ4/5
51H17	FILTER-AIR(125)	G17RQ4/5
32J13	LEAD(125)	G17RQ4/5
61590	MANIFOLD-GAS(125)	G17RQ4/5
45H33	MOTOR-BLOWER(125)	G17RQ4/5
51H74	MOTOR-DAMPER(125)	G17RQ4/5
78A18	MOUNT-MOTOR(125)	G17RQ4/5
94H80	ORIFICE-BURNER(125)	G17RQ4/5
LB-13437DA	ORIFICE-BURNER(125)	G17RQ4/5
18G89	SENSOR-FLAME(125)	G17RQ4/5
85980	SHUTTER-AIR(125)	G17RQ4/5
26H61	SWITCH(125)	G17RQ4/5
71G15	SWITCH(125)	G17RQ4/5
71G17	SWITCH(125)	G17RQ4/5
58H33	SWITCH-INTERLOCK(125)	G17RQ4/5
38631	TRANSFORMER(125)	G17RQ4/5
78H55	TRANSFORMER(125)	G17RQ4/5
18G88	VALVE-GAS(125)	G17RQ4/5
51H30	VALVE-GAS(125)	G17RQ4/5
97H05	VALVE-GAS(125)	G17RQ4/5
87A62	WHEEL-BLOWER(125)	G17RQ4/5

### G17RQ5

LB-63086B	BLADE-DAMPER(100)	G17RQ5
68H08	BOARD-CIRCUIT(100)	G17RQ5
18G90	BURNER - PILOT(100)	G17RQ5
81F94	BURNER-MAIN(100)	G17RQ5
82F60	BURNER-MAIN(100)	G17RQ5
61478	BURNER-PILOT(100)	G17RQ5
39H58	CAPACITOR(100)	G17RQ5
39H89	CAPACITOR(100)	G17RQ5
18G91	CONTROL-IGN(100)	G17RQ5
97H04	CONTROL-IGN(100)	G17RQ5
11G87	CONTROL-LIMIT(100)	G17RQ5
26H64	CONTROL-LIMIT(100)	G17RQ5
48G07	CONTROL-LIMIT(100)	G17RQ5
69H13	CONTROL-LIMIT(100)	G17RQ5

87F16	CONTROL-LIMIT(100)	G17RQ5
52H34	DIVERTER(100)	G17RQ5
51H17	FILTER-AIR(100)	G17RQ5
87F74	FILTER-AIR(100)	G17RQ5
32J13	LEAD(100)	G17RQ5
LB-17	MANIFOLD-GAS(100)	G17RQ5
45H32	MOTOR-BLOWER(100)	G17RQ5
45H33	MOTOR-BLOWER(100)	G17RQ5
51H74	MOTOR-DAMPER(100)	G17RQ5
78A18	MOUNT-MOTOR(100)	G17RQ5
94H80	ORIFICE-BURNER(100)	G17RQ5
18G89	SENSOR-FLAME(100)	G17RQ5
85980	SHUTTER-AIR(100)	G17RQ5
26H61	SWITCH(100)	G17RQ5
71G15	SWITCH(100)	G17RQ5
71G17	SWITCH(100)	G17RQ5
58H33	SWITCH-INTERLOCK(100)	G17RQ5
38631	TRANSFORMER(100)	G17RQ5
78H55	TRANSFORMER(100)	G17RQ5
18G88	VALVE-GAS(100)	G17RQ5
51H30	VALVE-GAS(100)	G17RQ5
97H05	VALVE-GAS(100)	G17RQ5
10G44	WHEEL-BLOWER(100)	G17RQ5
87A62	WHEEL-BLOWER(100)	G17RQ5