

## GHR26

48L96	BLOWER-COMB AIR(75 50 120 100)	GHR26
24L85	BOARD-CIRCUIT(75 50 120 100)	GHR26
63K89	BOARD-CIRCUIT(75 50 120 100)	GHR26
76K21	BOARD-CIRCUIT(75 50 120 100)	GHR26
50J54	BURNER-MAIN(100)	GHR26
50J55	BURNER-MAIN(120)	GHR26
50J52	BURNER-MAIN(50)	GHR26
50J53	BURNER-MAIN(75)	GHR26
97L48	CONTROL-IGN(75 50 120 100)	GHR26
18K44	CONTROL-LIMIT(100)	GHR26
29K51	CONTROL-LIMIT(100)	GHR26
39L08	CONTROL-LIMIT(100)	GHR26
18K45	CONTROL-LIMIT(120)	GHR26
39L07	CONTROL-LIMIT(120)	GHR26
18K80	CONTROL-LIMIT(75 50 120 100)	GHR26
18K43	CONTROL-LIMIT(75 50)	GHR26
14K99	ELECTRODE(75 50 120 100)	GHR26
59436	FILTER(120 100)	GHR26
31J81	FILTER(75 50)	GHR26
14K97	FITTING(75 50 120 100)	GHR26
41K56	IGNITOR(75 50 120 100)	GHR26
11M65	LEAD(75 50 120 100)	GHR26
18K14	LEAD-IGNITION(75 50 120 100)	GHR26
28F01	MOTOR-BLOWER(120 100)	GHR26
45H33	MOTOR-BLOWER(120 100)	GHR26
21L92	MOTOR-BLOWER(50)	GHR26
37J25	MOTOR-BLOWER(50)	GHR26
21L93	MOTOR-BLOWER(75 100)	GHR26
37J24	MOTOR-BLOWER(75 100)	GHR26
59L89	MOUNT-MOTOR(120 100)	GHR26
32K70	ORIFICE-BURNER(75 50 120 100)	GHR26
94H80	ORIFICE-BURNER(75 50 120 100)	GHR26
40L81	SENSOR-FLAME KIT(75 50 120 100)	GHR26
25J13	SWITCH(75 50 120 100)	GHR26
31J96	SWITCH-MANUAL(75 50 120 100)	GHR26
67K27	SWITCH-PRESS(75 50 120 100)	GHR26
42J32	TRANSFORMER(75 50 120 100)	GHR26
29K43	VALVE-GAS(75 50 120 100)	GHR26
29M84	VALVE-GAS(75 50 120 100)	GHR26
63K88	VALVE-GAS(75 50 120 100)	GHR26
99K65	VALVE-GAS(75 50 120 100)	GHR26
16596	WHEEL-BLOWER(100)	GHR26
10G44	WHEEL-BLOWER(120 100)	GHR26
21708	WHEEL-BLOWER(75 50)	GHR26

## GHR26Q2/3

48L96	BLOWER-COMB AIR(50)	GHR26Q2/3
24L85	BOARD-CIRCUIT(50)	GHR26Q2/3
63K89	BOARD-CIRCUIT(50)	GHR26Q2/3
76K21	BOARD-CIRCUIT(50)	GHR26Q2/3
37J56	BREAKER-CIRC(50)	GHR26Q2/3
50J52	BURNER-MAIN(50)	GHR26Q2/3
59C92	CAPACITOR-BLR MTR(50)	GHR26Q2/3
97L48	CONTROL-IGN(50)	GHR26Q2/3
18K43	CONTROL-LIMIT(50)	GHR26Q2/3
18K80	CONTROL-LIMIT(50)	GHR26Q2/3
14K99	ELECTRODE(50)	GHR26Q2/3
31J81	FILTER(50)	GHR26Q2/3
41K56	IGNITOR(50)	GHR26Q2/3
11M65	LEAD(50)	GHR26Q2/3
18K14	LEAD-IGNITION(50)	GHR26Q2/3
21L92	MOTOR-BLOWER(50)	GHR26Q2/3
37J25	MOTOR-BLOWER(50)	GHR26Q2/3
32K70	ORIFICE-BURNER(50)	GHR26Q2/3
94H80	ORIFICE-BURNER(50)	GHR26Q2/3
40L81	SENSOR-FLAME KIT(50)	GHR26Q2/3
25J13	SWITCH(50)	GHR26Q2/3
31J96	SWITCH-MANUAL(50)	GHR26Q2/3
67K27	SWITCH-PRESS(50)	GHR26Q2/3
42J32	TRANSFORMER(50)	GHR26Q2/3
29K43	VALVE-GAS(50)	GHR26Q2/3
29M84	VALVE-GAS(50)	GHR26Q2/3
63K88	VALVE-GAS(50)	GHR26Q2/3
99K65	VALVE-GAS(50)	GHR26Q2/3
21708	WHEEL-BLOWER(50)	GHR26Q2/3

### **GHR26Q3**

48L96	BLOWER-COMB AIR(75)	GHR26Q3
24L85	BOARD-CIRCUIT(75)	GHR26Q3
63K89	BOARD-CIRCUIT(75)	GHR26Q3
76K21	BOARD-CIRCUIT(75)	GHR26Q3
37J56	BREAKER-CIRC(75)	GHR26Q3
50J53	BURNER-MAIN(75)	GHR26Q3
39H89	CAPACITOR(75)	GHR26Q3
97L48	CONTROL-IGN(75)	GHR26Q3
18K43	CONTROL-LIMIT(75)	GHR26Q3
18K80	CONTROL-LIMIT(75)	GHR26Q3
14K99	ELECTRODE(75)	GHR26Q3
31J81	FILTER(75)	GHR26Q3
41K56	IGNITOR(75)	GHR26Q3
11M65	LEAD(75)	GHR26Q3
18K14	LEAD-IGNITION(75)	GHR26Q3
21L93	MOTOR-BLOWER(75)	GHR26Q3
37J24	MOTOR-BLOWER(75)	GHR26Q3
32K70	ORIFICE-BURNER(75)	GHR26Q3
94H80	ORIFICE-BURNER(75)	GHR26Q3

40L81	SENSOR-FLAME KIT(75)	GHR26Q3
25J13	SWITCH(75)	GHR26Q3
31J96	SWITCH-MANUAL(75)	GHR26Q3
67K27	SWITCH-PRESS(75)	GHR26Q3
42J32	TRANSFORMER(75)	GHR26Q3
29K43	VALVE-GAS(75)	GHR26Q3
29M84	VALVE-GAS(75)	GHR26Q3
63K88	VALVE-GAS(75)	GHR26Q3
99K65	VALVE-GAS(75)	GHR26Q3
21708	WHEEL-BLOWER(75)	GHR26Q3

### **GHR26Q3/4**

48L96	BLOWER-COMB AIR(100)	GHR26Q3/4
24L85	BOARD-CIRCUIT(100)	GHR26Q3/4
63K89	BOARD-CIRCUIT(100)	GHR26Q3/4
76K21	BOARD-CIRCUIT(100)	GHR26Q3/4
37J56	BREAKER-CIRC(100)	GHR26Q3/4
50J54	BURNER-MAIN(100)	GHR26Q3/4
39H58	CAPACITOR(100)	GHR26Q3/4
39H89	CAPACITOR(100)	GHR26Q3/4
97L48	CONTROL-IGN(100)	GHR26Q3/4
18K44	CONTROL-LIMIT(100)	GHR26Q3/4
18K80	CONTROL-LIMIT(100)	GHR26Q3/4
29K51	CONTROL-LIMIT(100)	GHR26Q3/4
39L08	CONTROL-LIMIT(100)	GHR26Q3/4
14K99	ELECTRODE(100)	GHR26Q3/4
59436	FILTER(100)	GHR26Q3/4
41K56	IGNITOR(100)	GHR26Q3/4
11M65	LEAD(100)	GHR26Q3/4
18K14	LEAD-IGNITION(100)	GHR26Q3/4
21L93	MOTOR-BLOWER(100)	GHR26Q3/4
28F01	MOTOR-BLOWER(100)	GHR26Q3/4
37J24	MOTOR-BLOWER(100)	GHR26Q3/4
45H33	MOTOR-BLOWER(100)	GHR26Q3/4
32K70	ORIFICE-BURNER(100)	GHR26Q3/4
94H80	ORIFICE-BURNER(100)	GHR26Q3/4
40L81	SENSOR-FLAME KIT(100)	GHR26Q3/4
25J13	SWITCH(100)	GHR26Q3/4
31J96	SWITCH-MANUAL(100)	GHR26Q3/4
67K27	SWITCH-PRESS(100)	GHR26Q3/4
42J32	TRANSFORMER(100)	GHR26Q3/4
32K96	TRAP(100)	GHR26Q3/4
29K43	VALVE-GAS(100)	GHR26Q3/4
29M84	VALVE-GAS(100)	GHR26Q3/4
63K88	VALVE-GAS(100)	GHR26Q3/4
99K65	VALVE-GAS(100)	GHR26Q3/4
16596	WHEEL-BLOWER(100)	GHR26Q3/4
10G44	WHEEL-BLOWER(100)	GHR26Q3/4

## **GHR26Q4/5**

48L96	BLOWER-COMB AIR(120 100)	GHR26Q4/5
24L85	BOARD-CIRCUIT(120 100)	GHR26Q4/5
63K89	BOARD-CIRCUIT(120 100)	GHR26Q4/5
76K21	BOARD-CIRCUIT(120 100)	GHR26Q4/5
37J56	BREAKER-CIRC(120 100)	GHR26Q4/5
50J54	BURNER-MAIN(100)	GHR26Q4/5
50J55	BURNER-MAIN(120)	GHR26Q4/5
39H89	CAPACITOR(100)	GHR26Q4/5
39H58	CAPACITOR(120 100)	GHR26Q4/5
97L48	CONTROL-IGN(120 100)	GHR26Q4/5
18K44	CONTROL-LIMIT(100)	GHR26Q4/5
29K51	CONTROL-LIMIT(100)	GHR26Q4/5
39L08	CONTROL-LIMIT(100)	GHR26Q4/5
18K80	CONTROL-LIMIT(120 100)	GHR26Q4/5
18K45	CONTROL-LIMIT(120)	GHR26Q4/5
39L07	CONTROL-LIMIT(120)	GHR26Q4/5
14K99	ELECTRODE(120 100)	GHR26Q4/5
59436	FILTER(120 100)	GHR26Q4/5
41K56	IGNITOR(120 100)	GHR26Q4/5
11M65	LEAD(120 100)	GHR26Q4/5
18K14	LEAD-IGNITION(120 100)	GHR26Q4/5
21L93	MOTOR-BLOWER(100)	GHR26Q4/5
37J24	MOTOR-BLOWER(100)	GHR26Q4/5
28F01	MOTOR-BLOWER(120 100)	GHR26Q4/5
45H33	MOTOR-BLOWER(120 100)	GHR26Q4/5
59L89	MOUNT-MOTOR(120 100)	GHR26Q4/5
32K70	ORIFICE-BURNER(120 100)	GHR26Q4/5
94H80	ORIFICE-BURNER(120 100)	GHR26Q4/5
40L81	SENSOR-FLAME KIT(120 100)	GHR26Q4/5
25J13	SWITCH(120 100)	GHR26Q4/5
31J96	SWITCH-MANUAL(120 100)	GHR26Q4/5
67K27	SWITCH-PRESS(120 100)	GHR26Q4/5
42J32	TRANSFORMER(120 100)	GHR26Q4/5
29K43	VALVE-GAS(120 100)	GHR26Q4/5
29M84	VALVE-GAS(120 100)	GHR26Q4/5
63K88	VALVE-GAS(120 100)	GHR26Q4/5
99K65	VALVE-GAS(120 100)	GHR26Q4/5
16596	WHEEL-BLOWER(100)	GHR26Q4/5
10G44	WHEEL-BLOWER(120 100)	GHR26Q4/5

## **GHR32Q2/3**

63L83	BLOWER-COMB AIR(50)	GHR32Q2/3
18M34	BOARD-CIRCUIT(50)	GHR32Q2/3
24L85	BOARD-CIRCUIT(50)	GHR32Q2/3
37J56	BREAKER-CIRC(50)	GHR32Q2/3
59C92	CAPACITOR-BLR MTR(50)	GHR32Q2/3
97L48	CONTROL-IGN(50)	GHR32Q2/3

18K43	CONTROL-LIMIT(50)	GHR32Q2/3
18K80	CONTROL-LIMIT(50)	GHR32Q2/3
31J81	FILTER(50)	GHR32Q2/3
41K56	IGNITOR(50)	GHR32Q2/3
21L92	MOTOR-BLOWER(50)	GHR32Q2/3
32K70	ORIFICE-BURNER(50)	GHR32Q2/3
94H80	ORIFICE-BURNER(50)	GHR32Q2/3
40L81	SENSOR-FLAME KIT(50)	GHR32Q2/3
25J13	SWITCH(50)	GHR32Q2/3
31J96	SWITCH-MANUAL(50)	GHR32Q2/3
60L03	SWITCH-PRESS(50)	GHR32Q2/3
29M71	TRANSFORMER(50)	GHR32Q2/3
42J32	TRANSFORMER(50)	GHR32Q2/3
12L57	VALVE-GAS(50)	GHR32Q2/3
61L11	VALVE-GAS(50)	GHR32Q2/3
78L42	VALVE-GAS(50)	GHR32Q2/3
21708	WHEEL-BLOWER(50)	GHR32Q2/3
11M65	WIRE-FLAME SENSOR(50)	GHR32Q2/3

### **GHR32Q3**

63L83	BLOWER-COMB AIR(75)	GHR32Q3
18M34	BOARD-CIRCUIT(75)	GHR32Q3
24L85	BOARD-CIRCUIT(75)	GHR32Q3
37J56	BREAKER-CIRC(75)	GHR32Q3
50J53	BURNER-MAIN(75)	GHR32Q3
39H89	CAPACITOR(75)	GHR32Q3
97L48	CONTROL-IGN(75)	GHR32Q3
18K43	CONTROL-LIMIT(75)	GHR32Q3
18K80	CONTROL-LIMIT(75)	GHR32Q3
31J81	FILTER(75)	GHR32Q3
41K56	IGNITOR(75)	GHR32Q3
21L93	MOTOR-BLOWER(75)	GHR32Q3
32K70	ORIFICE-BURNER(75)	GHR32Q3
94H80	ORIFICE-BURNER(75)	GHR32Q3
40L81	SENSOR-FLAME KIT(75)	GHR32Q3
25J13	SWITCH(75)	GHR32Q3
31J96	SWITCH-MANUAL(75)	GHR32Q3
60L03	SWITCH-PRESS(75)	GHR32Q3
29M71	TRANSFORMER(75)	GHR32Q3
42J32	TRANSFORMER(75)	GHR32Q3
12L57	VALVE-GAS(75)	GHR32Q3
61L11	VALVE-GAS(75)	GHR32Q3
78L42	VALVE-GAS(75)	GHR32Q3
21708	WHEEL-BLOWER(75)	GHR32Q3
11M65	WIRE-FLAME SENSOR(75)	GHR32Q3

### **GHR32Q4/5**

63L83	BLOWER-COMB AIR(120 100)	GHR32Q4/5
18M34	BOARD-CIRCUIT(120 100)	GHR32Q4/5
24L85	BOARD-CIRCUIT(120 100)	GHR32Q4/5
37J56	BREAKER-CIRC(120 100)	GHR32Q4/5
50J54	BURNER-MAIN(100)	GHR32Q4/5
50J55	BURNER-MAIN(120)	GHR32Q4/5
39H58	CAPACITOR(120 100)	GHR32Q4/5
97L48	CONTROL-IGN(120 100)	GHR32Q4/5
39L08	CONTROL-LIMIT(100)	GHR32Q4/5
18K80	CONTROL-LIMIT(120 100)	GHR32Q4/5
39L07	CONTROL-LIMIT(120)	GHR32Q4/5
59436	FILTER(120 100)	GHR32Q4/5
14K97	FITTING(120 100)	GHR32Q4/5
41K56	IGNITOR(120 100)	GHR32Q4/5
28F01	MOTOR-BLOWER(120 100)	GHR32Q4/5
32K70	ORIFICE-BURNER(120 100)	GHR32Q4/5
94H80	ORIFICE-BURNER(120 100)	GHR32Q4/5
40L81	SENSOR-FLAME KIT(120 100)	GHR32Q4/5
25J13	SWITCH(120 100)	GHR32Q4/5
31J96	SWITCH-MANUAL(120 100)	GHR32Q4/5
60L03	SWITCH-PRESS(120 100)	GHR32Q4/5
29M71	TRANSFORMER(120 100)	GHR32Q4/5
42J32	TRANSFORMER(120 100)	GHR32Q4/5
12L57	VALVE-GAS(120 100)	GHR32Q4/5
61L11	VALVE-GAS(120 100)	GHR32Q4/5
78L42	VALVE-GAS(120 100)	GHR32Q4/5
10G44	WHEEL-BLOWER(120 100)	GHR32Q4/5
11M65	WIRE-FLAME SENSOR(120 100)	GHR32Q4/5

### GHR32V3

63L83	BLOWER-COMB AIR(75)	GHR32V3
18M99	BOARD-CIRCUIT(75)	GHR32V3
24L85	BOARD-CIRCUIT(75)	GHR32V3
27M68	BOARD-CONTROL(75)	GHR32V3
38L95	BOARD-CONTROL(75)	GHR32V3
37J56	BREAKER-CIRC(75)	GHR32V3
50J53	BURNER-MAIN(75)	GHR32V3
69H12	CHOKE-POWER(75)	GHR32V3
97L48	CONTROL-IGN(75)	GHR32V3
18K43	CONTROL-LIMIT(75)	GHR32V3
18K80	CONTROL-LIMIT(75)	GHR32V3
31J81	FILTER(75)	GHR32V3
41K56	IGNITOR(75)	GHR32V3
37M06	MODULE-CONTROL(75)	GHR32V3
38L02	MODULE-CONTROL(75)	GHR32V3
32M98	MOTOR-BLOWER(75)	GHR32V3
39L32	MOTOR-BLOWER(75)	GHR32V3
32K70	ORIFICE-BURNER(75)	GHR32V3
94H80	ORIFICE-BURNER(75)	GHR32V3

40L81	SENSOR-FLAME KIT(75)	GHR32V3
25J13	SWITCH(75)	GHR32V3
31J96	SWITCH-MANUAL(75)	GHR32V3
60L03	SWITCH-PRESS(75)	GHR32V3
29M71	TRANSFORMER(75)	GHR32V3
42J32	TRANSFORMER(75)	GHR32V3
72H94	TRANSFORMER(75)	GHR32V3
12L57	VALVE-GAS(75)	GHR32V3
61L11	VALVE-GAS(75)	GHR32V3
78L42	VALVE-GAS(75)	GHR32V3
89J10	WHEEL-BLOWER(75)	GHR32V3
11M65	WIRE-FLAME SENSOR(75)	GHR32V3

### **GHR32V5**

63L83	BLOWER-COMB AIR(100)	GHR32V5
18M99	BOARD-CIRCUIT(100)	GHR32V5
24L85	BOARD-CIRCUIT(100)	GHR32V5
27M68	BOARD-CONTROL(100)	GHR32V5
38L95	BOARD-CONTROL(100)	GHR32V5
50J54	BURNER-MAIN(100)	GHR32V5
69H12	CHOKE-POWER(100)	GHR32V5
97L48	CONTROL-IGN(100)	GHR32V5
18K80	CONTROL-LIMIT(100)	GHR32V5
39L08	CONTROL-LIMIT(100)	GHR32V5
59436	FILTER(100)	GHR32V5
41K56	IGNITOR(100)	GHR32V5
28M32	MODULE-CONTROL(100)	GHR32V5
38L03	MODULE-CONTROL(100)	GHR32V5
25M10	MOTOR-BLOWER(100)	GHR32V5
39L33	MOTOR-BLOWER(100)	GHR32V5
39L58	MOUNT-MOTOR(100)	GHR32V5
32K70	ORIFICE-BURNER(100)	GHR32V5
94H80	ORIFICE-BURNER(100)	GHR32V5
40L81	SENSOR-FLAME KIT(100)	GHR32V5
25J13	SWITCH(100)	GHR32V5
31J96	SWITCH-MANUAL(100)	GHR32V5
60L03	SWITCH-PRESS(100)	GHR32V5
29M71	TRANSFORMER(100)	GHR32V5
42J32	TRANSFORMER(100)	GHR32V5
72H94	TRANSFORMER(100)	GHR32V5
12L57	VALVE-GAS(100)	GHR32V5
61L11	VALVE-GAS(100)	GHR32V5
78L42	VALVE-GAS(100)	GHR32V5
40F86	WHEEL-BLOWER(100)	GHR32V5
11M65	WIRE-FLAME SENSOR(100)	GHR32V5

### **GSR14**

80C93	BLOWER - PURGE(80 50 100)	GSR14
-------	---------------------------	-------

38F92	BLOWER-PURGE(80 50 100)	GSR14
38G92	BLOWER-PURGE(80)	GSR14
96C48	CAPACITOR(80 100)	GSR14
81A39	CAPACITOR(80 50)	GSR14
59C93	CAPACITOR-BLR MTR(50)	GSR14
96C52	CAPACITOR-BLR MTR(80 100)	GSR14
59C92	CAPACITOR-BLR MTR(80 50)	GSR14
28G55	CONTROL-F&L(100)	GSR14
78F11	CONTROL-F&L(80 100)	GSR14
78F07	CONTROL-F&L(80 50)	GSR14
23G38	CONTROL-LIMIT(50)	GSR14
28G45	CONTROL-LIMIT(80 50 100)	GSR14
28G46	CONTROL-LIMIT(80 50 100)	GSR14
58H59	CONTROL-LIMIT(80 50 100)	GSR14
37A07	CONTROL-LIMIT(80 50)	GSR14
60J00	CONTROL-PRIMARY(80 50 100)	GSR14
99C97	CONTROL-PRIMARY(80 50 100)	GSR14
28G54	COUPLING(80 50 100)	GSR14
20H86	DECOUPLER-GAS(80 50 100)	GSR14
32G05	DIAPHRAGM ASSY-AIR(100)	GSR14
42G21	DIAPHRAGM ASSY-AIR(100)	GSR14
84G25	DIAPHRAGM ASSY-AIR(100)	GSR14
32G03	DIAPHRAGM ASSY-AIR(50)	GSR14
84G24	DIAPHRAGM ASSY-AIR(80 50)	GSR14
20H60	DIAPHRAGM ASSY-AIR(80)	GSR14
34G83	DIAPHRAGM ASSY-GAS(80 50 100)	GSR14
LB-59	DIAPHRAGM(100)	GSR14
59436	FILTER(80 50 100)	GSR14
21G46	FUSE(80 50 100)	GSR14
36G00	FUSE(80 50 100)	GSR14
96C78	FUSE(80 50 100)	GSR14
35H96	LEAD(80 50 100)	GSR14
39G08	LEAD(80 50 100)	GSR14
39G09	LEAD(80 50 100)	GSR14
39G10	LEAD-IGNITION(80 50 100)	GSR14
85H36	LEAD-IGNITION(80 50 100)	GSR14
67F15	MOTOR-BLOWER(50)	GSR14
28F01	MOTOR-BLOWER(80 100)	GSR14
49C10	MOTOR-BLOWER(80 100)	GSR14
15B45	MOTOR-BLOWER(80 50)	GSR14
79A52	MOTOR-BLOWER(80 50)	GSR14
37G75	ORIFICE(100)	GSR14
76G29	ORIFICE(100)	GSR14
44H14	ORIFICE(80)	GSR14
37G83	ORIFICE-BURNER(100)	GSR14
37G84	ORIFICE-BURNER(100)	GSR14
47H67	ORIFICE-BURNER(100)	GSR14
LB-51	ORIFICE-BURNER(100)	GSR14
37G87	ORIFICE-BURNER(50)	GSR14
47H66	ORIFICE-BURNER(50)	GSR14
57G00	ORIFICE-BURNER(50)	GSR14



60G07	ORIFICE-BURNER(50)	GSR14
37G85	ORIFICE-BURNER(80)	GSR14
37G88	ORIFICE-BURNER(80)	GSR14
60G08	ORIFICE-BURNER(80)	GSR14
60G09	ORIFICE-BURNER(80)	GSR14
64K60	PLUG - SENSOR(80 50 100)	GSR14
39G06	PLUG-SPARK(80 50 100)	GSR14
13H44	RELAY(80 100)	GSR14
59C70	RELAY(80 50 100)	GSR14
59C71	RELAY(80 50 100)	GSR14
66C67	RELAY(80 50 100)	GSR14
65G69	RELAY-DELAY(50)	GSR14
28G13	SWITCH(80 50 100)	GSR14
43G88	SWITCH(80 50 100)	GSR14
58H32	SWITCH-PRESS(100)	GSR14
58H31	SWITCH-PRESS(80 50 100)	GSR14
44C06	THERMOSTAT(50)	GSR14
65G46	TRANSFORMER(80 100)	GSR14
38631	TRANSFORMER(80 50 100)	GSR14
96C79	TRANSFORMER(80 50 100)	GSR14
LB-49995CA	VALVE-AIR(100)	GSR14
28G14	VALVE-GAS(80 50 100)	GSR14
51H25	VALVE-GAS(80 50 100)	GSR14
51H60	VALVE-GAS(80 50)	GSR14
54G08	VALVE-GAS(80 50)	GSR14
54G55	VALVE-GAS(80 50)	GSR14
21708	WHEEL-BLOWER(50)	GSR14
87A62	WHEEL-BLOWER(80 100)	GSR14
P-8-10471	WHEEL-BLOWER(80 50)	GSR14

### **GSR14Q3**

80C93	BLOWER - PURGE(80 50)	GSR14Q3
38F92	BLOWER-PURGE(80 50)	GSR14Q3
38G92	BLOWER-PURGE(80)	GSR14Q3
81A39	CAPACITOR(80 50)	GSR14Q3
96C48	CAPACITOR(80)	GSR14Q3
59C93	CAPACITOR-BLR MTR(50)	GSR14Q3
59C92	CAPACITOR-BLR MTR(80 50)	GSR14Q3
96C52	CAPACITOR-BLR MTR(80)	GSR14Q3
78F07	CONTROL-F&L(80 50)	GSR14Q3
78F11	CONTROL-F&L(80)	GSR14Q3
23G38	CONTROL-LIMIT(50)	GSR14Q3
28G45	CONTROL-LIMIT(80 50)	GSR14Q3
28G46	CONTROL-LIMIT(80 50)	GSR14Q3
37A07	CONTROL-LIMIT(80 50)	GSR14Q3
58H59	CONTROL-LIMIT(80 50)	GSR14Q3
60J00	CONTROL-PRIMARY(80 50)	GSR14Q3
99C97	CONTROL-PRIMARY(80 50)	GSR14Q3

20H86	DECOUPLER-GAS(80 50)	GSR14Q3
32G03	DIAPHRAGM ASSY-AIR(50)	GSR14Q3
84G24	DIAPHRAGM ASSY-AIR(80 50)	GSR14Q3
20H60	DIAPHRAGM ASSY-AIR(80)	GSR14Q3
34G83	DIAPHRAGM ASSY-GAS(80 50)	GSR14Q3
59436	FILTER(80 50)	GSR14Q3
10J26	FRAME-MTR(80)	GSR14Q3
35H96	LEAD(80 50)	GSR14Q3
39G08	LEAD(80 50)	GSR14Q3
39G09	LEAD(80 50)	GSR14Q3
39G10	LEAD-IGNITION(80 50)	GSR14Q3
85H36	LEAD-IGNITION(80 50)	GSR14Q3
67F15	MOTOR-BLOWER(50)	GSR14Q3
15B45	MOTOR-BLOWER(80 50)	GSR14Q3
79A52	MOTOR-BLOWER(80 50)	GSR14Q3
28F01	MOTOR-BLOWER(80)	GSR14Q3
49C10	MOTOR-BLOWER(80)	GSR14Q3
44H14	ORIFICE(80)	GSR14Q3
37G87	ORIFICE-BURNER(50)	GSR14Q3
47H66	ORIFICE-BURNER(50)	GSR14Q3
57G00	ORIFICE-BURNER(50)	GSR14Q3
60G07	ORIFICE-BURNER(50)	GSR14Q3
37G85	ORIFICE-BURNER(80)	GSR14Q3
37G88	ORIFICE-BURNER(80)	GSR14Q3
60G08	ORIFICE-BURNER(80)	GSR14Q3
60G09	ORIFICE-BURNER(80)	GSR14Q3
64K60	PLUG - SENSOR(80 50)	GSR14Q3
39G06	PLUG-SPARK(80 50)	GSR14Q3
80H00	RACK-FILTER(80 50)	GSR14Q3
59C70	RELAY(80 50)	GSR14Q3
59C71	RELAY(80 50)	GSR14Q3
66C67	RELAY(80 50)	GSR14Q3
13H44	RELAY(80)	GSR14Q3
65G69	RELAY-DELAY(50)	GSR14Q3
28G13	SWITCH(80 50)	GSR14Q3
43G88	SWITCH(80 50)	GSR14Q3
58H31	SWITCH-PRESS(80 50)	GSR14Q3
44C06	THERMOSTAT(50)	GSR14Q3
38631	TRANSFORMER(80 50)	GSR14Q3
96C79	TRANSFORMER(80 50)	GSR14Q3
65G46	TRANSFORMER(80)	GSR14Q3
28G14	VALVE-GAS(80 50)	GSR14Q3
51H25	VALVE-GAS(80 50)	GSR14Q3
51H60	VALVE-GAS(80 50)	GSR14Q3
54G08	VALVE-GAS(80 50)	GSR14Q3
54G55	VALVE-GAS(80 50)	GSR14Q3
21708	WHEEL-BLOWER(50)	GSR14Q3
P-8-10471	WHEEL-BLOWER(80 50)	GSR14Q3
87A62	WHEEL-BLOWER(80)	GSR14Q3

## GSR14Q4

80C93	BLOWER - PURGE(50)	GSR14Q4
38F92	BLOWER-PURGE(50)	GSR14Q4
81A39	CAPACITOR(50)	GSR14Q4
59C92	CAPACITOR-BLR MTR(50)	GSR14Q4
59C93	CAPACITOR-BLR MTR(50)	GSR14Q4
78F07	CONTROL-F&L(50)	GSR14Q4
23G38	CONTROL-LIMIT(50)	GSR14Q4
28G45	CONTROL-LIMIT(50)	GSR14Q4
28G46	CONTROL-LIMIT(50)	GSR14Q4
37A07	CONTROL-LIMIT(50)	GSR14Q4
58H59	CONTROL-LIMIT(50)	GSR14Q4
60J00	CONTROL-PRIMARY(50)	GSR14Q4
99C97	CONTROL-PRIMARY(50)	GSR14Q4
32G03	DIAPHRAGM ASSY-AIR(50)	GSR14Q4
84G24	DIAPHRAGM ASSY-AIR(50)	GSR14Q4
34G83	DIAPHRAGM ASSY-GAS(50)	GSR14Q4
35H96	LEAD(50)	GSR14Q4
39G08	LEAD(50)	GSR14Q4
39G09	LEAD(50)	GSR14Q4
39G10	LEAD-IGNITION(50)	GSR14Q4
85H36	LEAD-IGNITION(50)	GSR14Q4
15B45	MOTOR-BLOWER(50)	GSR14Q4
67F15	MOTOR-BLOWER(50)	GSR14Q4
79A52	MOTOR-BLOWER(50)	GSR14Q4
37G87	ORIFICE-BURNER(50)	GSR14Q4
47H66	ORIFICE-BURNER(50)	GSR14Q4
57G00	ORIFICE-BURNER(50)	GSR14Q4
60G07	ORIFICE-BURNER(50)	GSR14Q4
64K60	PLUG - SENSOR(50)	GSR14Q4
39G06	PLUG-SPARK(50)	GSR14Q4
80H00	RACK-FILTER(50)	GSR14Q4
59C70	RELAY(50)	GSR14Q4
59C71	RELAY(50)	GSR14Q4
66C67	RELAY(50)	GSR14Q4
65G69	RELAY-DELAY(50)	GSR14Q4
28G13	SWITCH(50)	GSR14Q4
43G88	SWITCH(50)	GSR14Q4
58H31	SWITCH-PRESS(50)	GSR14Q4
44C06	THERMOSTAT(50)	GSR14Q4
38631	TRANSFORMER(50)	GSR14Q4
96C79	TRANSFORMER(50)	GSR14Q4
28G14	VALVE-GAS(50)	GSR14Q4
51H25	VALVE-GAS(50)	GSR14Q4
51H60	VALVE-GAS(50)	GSR14Q4
54G08	VALVE-GAS(50)	GSR14Q4
54G55	VALVE-GAS(50)	GSR14Q4
21708	WHEEL-BLOWER(50)	GSR14Q4
P-8-10471	WHEEL-BLOWER(50)	GSR14Q4

## GSR14Q4/5

80C93	BLOWER - PURGE(80 100)	GSR14Q4/5
38F92	BLOWER-PURGE(80 100)	GSR14Q4/5
38G92	BLOWER-PURGE(80)	GSR14Q4/5
96C48	CAPACITOR(80 100)	GSR14Q4/5
81A39	CAPACITOR(80)	GSR14Q4/5
96C52	CAPACITOR-BLR MTR(80 100)	GSR14Q4/5
59C92	CAPACITOR-BLR MTR(80)	GSR14Q4/5
28G55	CONTROL-F&L(100)	GSR14Q4/5
78F11	CONTROL-F&L(80 100)	GSR14Q4/5
78F07	CONTROL-F&L(80)	GSR14Q4/5
28G45	CONTROL-LIMIT(80 100)	GSR14Q4/5
28G46	CONTROL-LIMIT(80 100)	GSR14Q4/5
58H59	CONTROL-LIMIT(80 100)	GSR14Q4/5
37A07	CONTROL-LIMIT(80)	GSR14Q4/5
60J00	CONTROL-PRIMARY(80 100)	GSR14Q4/5
99C97	CONTROL-PRIMARY(80 100)	GSR14Q4/5
32G05	DIAPHRAGM ASSY-AIR(100)	GSR14Q4/5
42G21	DIAPHRAGM ASSY-AIR(100)	GSR14Q4/5
84G25	DIAPHRAGM ASSY-AIR(100)	GSR14Q4/5
20H60	DIAPHRAGM ASSY-AIR(80)	GSR14Q4/5
84G24	DIAPHRAGM ASSY-AIR(80)	GSR14Q4/5
34G83	DIAPHRAGM ASSY-GAS(80 100)	GSR14Q4/5
LB-59742DA	DIAPHRAGM(100)	GSR14Q4/5
35H96	LEAD(80 100)	GSR14Q4/5
39G08	LEAD(80 100)	GSR14Q4/5
39G09	LEAD(80 100)	GSR14Q4/5
39G10	LEAD-IGNITION(80 100)	GSR14Q4/5
85H36	LEAD-IGNITION(80 100)	GSR14Q4/5
28F01	MOTOR-BLOWER(80 100)	GSR14Q4/5
49C10	MOTOR-BLOWER(80 100)	GSR14Q4/5
15B45	MOTOR-BLOWER(80)	GSR14Q4/5
79A52	MOTOR-BLOWER(80)	GSR14Q4/5
37G75	ORIFICE(100)	GSR14Q4/5
76G29	ORIFICE(100)	GSR14Q4/5
44H14	ORIFICE(80)	GSR14Q4/5
37G83	ORIFICE-BURNER(100)	GSR14Q4/5
37G84	ORIFICE-BURNER(100)	GSR14Q4/5
47H67	ORIFICE-BURNER(100)	GSR14Q4/5
LB-51	ORIFICE-BURNER(100)	GSR14Q4/5
37G85	ORIFICE-BURNER(80)	GSR14Q4/5
37G88	ORIFICE-BURNER(80)	GSR14Q4/5
60G08	ORIFICE-BURNER(80)	GSR14Q4/5
60G09	ORIFICE-BURNER(80)	GSR14Q4/5
64K60	PLUG - SENSOR(80 100)	GSR14Q4/5
39G06	PLUG-SPARK(80 100)	GSR14Q4/5
13H44	RELAY(80 100)	GSR14Q4/5
59C70	RELAY(80 100)	GSR14Q4/5

59C71	RELAY(80 100)	GSR14Q4/5
66C67	RELAY(80 100)	GSR14Q4/5
28G13	SWITCH(80 100)	GSR14Q4/5
43G88	SWITCH(80 100)	GSR14Q4/5
58H32	SWITCH-PRESS(100)	GSR14Q4/5
58H31	SWITCH-PRESS(80 100)	GSR14Q4/5
38631	TRANSFORMER(80 100)	GSR14Q4/5
65G46	TRANSFORMER(80 100)	GSR14Q4/5
96C79	TRANSFORMER(80 100)	GSR14Q4/5
LB-49995CA	VALVE-AIR(100)	GSR14Q4/5
28G14	VALVE-GAS(80 100)	GSR14Q4/5
51H25	VALVE-GAS(80 100)	GSR14Q4/5
51H60	VALVE-GAS(80)	GSR14Q4/5
54G08	VALVE-GAS(80)	GSR14Q4/5
54G55	VALVE-GAS(80)	GSR14Q4/5
87A62	WHEEL-BLOWER(80 100)	GSR14Q4/5
P-8-10471	WHEEL-BLOWER(80)	GSR14Q4/5

### GSR21

80C93	BLOWER - PURGE(80 50 100)	GSR21
38F92	BLOWER-PURGE(80 50 100)	GSR21
39H89	CAPACITOR(50)	GSR21
39H58	CAPACITOR(80 100)	GSR21
81A39	CAPACITOR(80 50)	GSR21
96C52	CAPACITOR-BLR MTR(80 100)	GSR21
59C92	CAPACITOR-BLR MTR(80 50)	GSR21
96C77	CARRIER-FUSE(80 50 100)	GSR21
51K46	CONTROL(80 50 100)	GSR21
74H68	CONTROL-F&L(80 100)	GSR21
78F11	CONTROL-F&L(80 100)	GSR21
74H67	CONTROL-F&L(80 50)	GSR21
78F07	CONTROL-F&L(80 50)	GSR21
28G45	CONTROL-LIMIT(80 50 100)	GSR21
28G46	CONTROL-LIMIT(80 50 100)	GSR21
58H59	CONTROL-LIMIT(80 50 100)	GSR21
52J18	CONTROL-PRIMARY(80 50 100)	GSR21
60J00	CONTROL-PRIMARY(80 50 100)	GSR21
73K86	CONTROL-PRIMARY(80 50 100)	GSR21
20H86	DECOUPLER-GAS(80 50 100)	GSR21
73H95	DIAPHRAGM ASSY-AIR(100)	GSR21
73H98	DIAPHRAGM ASSY-AIR(100)	GSR21
84G25	DIAPHRAGM ASSY-AIR(100)	GSR21
73H99	DIAPHRAGM ASSY-AIR(50)	GSR21
84G24	DIAPHRAGM ASSY-AIR(80 50)	GSR21
74H00	DIAPHRAGM ASSY-AIR(80)	GSR21
34G83	DIAPHRAGM ASSY-GAS(80 50 100)	GSR21
LB-59742DA	DIAPHRAGM(100)	GSR21
59436	FILTER(80 50 100)	GSR21
67171	FUSE(80 50 100)	GSR21
32F24	FUSE(80 50 100)	GSR21

96C78	FUSE(80 50 100)	GSR21
LB-83611B	KIT-BLOWER(80 50 100)	GSR21
35H96	LEAD(80 50 100)	GSR21
39G09	LEAD(80 50 100)	GSR21
48K51	LEAD(80 50 100)	GSR21
84H95	LEAD-IGNITION(80 50 100)	GSR21
45H32	MOTOR-BLOWER(50)	GSR21
67F15	MOTOR-BLOWER(50)	GSR21
28F01	MOTOR-BLOWER(80 100)	GSR21
45H33	MOTOR-BLOWER(80 100)	GSR21
49C10	MOTOR-BLOWER(80 100)	GSR21
15B45	MOTOR-BLOWER(80 50)	GSR21
45H31	MOTOR-BLOWER(80 50)	GSR21
79A52	MOTOR-BLOWER(80 50)	GSR21
37G75	ORIFICE(100)	GSR21
76G29	ORIFICE(100)	GSR21
44H14	ORIFICE(80)	GSR21
37G84	ORIFICE-BURNER(100)	GSR21
47H67	ORIFICE-BURNER(100)	GSR21
47H66	ORIFICE-BURNER(50)	GSR21
60G07	ORIFICE-BURNER(50)	GSR21
60G09	ORIFICE-BURNER(80)	GSR21
43G62	PLUG - IGNITION(80 50 100)	GSR21
64K60	PLUG - SENSOR(80 50 100)	GSR21
13H43	PLUG(50)	GSR21
59C70	RELAY(80 50 100)	GSR21
59C71	RELAY(80 50 100)	GSR21
66C67	RELAY(80 50 100)	GSR21
28G13	SWITCH(80 50 100)	GSR21
43G88	SWITCH(80 50 100)	GSR21
12L82	SWITCH-PRESS(100)	GSR21
58H32	SWITCH-PRESS(100)	GSR21
12L81	SWITCH-PRESS(80 50)	GSR21
58H31	SWITCH-PRESS(80 50)	GSR21
38631	TRANSFORMER(80 50 100)	GSR21
78H55	TRANSFORMER(80 50 100)	GSR21
LB-49995CA	VALVE-AIR(100)	GSR21
28G14	VALVE-GAS(80 50 100)	GSR21
51H25	VALVE-GAS(80 50 100)	GSR21
51H60	VALVE-GAS(80 50)	GSR21
54G08	VALVE-GAS(80 50)	GSR21
54G55	VALVE-GAS(80 50)	GSR21
21708	WHEEL-BLOWER(50)	GSR21
87A62	WHEEL-BLOWER(80 100)	GSR21
16596	WHEEL-BLOWER(80 50)	GSR21

### **GSR21CV5**

80C93	BLOWER - PURGE(80 100)	GSR21CV5
54J66	BOARD(80 100)	GSR21CV5

56J62	BOARD-CIRCUIT(80 100)	GSR21CV5
74H68	CONTROL-F&L(80 100)	GSR21CV5
58H59	CONTROL-LIMIT(80 100)	GSR21CV5
52J18	CONTROL-PRIMARY(80 100)	GSR21CV5
60J00	CONTROL-PRIMARY(80 100)	GSR21CV5
73K86	CONTROL-PRIMARY(80 100)	GSR21CV5
73H96	DIAPHRAGM ASSY-AIR(100)	GSR21CV5
84G25	DIAPHRAGM ASSY-AIR(100)	GSR21CV5
74H00	DIAPHRAGM ASSY-AIR(80)	GSR21CV5
84G24	DIAPHRAGM ASSY-AIR(80)	GSR21CV5
34G83	DIAPHRAGM ASSY-GAS(80 100)	GSR21CV5
48K51	LEAD(80 100)	GSR21CV5
84H95	LEAD-IGNITION(80 100)	GSR21CV5
66K54	MODULE-CONTROL(80 100)	GSR21CV5
69H14	MOTOR-BLOWER(80 100)	GSR21CV5
69J87	MOTOR-BLOWER(80 100)	GSR21CV5
44H14	ORIFICE(80)	GSR21CV5
47H67	ORIFICE-BURNER(100)	GSR21CV5
LB-56	ORIFICE-BURNER(100)	GSR21CV5
60G09	ORIFICE-BURNER(80)	GSR21CV5
LB-58	ORIFICE-BURNER(80)	GSR21CV5
43G62	PLUG - IGNITION(80 100)	GSR21CV5
64K60	PLUG - SENSOR(80 100)	GSR21CV5
LB-66595A	PLUG(80 100)	GSR21CV5
LB-73731	PLUG(80 100)	GSR21CV5
LB-73732	PLUG(80 100)	GSR21CV5
LB-87656A	PLUG(80 100)	GSR21CV5
21J24	RELAY(80 100)	GSR21CV5
37H95	RELAY(80 100)	GSR21CV5
69J79	RELAY(80 100)	GSR21CV5
28G13	SWITCH(100)	GSR21CV5
LB-73762	SWITCH-INTERLOCK(80)	GSR21CV5
12L82	SWITCH-PRESS(100)	GSR21CV5
58H32	SWITCH-PRESS(100)	GSR21CV5
12L81	SWITCH-PRESS(80)	GSR21CV5
58H31	SWITCH-PRESS(80)	GSR21CV5
76C85	TIME DELAY(80 100)	GSR21CV5
54G52	TRANSFORMER(80 100)	GSR21CV5
65G46	TRANSFORMER(80 100)	GSR21CV5
51H60	VALVE-GAS(100)	GSR21CV5
54G08	VALVE-GAS(80)	GSR21CV5
95H11	VARISTOR(80 100)	GSR21CV5
10G44	WHEEL-BLOWER(80 100)	GSR21CV5

### **GSR21Q3**

80C93	BLOWER - PURGE(80 50)	GSR21Q3
38F92	BLOWER-PURGE(80 50)	GSR21Q3
39H89	CAPACITOR(50)	GSR21Q3
81A39	CAPACITOR(80 50)	GSR21Q3

39H58	CAPACITOR(80)	GSR21Q3
59C92	CAPACITOR-BLR MTR(80 50)	GSR21Q3
96C52	CAPACITOR-BLR MTR(80)	GSR21Q3
96C77	CARRIER-FUSE(80 50)	GSR21Q3
51K46	CONTROL(80 50)	GSR21Q3
74H67	CONTROL-F&L(80 50)	GSR21Q3
78F07	CONTROL-F&L(80 50)	GSR21Q3
74H68	CONTROL-F&L(80)	GSR21Q3
78F11	CONTROL-F&L(80)	GSR21Q3
28G45	CONTROL-LIMIT(80 50)	GSR21Q3
28G46	CONTROL-LIMIT(80 50)	GSR21Q3
58H59	CONTROL-LIMIT(80 50)	GSR21Q3
52J18	CONTROL-PRIMARY(80 50)	GSR21Q3
60J00	CONTROL-PRIMARY(80 50)	GSR21Q3
73K86	CONTROL-PRIMARY(80 50)	GSR21Q3
73H99	DIAPHRAGM ASSY-AIR(50)	GSR21Q3
84G24	DIAPHRAGM ASSY-AIR(80 50)	GSR21Q3
74H00	DIAPHRAGM ASSY-AIR(80)	GSR21Q3
34G83	DIAPHRAGM ASSY-GAS(80 50)	GSR21Q3
59436	FILTER(80 50)	GSR21Q3
18L13	FITTING-BARB(80 50)	GSR21Q3
67171	FUSE(80 50)	GSR21Q3
32F24	FUSE(80 50)	GSR21Q3
96C78	FUSE(80 50)	GSR21Q3
96C76	HOLDER-FUSE(80 50)	GSR21Q3
84H22	HOUSING-AIR DIAPH(80 50)	GSR21Q3
LB-83611B	KIT-BLOWER(80 50)	GSR21Q3
35H96	LEAD(80 50)	GSR21Q3
39G09	LEAD(80 50)	GSR21Q3
48K51	LEAD(80 50)	GSR21Q3
84H95	LEAD-IGNITION(80 50)	GSR21Q3
45H32	MOTOR-BLOWER(50)	GSR21Q3
67F15	MOTOR-BLOWER(50)	GSR21Q3
15B45	MOTOR-BLOWER(80 50)	GSR21Q3
45H31	MOTOR-BLOWER(80 50)	GSR21Q3
79A52	MOTOR-BLOWER(80 50)	GSR21Q3
28F01	MOTOR-BLOWER(80)	GSR21Q3
45H33	MOTOR-BLOWER(80)	GSR21Q3
49C10	MOTOR-BLOWER(80)	GSR21Q3
LB-35721D	MOUNT-MOTOR(50)	GSR21Q3
44H14	ORIFICE(80)	GSR21Q3
47H66	ORIFICE-BURNER(50)	GSR21Q3
60G07	ORIFICE-BURNER(50)	GSR21Q3
60G09	ORIFICE-BURNER(80)	GSR21Q3
43G62	PLUG - IGNITION(80 50)	GSR21Q3
64K60	PLUG - SENSOR(80 50)	GSR21Q3
13H43	PLUG(50)	GSR21Q3
59C70	RELAY(80 50)	GSR21Q3
59C71	RELAY(80 50)	GSR21Q3
66C67	RELAY(80 50)	GSR21Q3
14J67	SCREW(80 50)	GSR21Q3



40G04	SEAL(80 50)	GSR21Q3
28G13	SWITCH(80 50)	GSR21Q3
43G88	SWITCH(80 50)	GSR21Q3
12L81	SWITCH-PRESS(80 50)	GSR21Q3
58H31	SWITCH-PRESS(80 50)	GSR21Q3
38631	TRANSFORMER(80 50)	GSR21Q3
78H55	TRANSFORMER(80 50)	GSR21Q3
28G14	VALVE-GAS(80 50)	GSR21Q3
51H25	VALVE-GAS(80 50)	GSR21Q3
51H60	VALVE-GAS(80 50)	GSR21Q3
54G08	VALVE-GAS(80 50)	GSR21Q3
54G55	VALVE-GAS(80 50)	GSR21Q3
21708	WHEEL-BLOWER(50)	GSR21Q3
16596	WHEEL-BLOWER(80 50)	GSR21Q3
87A62	WHEEL-BLOWER(80)	GSR21Q3

### **GSR21Q4**

80C93	BLOWER - PURGE(50)	GSR21Q4
38F92	BLOWER-PURGE(50)	GSR21Q4
39H89	CAPACITOR(50)	GSR21Q4
81A39	CAPACITOR(50)	GSR21Q4
59C92	CAPACITOR-BLR MTR(50)	GSR21Q4
96C77	CARRIER-FUSE(50)	GSR21Q4
51K46	CONTROL(50)	GSR21Q4
74H67	CONTROL-F&L(50)	GSR21Q4
78F07	CONTROL-F&L(50)	GSR21Q4
28G45	CONTROL-LIMIT(50)	GSR21Q4
28G46	CONTROL-LIMIT(50)	GSR21Q4
58H59	CONTROL-LIMIT(50)	GSR21Q4
52J18	CONTROL-PRIMARY(50)	GSR21Q4
60J00	CONTROL-PRIMARY(50)	GSR21Q4
73K86	CONTROL-PRIMARY(50)	GSR21Q4
73H99	DIAPHRAGM ASSY-AIR(50)	GSR21Q4
84G24	DIAPHRAGM ASSY-AIR(50)	GSR21Q4
34G83	DIAPHRAGM ASSY-GAS(50)	GSR21Q4
59436	FILTER(50)	GSR21Q4
67171	FUSE(50)	GSR21Q4
32F24	FUSE(50)	GSR21Q4
96C78	FUSE(50)	GSR21Q4
14F39	GASKET(50)	GSR21Q4
28G81	GROMMET(50)	GSR21Q4
33G67	GROMMET(50)	GSR21Q4
72G62	GROMMET(50)	GSR21Q4
LB-83611B	KIT-BLOWER(50)	GSR21Q4
74K96	KIT-HT EXCH(50)	GSR21Q4
35H96	LEAD(50)	GSR21Q4
39G09	LEAD(50)	GSR21Q4
48K51	LEAD(50)	GSR21Q4
84H95	LEAD-IGNITION(50)	GSR21Q4
15B45	MOTOR-BLOWER(50)	GSR21Q4

45H31	MOTOR-BLOWER(50)	GSR21Q4
45H32	MOTOR-BLOWER(50)	GSR21Q4
67F15	MOTOR-BLOWER(50)	GSR21Q4
79A52	MOTOR-BLOWER(50)	GSR21Q4
47H66	ORIFICE-BURNER(50)	GSR21Q4
60G07	ORIFICE-BURNER(50)	GSR21Q4
43G62	PLUG - IGNITION(50)	GSR21Q4
64K60	PLUG - SENSOR(50)	GSR21Q4
13H43	PLUG(50)	GSR21Q4
59C70	RELAY(50)	GSR21Q4
59C71	RELAY(50)	GSR21Q4
66C67	RELAY(50)	GSR21Q4
28G13	SWITCH(50)	GSR21Q4
43G88	SWITCH(50)	GSR21Q4
12L81	SWITCH-PRESS(50)	GSR21Q4
58H31	SWITCH-PRESS(50)	GSR21Q4
38631	TRANSFORMER(50)	GSR21Q4
78H55	TRANSFORMER(50)	GSR21Q4
28G14	VALVE-GAS(50)	GSR21Q4
51H25	VALVE-GAS(50)	GSR21Q4
51H60	VALVE-GAS(50)	GSR21Q4
54G08	VALVE-GAS(50)	GSR21Q4
54G55	VALVE-GAS(50)	GSR21Q4
16596	WHEEL-BLOWER(50)	GSR21Q4
21708	WHEEL-BLOWER(50)	GSR21Q4

### **GSR21Q4/5**

80C93	BLOWER - PURGE(80 100)	GSR21Q4/5
38F92	BLOWER-PURGE(80 100)	GSR21Q4/5
39H58	CAPACITOR(80 100)	GSR21Q4/5
81A39	CAPACITOR(80)	GSR21Q4/5
96C52	CAPACITOR-BLR MTR(80 100)	GSR21Q4/5
59C92	CAPACITOR-BLR MTR(80)	GSR21Q4/5
96C77	CARRIER-FUSE(80 100)	GSR21Q4/5
51K46	CONTROL(80 100)	GSR21Q4/5
74H68	CONTROL-F&L(80 100)	GSR21Q4/5
78F11	CONTROL-F&L(80 100)	GSR21Q4/5
74H67	CONTROL-F&L(80)	GSR21Q4/5
78F07	CONTROL-F&L(80)	GSR21Q4/5
28G45	CONTROL-LIMIT(80 100)	GSR21Q4/5
28G46	CONTROL-LIMIT(80 100)	GSR21Q4/5
58H59	CONTROL-LIMIT(80 100)	GSR21Q4/5
52J18	CONTROL-PRIMARY(80 100)	GSR21Q4/5
60J00	CONTROL-PRIMARY(80 100)	GSR21Q4/5
73K86	CONTROL-PRIMARY(80 100)	GSR21Q4/5
73H95	DIAPHRAGM ASSY-AIR(100)	GSR21Q4/5
73H98	DIAPHRAGM ASSY-AIR(100)	GSR21Q4/5
84G25	DIAPHRAGM ASSY-AIR(100)	GSR21Q4/5
74H00	DIAPHRAGM ASSY-AIR(80)	GSR21Q4/5

84G24	DIAPHRAGM ASSY-AIR(80)	GSR21Q4/5
34G83	DIAPHRAGM ASSY-GAS(80 100)	GSR21Q4/5
LB-59742DA	DIAPHRAGM(100)	GSR21Q4/5
59436	FILTER(80 100)	GSR21Q4/5
67171	FUSE(80 100)	GSR21Q4/5
32F24	FUSE(80 100)	GSR21Q4/5
96C78	FUSE(80 100)	GSR21Q4/5
17J64	HOUSING-AIR DIAPH(100)	GSR21Q4/5
84H22	HOUSING-AIR DIAPH(80)	GSR21Q4/5
35H96	LEAD(80 100)	GSR21Q4/5
39G09	LEAD(80 100)	GSR21Q4/5
48K51	LEAD(80 100)	GSR21Q4/5
84H95	LEAD-IGNITION(80 100)	GSR21Q4/5
28F01	MOTOR-BLOWER(80 100)	GSR21Q4/5
45H33	MOTOR-BLOWER(80 100)	GSR21Q4/5
49C10	MOTOR-BLOWER(80 100)	GSR21Q4/5
15B45	MOTOR-BLOWER(80)	GSR21Q4/5
45H31	MOTOR-BLOWER(80)	GSR21Q4/5
79A52	MOTOR-BLOWER(80)	GSR21Q4/5
37G75	ORIFICE(100)	GSR21Q4/5
76G29	ORIFICE(100)	GSR21Q4/5
44H14	ORIFICE(80)	GSR21Q4/5
37G84	ORIFICE-BURNER(100)	GSR21Q4/5
47H67	ORIFICE-BURNER(100)	GSR21Q4/5
60G09	ORIFICE-BURNER(80)	GSR21Q4/5
43G62	PLUG - IGNITION(80 100)	GSR21Q4/5
64K60	PLUG - SENSOR(80 100)	GSR21Q4/5
59C70	RELAY(80 100)	GSR21Q4/5
59C71	RELAY(80 100)	GSR21Q4/5
66C67	RELAY(80 100)	GSR21Q4/5
28G13	SWITCH(80 100)	GSR21Q4/5
43G88	SWITCH(80 100)	GSR21Q4/5
12L82	SWITCH-PRESS(100)	GSR21Q4/5
58H32	SWITCH-PRESS(100)	GSR21Q4/5
12L81	SWITCH-PRESS(80)	GSR21Q4/5
58H31	SWITCH-PRESS(80)	GSR21Q4/5
38631	TRANSFORMER(80 100)	GSR21Q4/5
78H55	TRANSFORMER(80 100)	GSR21Q4/5
LB-49995CA	VALVE-AIR(100)	GSR21Q4/5
28G14	VALVE-GAS(80 100)	GSR21Q4/5
51H25	VALVE-GAS(80 100)	GSR21Q4/5
51H60	VALVE-GAS(80)	GSR21Q4/5
54G08	VALVE-GAS(80)	GSR21Q4/5
54G55	VALVE-GAS(80)	GSR21Q4/5
87A62	WHEEL-BLOWER(80 100)	GSR21Q4/5
16596	WHEEL-BLOWER(80)	GSR21Q4/5
LB-83611B	KIT-BLOWER(80 100)	GSR21Q4/5

### GSR21V

80C93 BLOWER - PURGE(80 100)

GSR21V

56J65	BOARD-CIRCUIT(80 100)	GSR21V
68H13	BOARD-CIRCUIT(80 100)	GSR21V
69H12	CHOKE-POWER(80 100)	GSR21V
72H49	CONTROL-F&L(100)	GSR21V
72H47	CONTROL-F&L(80)	GSR21V
72H48	CONTROL-F&L(80)	GSR21V
28G45	CONTROL-LIMIT(80 100)	GSR21V
28G46	CONTROL-LIMIT(80 100)	GSR21V
58H59	CONTROL-LIMIT(80 100)	GSR21V
52J18	CONTROL-PRIMARY(80 100)	GSR21V
60J00	CONTROL-PRIMARY(80 100)	GSR21V
73K86	CONTROL-PRIMARY(80 100)	GSR21V
73H95	DIAPHRAGM ASSY-AIR(100)	GSR21V
73H98	DIAPHRAGM ASSY-AIR(100)	GSR21V
84G25	DIAPHRAGM ASSY-AIR(100)	GSR21V
74H00	DIAPHRAGM ASSY-AIR(80)	GSR21V
84G24	DIAPHRAGM ASSY-AIR(80)	GSR21V
34G83	DIAPHRAGM ASSY-GAS(80 100)	GSR21V
LB-59742DA	DIAPHRAGM(100)	GSR21V
59436	FILTER(80 100)	GSR21V
74H08	FUSE(80 100)	GSR21V
LB-83611B	KIT-BLOWER(80 100)	GSR21V
48K51	LEAD(80 100)	GSR21V
84H95	LEAD-IGNITION(80 100)	GSR21V
66K54	MODULE-CONTROL(80 100)	GSR21V
66K53	MODULE-CONTROL(80)	GSR21V
LB-97045D	MODULE-CONTROL(80)	GSR21V
69H14	MOTOR-BLOWER(80 100)	GSR21V
69J87	MOTOR-BLOWER(80 100)	GSR21V
53J80	MOTOR-BLOWER(80)	GSR21V
69H15	MOTOR-BLOWER(80)	GSR21V
37G75	ORIFICE(100)	GSR21V
76G29	ORIFICE(100)	GSR21V
44H14	ORIFICE(80)	GSR21V
37G84	ORIFICE-BURNER(100)	GSR21V
47H67	ORIFICE-BURNER(100)	GSR21V
60G09	ORIFICE-BURNER(80)	GSR21V
43G62	PLUG - IGNITION(80 100)	GSR21V
64K60	PLUG - SENSOR(80 100)	GSR21V
25J38	RELAY(80 100)	GSR21V
28G13	SWITCH(80 100)	GSR21V
58H32	SWITCH-PRESS(100)	GSR21V
12L82	SWITCH-PRESS(80 100)	GSR21V
58H31	SWITCH-PRESS(80)	GSR21V
72H94	TRANSFORMER(80 100)	GSR21V
LB-49995CA	VALVE-AIR(100)	GSR21V
28G14	VALVE-GAS(100)	GSR21V
54G08	VALVE-GAS(80)	GSR21V
10G44	WHEEL-BLOWER(80 100)	GSR21V
21708	WHEEL-BLOWER(80)	GSR21V

## GSR21V3

80C93	BLOWER - PURGE(80)	GSR21V3
56J65	BOARD-CIRCUIT(80)	GSR21V3
68H13	BOARD-CIRCUIT(80)	GSR21V3
69H12	CHOKE-POWER(80)	GSR21V3
72H47	CONTROL-F&L(80)	GSR21V3
72H48	CONTROL-F&L(80)	GSR21V3
28G45	CONTROL-LIMIT(80)	GSR21V3
28G46	CONTROL-LIMIT(80)	GSR21V3
58H59	CONTROL-LIMIT(80)	GSR21V3
52J18	CONTROL-PRIMARY(80)	GSR21V3
60J00	CONTROL-PRIMARY(80)	GSR21V3
73K86	CONTROL-PRIMARY(80)	GSR21V3
74H00	DIAPHRAGM ASSY-AIR(80)	GSR21V3
84G24	DIAPHRAGM ASSY-AIR(80)	GSR21V3
34G83	DIAPHRAGM ASSY-GAS(80)	GSR21V3
59436	FILTER(80)	GSR21V3
74H08	FUSE(80)	GSR21V3
LB-83611B	KIT-BLOWER(80)	GSR21V3
48K51	LEAD(80)	GSR21V3
84H95	LEAD-IGNITION(80)	GSR21V3
66K53	MODULE-CONTROL(80)	GSR21V3
66K54	MODULE-CONTROL(80)	GSR21V3
LB-97045D	MODULE-CONTROL(80)	GSR21V3
53J80	MOTOR-BLOWER(80)	GSR21V3
69H14	MOTOR-BLOWER(80)	GSR21V3
69H15	MOTOR-BLOWER(80)	GSR21V3
69J87	MOTOR-BLOWER(80)	GSR21V3
98G23	MOUNT-MOTOR(80)	GSR21V3
44H14	ORIFICE(80)	GSR21V3
60G09	ORIFICE-BURNER(80)	GSR21V3
28G13	SWITCH(80)	GSR21V3
12L82	SWITCH-PRESS(80)	GSR21V3
58H31	SWITCH-PRESS(80)	GSR21V3
72H94	TRANSFORMER(80)	GSR21V3
54G08	VALVE-GAS(80)	GSR21V3
21708	WHEEL-BLOWER(80)	GSR21V3
10G44	WHEEL-BLOWER(80)	GSR21V3

## GSR21V5

80C93	BLOWER - PURGE(80 100)	GSR21V5
56J65	BOARD-CIRCUIT(80 100)	GSR21V5
68H13	BOARD-CIRCUIT(80 100)	GSR21V5
69H12	CHOKE-POWER(80 100)	GSR21V5
72H49	CONTROL-F&L(100)	GSR21V5
72H47	CONTROL-F&L(80)	GSR21V5
72H48	CONTROL-F&L(80)	GSR21V5

28G45	CONTROL-LIMIT(80 100)	GSR21V5
28G46	CONTROL-LIMIT(80 100)	GSR21V5
58H59	CONTROL-LIMIT(80 100)	GSR21V5
52J18	CONTROL-PRIMARY(80 100)	GSR21V5
60J00	CONTROL-PRIMARY(80 100)	GSR21V5
73K86	CONTROL-PRIMARY(80 100)	GSR21V5
73H95	DIAPHRAGM ASSY-AIR(100)	GSR21V5
73H98	DIAPHRAGM ASSY-AIR(100)	GSR21V5
84G25	DIAPHRAGM ASSY-AIR(100)	GSR21V5
74H00	DIAPHRAGM ASSY-AIR(80)	GSR21V5
84G24	DIAPHRAGM ASSY-AIR(80)	GSR21V5
34G83	DIAPHRAGM ASSY-GAS(80 100)	GSR21V5
LB-59742DA	DIAPHRAGM(100)	GSR21V5
59436	FILTER(80 100)	GSR21V5
LB-83	KIT-BLOWER(80 100)	GSR21V5
48K51	LEAD(80 100)	GSR21V5
84H95	LEAD-IGNITION(80 100)	GSR21V5
66K54	MODULE-CONTROL(80 100)	GSR21V5
66K53	MODULE-CONTROL(80)	GSR21V5
LB-97	MODULE-CONTROL(80)	GSR21V5
69H14	MOTOR-BLOWER(80 100)	GSR21V5
69J87	MOTOR-BLOWER(80 100)	GSR21V5
53J80	MOTOR-BLOWER(80)	GSR21V5
69H15	MOTOR-BLOWER(80)	GSR21V5
37G75	ORIFICE(100)	GSR21V5
76G29	ORIFICE(100)	GSR21V5
44H14	ORIFICE(80)	GSR21V5
37G84	ORIFICE-BURNER(100)	GSR21V5
47H67	ORIFICE-BURNER(100)	GSR21V5
60G09	ORIFICE-BURNER(80)	GSR21V5
64K60	PLUG - SENSOR(80 100)	GSR21V5
25J38	RELAY(80 100)	GSR21V5
35G42	SCREW(80 100)	GSR21V5
40G04	SEAL(80 100)	GSR21V5
38538	STRIP TERMINAL(80 100)	GSR21V5
69J66	STRIP-TERMINAL(80 100)	GSR21V5
72H95	STRIP-TERMINAL(80 100)	GSR21V5
28G13	SWITCH(80 100)	GSR21V5
58H32	SWITCH-PRESS(100)	GSR21V5
12L82	SWITCH-PRESS(80 100)	GSR21V5
58H31	SWITCH-PRESS(80)	GSR21V5
72H94	TRANSFORMER(80 100)	GSR21V5
LB-49995CA	VALVE-AIR(100)	GSR21V5
28G14	VALVE-GAS(100)	GSR21V5
54G08	VALVE-GAS(80)	GSR21V5
10G44	WHEEL-BLOWER(80 100)	GSR21V5
21708	WHEEL-BLOWER(80)	GSR21V5

## HM30

84K53	BLOWER-COMB AIR(150P 150 100P 100)	HM30
93K98	BLOWER-COMB AIR(150P 150 100P 100)	HM30
37J56	BREAKER-CIRC(150P 150 100P 100)	HM30
84K51	BURNER(150P 150 100P 100)	HM30
84K52	BURNER(150P 150 100P 100)	HM30
94K75	BURNER(150P 150 100P 100)	HM30
60F40	BUSHING(150P 150 100P 100)	HM30
14K70	CAPACITOR(150P 150 100P 100)	HM30
73J96	CAPACITOR(150P 150 100P 100)	HM30
66J78	CONTROL-LIMIT(150P 150 100P 100)	HM30
93J39	CONTROL-LIMIT(150P 150 100P 100)	HM30
27L41	ELECTRODE(150P 150 100P 100)	HM30
28L90	FILTER-CARTRIDGE(150P 150 100P 100)	HM30
45L91	GAS VALVE KIT REPL(150P 150 100P 100)	HM30
32L63	GAS VALVE(150P 150 100P 100)	HM30
28L82	INTAKE AIR FILTER(150P 150 100P 100)	HM30
89K33	KIT-AIR INTAKE DRAIN(150P 150 100P 100)	HM30
73J78	KIT-CARTRIDGE(150P 150 100P 100)	HM30
LB-74432A	KIT-EXP TANK & VALVE(150P 150 100P 100)	HM30
90J03	KIT-INTERFACE(150P 150 100P 100)	HM30
59K21	MODULE(150P 150 100P 100)	HM30
62K35	MODULE(150P 150 100P 100)	HM30
85K82	MODULE(150P 150 100P 100)	HM30
89K24	MODULE(150P 150 100P 100)	HM30
54K70	NOISE KIT(150P 150 100P 100)	HM30
11K59	ORIFICE- IN LINE GAS(150P 150 100P 100)	HM30
26L76	ORIFICE- IN LINE GAS(150P 150 100P 100)	HM30
94K82	ORIFICE- IN LINE GAS(150P 150 100P 100)	HM30
94K83	ORIFICE- IN LINE GAS(150P 150 100P 100)	HM30
13K73	ORIFICE IN LINE(150P 150 100P 100)	HM30
26L75	ORIFICE(150P 150 100P 100)	HM30
57J16	ORIFICE-AIR(150P 150 100P 100)	HM30
57J17	ORIFICE-AIR(150P 150 100P 100)	HM30
69J82	PLUG(150P 150 100P 100)	HM30
38M33	PUMP(150P 150 100P 100)	HM30
39M16	PUMP(150P 150 100P 100)	HM30
99K68	PUMP(150P 150 100P 100)	HM30
68119	RELAY(150P 150 100P 100)	HM30
57J76	SEAL(150P 150 100P 100)	HM30
85K74	SWITCH(150P 150 100P 100)	HM30
57J01	SWITCH-PRESS(150P 150 100P 100)	HM30
37K63	THERMISTOR(150P 150 100P 100)	HM30
38512	TRANSFORMER(150P 150 100P 100)	HM30
42J32	TRANSFORMER(150P 150 100P 100)	HM30
56L48	VALVE(150P 150 100P 100)	HM30
57J10	VALVE(150P 150 100P 100)	HM30
57J11	VALVE(150P 150 100P 100)	HM30
57J24	VALVE(150P 150 100P 100)	HM30

67K57	VALVE(150P 150 100P 100)	HM30
31194	VALVE-GAS(150P 150 100P 100)	HM30
69J22	VALVE-GAS(150P 150 100P 100)	HM30
29K49	VENT-AIR BLEED(150P 150 100P 100)	HM30
29K50	VENT-AIR BLEED(150P 150 100P 100)	HM30

### HM61

51M88	BLOWER-COMB AIR(150P 150 100P 100)	HM61
51M90	BLOWER-COMB AIR(150P 150 100P 100)	HM61
51M95	BOARD(150P 150 100P 100)	HM61
51M82	BURNER(150P 150 100P 100)	HM61
51M6	CONTROL(150P 150 100P 100)	HM61
60M27	CONTROL(150P 150 100P 100)	HM61
51M85	CONTROL-LIMIT(150P 150 100P 100)	HM61
51M93	IGNITOR(150P 150 100P 100)	HM61
56M02	POTENTIOMETER(150P 150 100P 100)	HM61
56M82	PRIORISTAT(150P 150 100P 100)	HM61
60M25	RELAY(150P 150 100P 100)	HM61
51M86	SWITCH-PRESS(150P 150 100P 100)	HM61
51M87	SWITCH-PRESS(150P 150 100P 100)	HM61
51M97	TRANSFORMER(150P 150 100P 100)	HM61
51M99	VALVE(150P 150 100P 100)	HM61
56M00	VALVE(150P 150 100P 100)	HM61
51M94	VALVE-GAS(150P 150 100P 100)	HM61

### LF24

60905	BLADE-FAN(75S 75A 50S 50A)	LF24
19J04	BLOWER ASSY(150S 150A 125S 125A 100S 100A)	LF24
88J38	BLOWER ASSY(400S 400A 345S 345A)	LF24
43K30	BLOWER ASSY(75S 75A 50S 50A 145S 145A 115S 115A)	LF24
90H86	BLOWER ASSY(75S 75A 50S 50A)	LF24
27K61	BLOWER ASSY(75S 75A 60A 45A 30A)	LF24
20J89	R-IND DRAFT(300S 300A 250S 250A 230S 230A 200S 200A 175	LF24
43K49	A 60A 50S 50A 45A 400S 400A 345S 345A 30A 300S 300A 250	LF24
23L53	OL(75A 60A 45A 400S 400A 345S 345A 30A 300S 300A 250S 2	LF24
20J87	BURNER-INSHOT(75S 75A 50S 50A)	LF24
17J58	400S 400A 345S 345A 300S 300A 250S 250A 230S 230A 200S	LF24
74M42	BURNER-MAIN(50S 50A)	LF24
27K66	BURNER-MAIN(75S 75A 60A 45A 30A)	LF24
74M43	BURNER-MAIN(75S 75A)	LF24
53H02	CAPACITOR-MOTOR(175S 175A 145S 145A 115S 115A)	LF24
97H03	75S 75A 50S 50A 300S 300A 250S 250A 200S 200A 150S 150A	LF24
10J58	75S 75A 50S 50A 300S 300A 250S 250A 200S 200A 150S 150A	LF24
19J81	ROL-LIMIT(200S 200A 150S 150A 125S 125A 115S 115A 100S	LF24
20J98	CONTROL-LIMIT(400S 400A 300S 300A 250S 250A 200S 200A)	LF24
20J99	IMIT(400S 400A 345S 345A 300S 300A 250S 250A 230S 230A	LF24
86H72	CONTROL-LIMIT(75S 75A 50S 50A 175S 175A)	LF24
18J28	CONTROL-LIMIT(75S 75A 50S 50A 345S 345A 230S 230A)	LF24



27K79	CONTROL-LIMIT(75S 75A 60A 45A 30A 145S 145A)	LF24
90H82	ELECTRODE(75S 75A 50S 50A)	LF24
20J90	ELECTRODE(75S 75A 60A 45A 30A)	LF24
17J57	S 75A 60A 50S 50A 45A 400S 400A 345S 345A 30A 300S 300A	LF24
33J23	KIT-REGULATOR(200S 200A)	LF24
43K65	DE(75S 75A 60A 50S 50A 45A 30A 200S 200A 175S 175A 150S	LF24
45J91	LEAD-IGNITION(150S 150A 125S 125A 100S 100A)	LF24
38J77	LEAD-IGNITION(300S 300A 250S 250A 200S 200A)	LF24
43K69	ION(400S 400A 345S 345A 300S 300A 250S 250A 230S 230A ;	LF24
20J85	LEAD-IGNITION(45A 30A)	LF24
10K42	LEAD-SENSOR(300S 300A 250S 250A 200S 200A)	LF24
43K27	LEAD-SENSOR(45A 30A)	LF24
79L59	75A 60A 45A 30A 200S 200A 175S 175A 150S 150A 145S 145A	LF24
10K41	AD-SENSOR(75S 75A 50S 50A 150S 150A 125S 125A 100S 100	LF24
32678	75S 75A 50S 50A 400S 400A 345S 345A 300S 300A 250S 250A	LF24
27K58	MOTOR-FAN(45A 30A)	LF24
33J39	MOTOR-FAN(75S 75A 60A 125S 125A 100S 100A)	LF24
71J30	MOUNT-MOTOR(75S 75A 50S 50A)	LF24
H0922	ORIFICE(75S 75A 50S 50A)	LF24
12L29	ORIFICE-BURNER(200S 200A)	LF24
17J72	E-BURNER(300S 300A 250S 250A 150S 150A 125S 125A 100S	LF24
56L59	E-BURNER(300S 300A 250S 250A 150S 150A 125S 125A 100S	LF24
79L55	E-BURNER(300S 300A 250S 250A 150S 150A 125S 125A 100S	LF24
41J81	RNER(300S 300A 250S 250A 200S 200A 150S 150A 125S 125A	LF24
H3721	RNER(300S 300A 250S 250A 200S 200A 150S 150A 125S 125A	LF24
56L55	E-BURNER(345S 345A 230S 230A 175S 175A 145S 145A 115S	LF24
79L53	E-BURNER(345S 345A 230S 230A 175S 175A 145S 145A 115S	LF24
33J76	ORIFICE-BURNER(345S 345A)	LF24
60J99	ORIFICE-BURNER(345S 345A)	LF24
56L57	ORIFICE-BURNER(400S 400A 200S 200A)	LF24
79L56	ORIFICE-BURNER(400S 400A 200S 200A)	LF24
85K36	ORIFICE-BURNER(400S 400A 200S 200A)	LF24
85K31	ORIFICE-BURNER(400S 400A)	LF24
56L56	ORIFICE-BURNER(75A 60A 50S 50A 45A 30A)	LF24
79L57	ORIFICE-BURNER(75A 60A 50S 50A 45A 30A)	LF24
17J71	ORIFICE-BURNER(75S 75A 50S 50A)	LF24
12K48	ORIFICE-BURNER(75S 75A 60A 45A 30A)	LF24
33J95	ORIFICE-BURNER(75S 75A 60A 45A 30A)	LF24
90H83	SENSOR-FLAME(75S 75A 50S 50A)	LF24
20J91	SENSOR-FLAME(75S 75A 60A 45A 30A)	LF24
17J56	E(75S 75A 60A 50S 50A 45A 400S 400A 345S 345A 30A 300S 300	LF24
43K47	SWITCH(45A 30A)	LF24
99K63	SWITCH(75S 75A 60A)	LF24
17J63	SWITCH-PRESS(150S 150A 125S 125A 100S 100A)	LF24
60J24	SWITCH-PRESS(200S 200A)	LF24
33J88	RESS(230S 230A 175S 175A 150S 150A 145S 145A 115S 115A 1	LF24
60J54	SWITCH-PRESS(300S 300A 250S 250A)	LF24
20J97	SWITCH-PRESS(345S 345A)	LF24
85K37	SWITCH-PRESS(400S 400A)	LF24
27K63	SWITCH-PRESS(60A 45A 30A)	LF24
10J59	SWITCH-PRESS(75S 75A 50S 50A)	LF24

43K57	SWITCH-PRESS(75S 75A 50S 50A)	LF24
60J47	SWITCH-PRESS(75S 75A)	LF24
26W76	SWITCH-PRESSURE(145S 145A 115S 115A)	LF24
34M76	SWITCH-PRESSURE(230S 230A 175S 175A)	LF24
78H55	(75S 75A 60A 50S 50A 45A 400S 400A 345S 345A 30A 300S 300A 25S 25A 230S 230A 20S 20A)	LF24
26L95	5A 60A 50S 50A 45A 400S 400A 345S 345A 30A 300S 300A 25S 25A 230S 230A 20S 20A	LF24
43L21	SSY(400S 400A 345S 345A 300S 300A 250S 250A 230S 230A 20S 20A)	LF24
21J00	VALVE-GAS(200S 200A)	LF24
20J96	VALVE-GAS(300S 300A 250S 250A 200S 200A)	LF24
60J91	VALVE-GAS(345S 345A 300S 300A 250S 250A 230S 230A 200S 200A)	LF24
60J92	VALVE-GAS(400S 400A 345S 345A 300S 300A 250S 250A 230S 230A 200S 200A)	LF24
85K35	VALVE-GAS(400S 400A)	LF24
10K54	VALVE-GAS(75S 75A 60A 45A 30A 200S 200A 175S 175A 150S 150A 145S 145A 115S 115A)	LF24
18M32	VALVE-GAS(75S 75A 60A 45A 30A)	LF24
25M72	VALVE-GAS(75S 75A 60A 45A 30A)	LF24
31L13	VALVE-GAS(75S 75A 60A 45A 30A)	LF24
60J59	VALVE-GAS(75S 75A 60A 45A 30A 200S 200A 175S 175A 150S 150A 145S 145A 115S 115A)	LF24
79L60	WIRE(400S 400A 345S 345A 300S 300A 250S 250A 230S 230A)	LF24

### ML180UH045P24A

28W59	BOX-CONTROL(01)	ML180UH045P24A
22W78	CAPACITOR-FAN(01)	ML180UH045P24A
17W70	CONTROL-IGN(01)	ML180UH045P24A
69M38	CONTROL-LIMIT(01)	ML180UH045P24A
LB-74940B	FLAME SENSOR(01)	ML180UH045P24A
68L52	HARNESS - WIRING(01)	ML180UH045P24A
57M86	HOUSING-BLOWER(01)	ML180UH045P24A
19W61	IGNITOR(01)	ML180UH045P24A
97M37	KIT-HARDWARE(01)	ML180UH045P24A
29M85	KIT-REGULATOR(01)	ML180UH045P24A
73W63	PANEL-BLOWER ACCESS(01)	ML180UH045P24A
73W62	PANEL-BURNER ACCESS(01)	ML180UH045P24A
81L89	PLATE-CUTOFF(01)	ML180UH045P24A
51W15	SWITCH(01)	ML180UH045P24A
51W92	SWITCH-PRESS(01)	ML180UH045P24A
25M60	SWITCH-ROLLOUT(01)	ML180UH045P24A
42J32	TRANSFORMER(01)	ML180UH045P24A
98L78	TUBING(01)	ML180UH045P24A
21709	WHEEL-BLOWER(01)	ML180UH045P24A
11M65	WIRE-FLAME SENSOR(01)	ML180UH045P24A

### ML180UH045P36A

28W59	BOX-CONTROL(01)	ML180UH045P36A
22W78	CAPACITOR-FAN(01)	ML180UH045P36A
17W70	CONTROL-IGN(01)	ML180UH045P36A
69M38	CONTROL-LIMIT(01)	ML180UH045P36A
LB-74940B	FLAME SENSOR(01)	ML180UH045P36A
68L52	HARNESS - WIRING(01)	ML180UH045P36A
57M87	HOUSING-BLOWER(01)	ML180UH045P36A

19W61	IGNITOR(01)	ML180UH045P36A
97M37	KIT-HARDWARE(01)	ML180UH045P36A
29M85	KIT-REGULATOR(01)	ML180UH045P36A
21W85	MOTOR-BLOWER(01)	ML180UH045P36A
73W63	PANEL-BLOWER ACCESS(01)	ML180UH045P36A
73W62	PANEL-BURNER ACCESS(01)	ML180UH045P36A
51W15	SWITCH(01)	ML180UH045P36A
51W92	SWITCH-PRESS(01)	ML180UH045P36A
25M60	SWITCH-ROLLOUT(01)	ML180UH045P36A
42J32	TRANSFORMER(01)	ML180UH045P36A
98L78	TUBING(01)	ML180UH045P36A
89J10	WHEEL-BLOWER(01)	ML180UH045P36A
11M65	WIRE-FLAME SENSOR(01)	ML180UH045P36A

### **ML180UH045XP36A**

28W59	BOX-CONTROL(01)	ML180UH045XP36A
22W78	CAPACITOR-FAN(01)	ML180UH045XP36A
17W70	CONTROL-IGN(01)	ML180UH045XP36A
69M38	CONTROL-LIMIT(01)	ML180UH045XP36A
LB-74940B	FLAME SENSOR(01)	ML180UH045XP36A
68L52	HARNES - WIRING(01)	ML180UH045XP36A
57M87	HOUSING-BLOWER(01)	ML180UH045XP36A
19W61	IGNITOR(01)	ML180UH045XP36A
97M37	KIT-HARDWARE(01)	ML180UH045XP36A
29M85	KIT-REGULATOR(01)	ML180UH045XP36A
21W85	MOTOR-BLOWER(01)	ML180UH045XP36A
73W63	PANEL-BLOWER ACCESS(01)	ML180UH045XP36A
73W62	PANEL-BURNER ACCESS(01)	ML180UH045XP36A
51W15	SWITCH(01)	ML180UH045XP36A
51W92	SWITCH-PRESS(01)	ML180UH045XP36A
25M60	SWITCH-ROLLOUT(01)	ML180UH045XP36A
42J32	TRANSFORMER(01)	ML180UH045XP36A
98L78	TUBING(01)	ML180UH045XP36A
89J10	WHEEL-BLOWER(01)	ML180UH045XP36A
11M65	WIRE-FLAME SENSOR(01)	ML180UH045XP36A

### **ML180UH070P24A**

28W59	BOX-CONTROL(01)	ML180UH070P24A
22W78	CAPACITOR-FAN(01)	ML180UH070P24A
17W70	CONTROL-IGN(01)	ML180UH070P24A
69M38	CONTROL-LIMIT(01)	ML180UH070P24A
LB-74	FLAME SENSOR(01)	ML180UH070P24A
68L52	HARNES - WIRING(01)	ML180UH070P24A
57M86	HOUSING-BLOWER(01)	ML180UH070P24A
19W61	IGNITOR(01)	ML180UH070P24A
97M37	KIT-HARDWARE(01)	ML180UH070P24A
29M85	KIT-REGULATOR(01)	ML180UH070P24A
73W63	PANEL-BLOWER ACCESS(01)	ML180UH070P24A

73W62	PANEL-BURNER ACCESS(01)	ML180UH070P24A
81L89	PLATE-CUTOFF(01)	ML180UH070P24A
51W15	SWITCH(01)	ML180UH070P24A
25M60	SWITCH-ROLLOUT(01)	ML180UH070P24A
42J32	TRANSFORMER(01)	ML180UH070P24A
98L78	TUBING(01)	ML180UH070P24A
21709	WHEEL-BLOWER(01)	ML180UH070P24A
11M65	WIRE-FLAME SENSOR(01)	ML180UH070P24A

### **ML180UH070P36A**

28W59	BOX-CONTROL(01)	ML180UH070P36A
22W78	CAPACITOR-FAN(01)	ML180UH070P36A
17W70	CONTROL-IGN(01)	ML180UH070P36A
47W64	CONTROL-LIMIT(01)	ML180UH070P36A
69M38	CONTROL-LIMIT(01)	ML180UH070P36A
LB-74940B	FLAME SENSOR(01)	ML180UH070P36A
68L52	HARNES - WIRING(01)	ML180UH070P36A
57M87	HOUSING-BLOWER(01)	ML180UH070P36A
19W61	IGNITOR(01)	ML180UH070P36A
97M37	KIT-HARDWARE(01)	ML180UH070P36A
29M85	KIT-REGULATOR(01)	ML180UH070P36A
21W85	MOTOR-BLOWER(01)	ML180UH070P36A
73W63	PANEL-BLOWER ACCESS(01)	ML180UH070P36A
73W62	PANEL-BURNER ACCESS(01)	ML180UH070P36A
51W15	SWITCH(01)	ML180UH070P36A
25M60	SWITCH-ROLLOUT(01)	ML180UH070P36A
42J32	TRANSFORMER(01)	ML180UH070P36A
98L78	TUBING(01)	ML180UH070P36A
89J10	WHEEL-BLOWER(01)	ML180UH070P36A
11M65	WIRE-FLAME SENSOR(01)	ML180UH070P36A

### **ML180UH070XP36A**

28W59	BOX-CONTROL(01)	ML180UH070XP36A
22W78	CAPACITOR-FAN(01)	ML180UH070XP36A
17W70	CONTROL-IGN(01)	ML180UH070XP36A
47W64	CONTROL-LIMIT(01)	ML180UH070XP36A
69M38	CONTROL-LIMIT(01)	ML180UH070XP36A
LB-74940B	FLAME SENSOR(01)	ML180UH070XP36A
68L52	HARNES - WIRING(01)	ML180UH070XP36A
57M87	HOUSING-BLOWER(01)	ML180UH070XP36A
19W61	IGNITOR(01)	ML180UH070XP36A
97M37	KIT-HARDWARE(01)	ML180UH070XP36A
29M85	KIT-REGULATOR(01)	ML180UH070XP36A
21W85	MOTOR-BLOWER(01)	ML180UH070XP36A
73W63	PANEL-BLOWER ACCESS(01)	ML180UH070XP36A
73W62	PANEL-BURNER ACCESS(01)	ML180UH070XP36A
51W15	SWITCH(01)	ML180UH070XP36A
25M60	SWITCH-ROLLOUT(01)	ML180UH070XP36A

42J32	TRANSFORMER(01)	ML180UH070XP36A
98L78	TUBING(01)	ML180UH070XP36A
89J10	WHEEL-BLOWER(01)	ML180UH070XP36A
11M65	WIRE-FLAME SENSOR(01)	ML180UH070XP36A

### ML193DF045P36B

28W59	BOX-CONTROL(01)	ML193DF045P36B
22W78	CAPACITOR-FAN(01)	ML193DF045P36B
17W70	CONTROL-IGN(01)	ML193DF045P36B
LB-74940B	FLAME SENSOR(01)	ML193DF045P36B
57M87	HOUSING-BLOWER(01)	ML193DF045P36B
19W61	IGNITOR(01)	ML193DF045P36B
97M37	KIT-HARDWARE(01)	ML193DF045P36B
29M85	KIT-REGULATOR(01)	ML193DF045P36B
21W85	MOTOR-BLOWER(01)	ML193DF045P36B
73W63	PANEL-BLOWER ACCESS(01)	ML193DF045P36B
73W62	PANEL-BURNER ACCESS(01)	ML193DF045P36B
51W15	SWITCH(01)	ML193DF045P36B
42J32	TRANSFORMER(01)	ML193DF045P36B
47M84	TUBING(01)	ML193DF045P36B
21708	WHEEL-BLOWER(01)	ML193DF045P36B
11M65	WIRE-FLAME SENSOR(01)	ML193DF045P36B

### ML193DF070P36B

28W59	BOX-CONTROL(01)	ML193DF070P36B
22W78	CAPACITOR-FAN(01)	ML193DF070P36B
17W70	CONTROL-IGN(01)	ML193DF070P36B
CAT#	DESCRIPTION	Unit
LB-74940B	FLAME SENSOR(01)	ML193DF070P36B
57M87	HOUSING-BLOWER(01)	ML193DF070P36B
19W61	IGNITOR(01)	ML193DF070P36B
97M37	KIT-HARDWARE(01)	ML193DF070P36B
29M85	KIT-REGULATOR(01)	ML193DF070P36B
21W85	MOTOR-BLOWER(01)	ML193DF070P36B
73W63	PANEL-BLOWER ACCESS(01)	ML193DF070P36B
73W62	PANEL-BURNER ACCESS(01)	ML193DF070P36B
51W15	SWITCH(01)	ML193DF070P36B
42J32	TRANSFORMER(01)	ML193DF070P36B
47M84	TUBING(01)	ML193DF070P36B
21708	WHEEL-BLOWER(01)	ML193DF070P36B
11M65	WIRE-FLAME SENSOR(01)	ML193DF070P36B

### ML193DF090P48C

28W59	BOX-CONTROL(01)	ML193DF090P48C
22W79	CAPACITOR-MOTOR(01)	ML193DF090P48C

17W70	CONTROL-IGN(01)	ML193DF090P48C
LB-74940B	FLAME SENSOR(01)	ML193DF090P48C
57M88	HOUSING-BLOWER(01)	ML193DF090P48C
19W61	IGNITOR(01)	ML193DF090P48C
97M37	KIT-HARDWARE(01)	ML193DF090P48C
29M85	KIT-REGULATOR(01)	ML193DF090P48C
21W86	MOTOR-BLOWER(01)	ML193DF090P48C
73W63	PANEL-BLOWER ACCESS(01)	ML193DF090P48C
73W62	PANEL-BURNER ACCESS(01)	ML193DF090P48C
51W15	SWITCH(01)	ML193DF090P48C
42J32	TRANSFORMER(01)	ML193DF090P48C
47M84	TUBING(01)	ML193DF090P48C
16596	WHEEL-BLOWER(01)	ML193DF090P48C
11M65	WIRE-FLAME SENSOR(01)	ML193DF090P48C

### **ML193DF110P60C**

28W59	BOX-CONTROL(01)	ML193DF110P60C
26W38	CAPACITOR(01)	ML193DF110P60C
17W70	CONTROL-IGN(01)	ML193DF110P60C
LB-74940B	FLAME SENSOR(01)	ML193DF110P60C
57M89	HOUSING-BLOWER(01)	ML193DF110P60C
19W61	IGNITOR(01)	ML193DF110P60C
97M37	KIT-HARDWARE(01)	ML193DF110P60C
29M85	KIT-REGULATOR(01)	ML193DF110P60C
73W63	PANEL-BLOWER ACCESS(01)	ML193DF110P60C
73W62	PANEL-BURNER ACCESS(01)	ML193DF110P60C
81L92	PLATE-CUTOFF(01)	ML193DF110P60C
51W15	SWITCH(01)	ML193DF110P60C
42J32	TRANSFORMER(01)	ML193DF110P60C
47M84	TUBING(01)	ML193DF110P60C
45M36	WHEEL-BLOWER(01)	ML193DF110P60C
11M65	WIRE-FLAME SENSOR(01)	ML193DF110P60C

### **ML193UH045P24B**

28W59	BOX-CONTROL(01)	ML193UH045P24B
22W78	CAPACITOR-FAN(01)	ML193UH045P24B
17W70	CONTROL-IGN(01)	ML193UH045P24B
LB-74940B	FLAME SENSOR(01)	ML193UH045P24B
57M87	HOUSING-BLOWER(01)	ML193UH045P24B
19W61	IGNITOR(01)	ML193UH045P24B
97M37	KIT-HARDWARE(01)	ML193UH045P24B
29M85	KIT-REGULATOR(01)	ML193UH045P24B
73W63	PANEL-BLOWER ACCESS(01)	ML193UH045P24B
73W62	PANEL-BURNER ACCESS(01)	ML193UH045P24B
51W15	SWITCH(01)	ML193UH045P24B
51W92	SWITCH-PRESS(01)	ML193UH045P24B
42J32	TRANSFORMER(01)	ML193UH045P24B
47M84	TUBING(01)	ML193UH045P24B

21708	WHEEL-BLOWER(01)	ML193UH045P24B
11M65	WIRE-FLAME SENSOR(01)	ML193UH045P24B

### **ML193UH045P36B**

28W59	BOX-CONTROL(01)	ML193UH045P36B
22W78	CAPACITOR-FAN(01)	ML193UH045P36B
17W70	CONTROL-IGN(01)	ML193UH045P36B
LB-74940B	FLAME SENSOR(01)	ML193UH045P36B
57M87	HOUSING-BLOWER(01)	ML193UH045P36B
19W61	IGNITOR(01)	ML193UH045P36B
97M37	KIT-HARDWARE(01)	ML193UH045P36B
29M85	KIT-REGULATOR(01)	ML193UH045P36B
21W85	MOTOR-BLOWER(01)	ML193UH045P36B
73W63	PANEL-BLOWER ACCESS(01)	ML193UH045P36B
73W62	PANEL-BURNER ACCESS(01)	ML193UH045P36B
51W15	SWITCH(01)	ML193UH045P36B
42J32	TRANSFORMER(01)	ML193UH045P36B
47M84	TUBING(01)	ML193UH045P36B
21708	WHEEL-BLOWER(01)	ML193UH045P36B
11M65	WIRE-FLAME SENSOR(01)	ML193UH045P36B

### **ML193UH070P24B**

28W59	BOX-CONTROL(01)	ML193UH070P24B
22W78	CAPACITOR-FAN(01)	ML193UH070P24B
17W70	CONTROL-IGN(01)	ML193UH070P24B
LB-74	FLAME SENSOR(01)	ML193UH070P24B
57M87	HOUSING-BLOWER(01)	ML193UH070P24B
19W61	IGNITOR(01)	ML193UH070P24B
97M37	KIT-HARDWARE(01)	ML193UH070P24B
29M85	KIT-REGULATOR(01)	ML193UH070P24B
73W63	PANEL-BLOWER ACCESS(01)	ML193UH070P24B
73W62	PANEL-BURNER ACCESS(01)	ML193UH070P24B
51W15	SWITCH(01)	ML193UH070P24B
42J32	TRANSFORMER(01)	ML193UH070P24B
47M84	TUBING(01)	ML193UH070P24B
21708	WHEEL-BLOWER(01)	ML193UH070P24B
11M65	WIRE-FLAME SENSOR(01)	ML193UH070P24B

### **ML193UH070P36B**

28W59	BOX-CONTROL(01)	ML193UH070P36B
22W78	CAPACITOR-FAN(01)	ML193UH070P36B
17W70	CONTROL-IGN(01)	ML193UH070P36B
LB-74940B	FLAME SENSOR(01)	ML193UH070P36B
57M87	HOUSING-BLOWER(01)	ML193UH070P36B
19W61	IGNITOR(01)	ML193UH070P36B
97M37	KIT-HARDWARE(01)	ML193UH070P36B

29M85	KIT-REGULATOR(01)	ML193UH070P36B
21W85	MOTOR-BLOWER(01)	ML193UH070P36B
73W63	PANEL-BLOWER ACCESS(01)	ML193UH070P36B
73W62	PANEL-BURNER ACCESS(01)	ML193UH070P36B
51W15	SWITCH(01)	ML193UH070P36B
42J32	TRANSFORMER(01)	ML193UH070P36B
47M84	TUBING(01)	ML193UH070P36B
21708	WHEEL-BLOWER(01)	ML193UH070P36B
11M65	WIRE-FLAME SENSOR(01)	ML193UH070P36B

### **ML193UH090P36C**

28W59	BOX-CONTROL(01)	ML193UH090P36C
22W78	CAPACITOR-FAN(01)	ML193UH090P36C
17W70	CONTROL-IGN(01)	ML193UH090P36C
LB-74	FLAME SENSOR(01)	ML193UH090P36C
57M87	HOUSING-BLOWER(01)	ML193UH090P36C
19W61	IGNITOR(01)	ML193UH090P36C
97M37	KIT-HARDWARE(01)	ML193UH090P36C
29M85	KIT-REGULATOR(01)	ML193UH090P36C
21W85	MOTOR-BLOWER(01)	ML193UH090P36C
73W63	PANEL-BLOWER ACCESS(01)	ML193UH090P36C
73W62	PANEL-BURNER ACCESS(01)	ML193UH090P36C
51W15	SWITCH(01)	ML193UH090P36C
42J32	TRANSFORMER(01)	ML193UH090P36C
47M84	TUBING(01)	ML193UH090P36C
21708	WHEEL-BLOWER(01)	ML193UH090P36C
11M65	WIRE-FLAME SENSOR(01)	ML193UH090P36C

### **ML193UH090P48C**

28W59	BOX-CONTROL(01)	ML193UH090P48C
22W79	CAPACITOR-MOTOR(01)	ML193UH090P48C
17W70	CONTROL-IGN(01)	ML193UH090P48C
LB-74940B	FLAME SENSOR(01)	ML193UH090P48C
57M88	HOUSING-BLOWER(01)	ML193UH090P48C
19W61	IGNITOR(01)	ML193UH090P48C
97M37	KIT-HARDWARE(01)	ML193UH090P48C
29M85	KIT-REGULATOR(01)	ML193UH090P48C
21W86	MOTOR-BLOWER(01)	ML193UH090P48C
73W63	PANEL-BLOWER ACCESS(01)	ML193UH090P48C
73W62	PANEL-BURNER ACCESS(01)	ML193UH090P48C
51W15	SWITCH(01)	ML193UH090P48C
42J32	TRANSFORMER(01)	ML193UH090P48C
47M84	TUBING(01)	ML193UH090P48C
16596	WHEEL-BLOWER(01)	ML193UH090P48C
11M65	WIRE-FLAME SENSOR(01)	ML193UH090P48C



### **ML193UH110P48C**

28W59	BOX-CONTROL(01)	ML193UH110P48C
22W79	CAPACITOR-MOTOR(01)	ML193UH110P48C
17W70	CONTROL-IGN(01)	ML193UH110P48C
LB-74940B	FLAME SENSOR(01)	ML193UH110P48C
57M88	HOUSING-BLOWER(01)	ML193UH110P48C
19W61	IGNITOR(01)	ML193UH110P48C
97M37	KIT-HARDWARE(01)	ML193UH110P48C
29M85	KIT-REGULATOR(01)	ML193UH110P48C
21W86	MOTOR-BLOWER(01)	ML193UH110P48C
73W63	PANEL-BLOWER ACCESS(01)	ML193UH110P48C
73W62	PANEL-BURNER ACCESS(01)	ML193UH110P48C
51W15	SWITCH(01)	ML193UH110P48C
42J32	TRANSFORMER(01)	ML193UH110P48C
47M84	TUBING(01)	ML193UH110P48C
16596	WHEEL-BLOWER(01)	ML193UH110P48C
11M65	WIRE-FLAME SENSOR(01)	ML193UH110P48C

### **ML193UH110P60C**

28W59	BOX-CONTROL(01)	ML193UH110P60C
26W38	CAPACITOR(01)	ML193UH110P60C
17W70	CONTROL-IGN(01)	ML193UH110P60C
LB-74	FLAME SENSOR(01)	ML193UH110P60C
57M89	HOUSING-BLOWER(01)	ML193UH110P60C
19W61	IGNITOR(01)	ML193UH110P60C
97M37	KIT-HARDWARE(01)	ML193UH110P60C
29M85	KIT-REGULATOR(01)	ML193UH110P60C
73W63	PANEL-BLOWER ACCESS(01)	ML193UH110P60C
73W62	PANEL-BURNER ACCESS(01)	ML193UH110P60C
81L92	PLATE-CUTOFF(01)	ML193UH110P60C
51W15	SWITCH(01)	ML193UH110P60C
42J32	TRANSFORMER(01)	ML193UH110P60C
47M84	TUBING(01)	ML193UH110P60C
45M36	WHEEL-BLOWER(01)	ML193UH110P60C
11M65	WIRE-FLAME SENSOR(01)	ML193UH110P60C

### **ML193UH135P60D**

28W59	BOX-CONTROL(01)	ML193UH135P60D
26W38	CAPACITOR(01)	ML193UH135P60D
17W70	CONTROL-IGN(01)	ML193UH135P60D
LB-74	FLAME SENSOR(01)	ML193UH135P60D
57M89	HOUSING-BLOWER(01)	ML193UH135P60D
19W61	IGNITOR(01)	ML193UH135P60D
97M37	KIT-HARDWARE(01)	ML193UH135P60D
29M85	KIT-REGULATOR(01)	ML193UH135P60D
73W63	PANEL-BLOWER ACCESS(01)	ML193UH135P60D

73W62	PANEL-BURNER ACCESS(01)	ML193UH135P60D
81L92	PLATE-CUTOFF(01)	ML193UH135P60D
51W15	SWITCH(01)	ML193UH135P60D
42J32	TRANSFORMER(01)	ML193UH135P60D
47M84	TUBING(01)	ML193UH135P60D
45M36	WHEEL-BLOWER(01)	ML193UH135P60D
11M65	WIRE-FLAME SENSOR(01)	ML193UH135P60D

### SL280DF070V36A

31L98	ADAPTER(01)	SL280DF070V36A
100870-03	BOARD-CIRCUIT(01)	SL280DF070V36A
28W59	BOX-CONTROL(01)	SL280DF070V36A
26W34	BREAKER-CIRCUIT(01)	SL280DF070V36A
69M38	CONTROL-LIMIT(01)	SL280DF070V36A
70W05	DOOR CLIP KIT(01)	SL280DF070V36A
LB-74	FLAME SENSOR(01)	SL280DF070V36A
12M66	HARNESS-WIRING(01)	SL280DF070V36A
27M11	HARNESS-WIRING(01)	SL280DF070V36A
27M25	HARNESS-WIRING(01)	SL280DF070V36A
19W61	IGNITOR(01)	SL280DF070V36A
71M48	KIT-BLOWER(01)	SL280DF070V36A
48M39	KIT-STANDOFF(01)	SL280DF070V36A
18M68	MOUNT-MOTOR(01)	SL280DF070V36A
30W37	SCREW(01)	SL280DF070V36A
49L04	SIGHT GLASS(01)	SL280DF070V36A
51W15	SWITCH(01)	SL280DF070V36A
25M60	SWITCH-ROLLOUT(01)	SL280DF070V36A
42J32	TRANSFORMER(01)	SL280DF070V36A
98L78	TUBING(01)	SL280DF070V36A
89J10	WHEEL-BLOWER(01)	SL280DF070V36A
11M65	WIRE-FLAME SENSOR(01)	SL280DF070V36A

### SL280DF090V48B

31L98	ADAPTER(01)	SL280DF090V48B
32M17	ARM(01)	SL280DF090V48B
10087	BOARD-CIRCUIT(01)	SL280DF090V48B
28W59	BOX-CONTROL(01)	SL280DF090V48B
26W34	BREAKER-CIRCUIT(01)	SL280DF090V48B
69M38	CONTROL-LIMIT(01)	SL280DF090V48B
70W05	DOOR CLIP KIT(01)	SL280DF090V48B
LB-74940B	FLAME SENSOR(01)	SL280DF090V48B
43H81	GROMMET(01)	SL280DF090V48B
12M66	HARNESS-WIRING(01)	SL280DF090V48B
27M11	HARNESS-WIRING(01)	SL280DF090V48B
27M25	HARNESS-WIRING(01)	SL280DF090V48B
19W61	IGNITOR(01)	SL280DF090V48B
48M39	KIT-STANDOFF(01)	SL280DF090V48B
49L97	MOUNT-MOTOR(01)	SL280DF090V48B

30W37	SCREW(01)	SL280DF090V48B
49L04	SIGHT GLASS(01)	SL280DF090V48B
49L98	SLEEVE(01)	SL280DF090V48B
51W15	SWITCH(01)	SL280DF090V48B
25M60	SWITCH-ROLLOUT(01)	SL280DF090V48B
42J32	TRANSFORMER(01)	SL280DF090V48B
98L78	TUBING(01)	SL280DF090V48B
11M65	WIRE-FLAME SENSOR(01)	SL280DF090V48B

### SL280DF090V60C

31L98	ADAPTER(01)	SL280DF090V60C
32M17	ARM(01)	SL280DF090V60C
10087	BOARD-CIRCUIT(01)	SL280DF090V60C
28W59	BOX-CONTROL(01)	SL280DF090V60C
26W34	BREAKER-CIRCUIT(01)	SL280DF090V60C
69H12	CHOKE-POWER(01)	SL280DF090V60C
69M38	CONTROL-LIMIT(01)	SL280DF090V60C
70W05	DOOR CLIP KIT(01)	SL280DF090V60C
LB-74940B	FLAME SENSOR(01)	SL280DF090V60C
43H81	GROMMET(01)	SL280DF090V60C
12M66	HARNESS-WIRING(01)	SL280DF090V60C
27M11	HARNESS-WIRING(01)	SL280DF090V60C
27M25	HARNESS-WIRING(01)	SL280DF090V60C
19W61	IGNITOR(01)	SL280DF090V60C
48M39	KIT-STANDOFF(01)	SL280DF090V60C
49L97	MOUNT-MOTOR(01)	SL280DF090V60C
81L92	PLATE-CUTOFF(01)	SL280DF090V60C
30W37	SCREW(01)	SL280DF090V60C
49L04	SIGHT GLASS(01)	SL280DF090V60C
49L98	SLEEVE(01)	SL280DF090V60C
51W15	SWITCH(01)	SL280DF090V60C
25M60	SWITCH-ROLLOUT(01)	SL280DF090V60C
42J32	TRANSFORMER(01)	SL280DF090V60C
98L78	TUBING(01)	SL280DF090V60C
36M22	WHEEL-BLOWER(01)	SL280DF090V60C
11M65	WIRE-FLAME SENSOR(01)	SL280DF090V60C

### SL280DF110V60C

31L98	ADAPTER(01)	SL280DF110V60C
32M17	ARM(01)	SL280DF110V60C
100870-03	BOARD-CIRCUIT(01)	SL280DF110V60C
28W59	BOX-CONTROL(01)	SL280DF110V60C
26W34	BREAKER-CIRCUIT(01)	SL280DF110V60C
69H12	CHOKE-POWER(01)	SL280DF110V60C
69M38	CONTROL-LIMIT(01)	SL280DF110V60C
70W05	DOOR CLIP KIT(01)	SL280DF110V60C
LB-74940B	FLAME SENSOR(01)	SL280DF110V60C
43H81	GROMMET(01)	SL280DF110V60C

12M66	HARNESS-WIRING(01)	SL280DF110V60C
27M11	HARNESS-WIRING(01)	SL280DF110V60C
27M25	HARNESS-WIRING(01)	SL280DF110V60C
19W61	IGNITOR(01)	SL280DF110V60C
48M39	KIT-STANDOFF(01)	SL280DF110V60C
49L97	MOUNT-MOTOR(01)	SL280DF110V60C
81L92	PLATE-CUTOFF(01)	SL280DF110V60C
30W37	SCREW(01)	SL280DF110V60C
49L04	SIGHT GLASS(01)	SL280DF110V60C
49L98	SLEEVE(01)	SL280DF110V60C
51W15	SWITCH(01)	SL280DF110V60C
25M60	SWITCH-ROLLOUT(01)	SL280DF110V60C
42J32	TRANSFORMER(01)	SL280DF110V60C
98L78	TUBING(01)	SL280DF110V60C
36M22	WHEEL-BLOWER(01)	SL280DF110V60C
11M65	WIRE-FLAME SENSOR(01)	SL280DF110V60C

### SL280UH070V36A

100870-03	BOARD-CIRCUIT(01)	SL280UH070V36A
100870-03	BOARD-CIRCUIT(01)	SL280UH070XV36A
28W59	BOX-CONTROL(01)	SL280UH070V36A
26W34	BREAKER-CIRCUIT(01)	SL280UH070V36A
69M38	CONTROL-LIMIT(01)	SL280UH070V36A
70W05	DOOR CLIP KIT(01)	SL280UH070V36A
LB-74	FLAME SENSOR(01)	SL280UH070V36A
68L52	HARNESS - WIRING(01)	SL280UH070V36A
27M11	HARNESS-WIRING(01)	SL280UH070V36A
27M25	HARNESS-WIRING(01)	SL280UH070V36A
57M87	HOUSING-BLOWER(01)	SL280UH070V36A
19W61	IGNITOR(01)	SL280UH070V36A
71M48	KIT-BLOWER(01)	SL280UH070V36A
18M68	MOUNT-MOTOR(01)	SL280UH070V36A
30W37	SCREW(01)	SL280UH070V36A
49L04	SIGHT GLASS(01)	SL280UH070V36A
51W15	SWITCH(01)	SL280UH070V36A
25M60	SWITCH-ROLLOUT(01)	SL280UH070V36A
42J32	TRANSFORMER(01)	SL280UH070V36A
98L78	TUBING(01)	SL280UH070V36A
89J10	WHEEL-BLOWER(01)	SL280UH070V36A
11M65	WIRE-FLAME SENSOR(01)	SL280UH070V36A

### SL280UH070XV36A

28W59	BOX-CONTROL(01)	SL280UH070XV36A
26W34	BREAKER-CIRCUIT(01)	SL280UH070XV36A
69M38	CONTROL-LIMIT(01)	SL280UH070XV36A
70W05	DOOR CLIP KIT(01)	SL280UH070XV36A
LB-74940B	FLAME SENSOR(01)	SL280UH070XV36A

68L52	HARNESS - WIRING(01)	SL280UH070XV36A
27M11	HARNESS-WIRING(01)	SL280UH070XV36A
27M25	HARNESS-WIRING(01)	SL280UH070XV36A
57M87	HOUSING-BLOWER(01)	SL280UH070XV36A
19W61	IGNITOR(01)	SL280UH070XV36A
71M48	KIT-BLOWER(01)	SL280UH070XV36A
18M68	MOUNT-MOTOR(01)	SL280UH070XV36A
30W37	SCREW(01)	SL280UH070XV36A
49L04	SIGHT GLASS(01)	SL280UH070XV36A
51W15	SWITCH(01)	SL280UH070XV36A
25M60	SWITCH-ROLLOUT(01)	SL280UH070XV36A
42J32	TRANSFORMER(01)	SL280UH070XV36A
98L78	TUBING(01)	SL280UH070XV36A
89J10	WHEEL-BLOWER(01)	SL280UH070XV36A
11M65	WIRE-FLAME SENSOR(01)	SL280UH070XV36A

### **SL280UH090V36B**

10087	BOARD-CIRCUIT(01)	SL280UH090V36B
28W59	BOX-CONTROL(01)	SL280UH090V36B
26W34	BREAKER-CIRCUIT(01)	SL280UH090V36B
69M38	CONTROL-LIMIT(01)	SL280UH090V36B
70W05	DOOR CLIP KIT(01)	SL280UH090V36B
LB-74940B	FLAME SENSOR(01)	SL280UH090V36B
68L52	HARNESS - WIRING(01)	SL280UH090V36B
27M11	HARNESS-WIRING(01)	SL280UH090V36B
27M25	HARNESS-WIRING(01)	SL280UH090V36B
19W61	IGNITOR(01)	SL280UH090V36B
71M48	KIT-BLOWER(01)	SL280UH090V36B
18M68	MOUNT-MOTOR(01)	SL280UH090V36B
30W37	SCREW(01)	SL280UH090V36B
49L04	SIGHT GLASS(01)	SL280UH090V36B
51W15	SWITCH(01)	SL280UH090V36B
25M60	SWITCH-ROLLOUT(01)	SL280UH090V36B
42J32	TRANSFORMER(01)	SL280UH090V36B
98L78	TUBING(01)	SL280UH090V36B
11M65	WIRE-FLAME SENSOR(01)	SL280UH090V36B

### **SL280UH090V48B**

32M17	ARM(01)	SL280UH090V48B
100870-03	BOARD-CIRCUIT(01)	SL280UH090V48B
28W59	BOX-CONTROL(01)	SL280UH090V48B
26W34	BREAKER-CIRCUIT(01)	SL280UH090V48B
69H12	CHOKE-POWER(01)	SL280UH090V48B
69M38	CONTROL-LIMIT(01)	SL280UH090V48B
70W05	DOOR CLIP KIT(01)	SL280UH090V48B
LB-74940B	FLAME SENSOR(01)	SL280UH090V48B
43H81	GROMMET(01)	SL280UH090V48B
68L52	HARNESS - WIRING(01)	SL280UH090V48B

27M11	HARNESS-WIRING(01)	SL280UH090V48B
27M25	HARNESS-WIRING(01)	SL280UH090V48B
19W61	IGNITOR(01)	SL280UH090V48B
30W37	SCREW(01)	SL280UH090V48B
49L04	SIGHT GLASS(01)	SL280UH090V48B
49L98	SLEEVE(01)	SL280UH090V48B
51W15	SWITCH(01)	SL280UH090V48B
25M60	SWITCH-ROLLOUT(01)	SL280UH090V48B
42J32	TRANSFORMER(01)	SL280UH090V48B
98L78	TUBING(01)	SL280UH090V48B
11M65	WIRE-FLAME SENSOR(01)	SL280UH090V48B

### **SL280UH090V60C**

32M17	ARM(01)	SL280UH090V60C
100870-03	BOARD-CIRCUIT(01)	SL280UH090V60C
28W59	BOX-CONTROL(01)	SL280UH090V60C
26W34	BREAKER-CIRCUIT(01)	SL280UH090V60C
69H12	CHOKE-POWER(01)	SL280UH090V60C
69M38	CONTROL-LIMIT(01)	SL280UH090V60C
70W05	DOOR CLIP KIT(01)	SL280UH090V60C
LB-74940B	FLAME SENSOR(01)	SL280UH090V60C
43H81	GROMMET(01)	SL280UH090V60C
68L52	HARNESS - WIRING(01)	SL280UH090V60C
27M11	HARNESS-WIRING(01)	SL280UH090V60C
27M25	HARNESS-WIRING(01)	SL280UH090V60C
57M89	HOUSING-BLOWER(01)	SL280UH090V60C
19W61	IGNITOR(01)	SL280UH090V60C
49L97	MOUNT-MOTOR(01)	SL280UH090V60C
81L92	PLATE-CUTOFF(01)	SL280UH090V60C
30W37	SCREW(01)	SL280UH090V60C
49L04	SIGHT GLASS(01)	SL280UH090V60C
49L98	SLEEVE(01)	SL280UH090V60C
51W15	SWITCH(01)	SL280UH090V60C
25M60	SWITCH-ROLLOUT(01)	SL280UH090V60C
42J32	TRANSFORMER(01)	SL280UH090V60C
98L78	TUBING(01)	SL280UH090V60C
36M22	WHEEL-BLOWER(01)	SL280UH090V60C
11M65	WIRE-FLAME SENSOR(01)	SL280UH090V60C

### **SL280UH090XV48B**

32M17	ARM(01)	SL280UH090XV48B
100870-03	BOARD-CIRCUIT(01)	SL280UH090XV48B
28W59	BOX-CONTROL(01)	SL280UH090XV48B
26W34	BREAKER-CIRCUIT(01)	SL280UH090XV48B
69H12	CHOKE-POWER(01)	SL280UH090XV48B
69M38	CONTROL-LIMIT(01)	SL280UH090XV48B
70W05	DOOR CLIP KIT(01)	SL280UH090XV48B
LB-74940B	FLAME SENSOR(01)	SL280UH090XV48B

43H81	GROMMET(01)	SL280UH090XV48B
68L52	HARNESS - WIRING(01)	SL280UH090XV48B
27M11	HARNESS-WIRING(01)	SL280UH090XV48B
27M25	HARNESS-WIRING(01)	SL280UH090XV48B
19W61	IGNITOR(01)	SL280UH090XV48B
30W37	SCREW(01)	SL280UH090XV48B
49L04	SIGHT GLASS(01)	SL280UH090XV48B
49L98	SLEEVE(01)	SL280UH090XV48B
51W15	SWITCH(01)	SL280UH090XV48B
25M60	SWITCH-ROLLOUT(01)	SL280UH090XV48B
42J32	TRANSFORMER(01)	SL280UH090XV48B
98L78	TUBING(01)	SL280UH090XV48B
11M65	WIRE-FLAME SENSOR(01)	SL280UH090XV48B

### **SL280UH110V60C**

32M17	ARM(01)	SL280UH110V60C
10087	BOARD-CIRCUIT(01)	SL280UH110V60C
28W59	BOX-CONTROL(01)	SL280UH110V60C
26W34	BREAKER-CIRCUIT(01)	SL280UH110V60C
69H12	CHOKE-POWER(01)	SL280UH110V60C
69M38	CONTROL-LIMIT(01)	SL280UH110V60C
70W05	DOOR CLIP KIT(01)	SL280UH110V60C
LB-74940B	FLAME SENSOR(01)	SL280UH110V60C
43H81	GROMMET(01)	SL280UH110V60C
68L52	HARNESS - WIRING(01)	SL280UH110V60C
27M11	HARNESS-WIRING(01)	SL280UH110V60C
27M25	HARNESS-WIRING(01)	SL280UH110V60C
57M89	HOUSING-BLOWER(01)	SL280UH110V60C
19W61	IGNITOR(01)	SL280UH110V60C
49L97	MOUNT-MOTOR(01)	SL280UH110V60C
81L92	PLATE-CUTOFF(01)	SL280UH110V60C
30W37	SCREW(01)	SL280UH110V60C
49L04	SIGHT GLASS(01)	SL280UH110V60C
49L98	SLEEVE(01)	SL280UH110V60C
51W15	SWITCH(01)	SL280UH110V60C
25M60	SWITCH-ROLLOUT(01)	SL280UH110V60C
42J32	TRANSFORMER(01)	SL280UH110V60C
98L78	TUBING(01)	SL280UH110V60C
36M22	WHEEL-BLOWER(01)	SL280UH110V60C
11M65	WIRE-FLAME SENSOR(01)	SL280UH110V60C

### **SL280UH110XV60C**

32M17	ARM(01)	SL280UH110XV60C
10087	BOARD-CIRCUIT(01)	SL280UH110XV60C
28W59	BOX-CONTROL(01)	SL280UH110XV60C
26W34	BREAKER-CIRCUIT(01)	SL280UH110XV60C
69H12	CHOKE-POWER(01)	SL280UH110XV60C
69M38	CONTROL-LIMIT(01)	SL280UH110XV60C

70W05	DOOR CLIP KIT(01)	SL280UH110XV60C
LB-74	FLAME SENSOR(01)	SL280UH110XV60C
43H81	GROMMET(01)	SL280UH110XV60C
68L52	HARNESS - WIRING(01)	SL280UH110XV60C
27M11	HARNESS-WIRING(01)	SL280UH110XV60C
27M25	HARNESS-WIRING(01)	SL280UH110XV60C
57M89	HOUSING-BLOWER(01)	SL280UH110XV60C
19W61	IGNITOR(01)	SL280UH110XV60C
49L97	MOUNT-MOTOR(01)	SL280UH110XV60C
81L92	PLATE-CUTOFF(01)	SL280UH110XV60C
30W37	SCREW(01)	SL280UH110XV60C
49L04	SIGHT GLASS(01)	SL280UH110XV60C
49L98	SLEEVE(01)	SL280UH110XV60C
51W15	SWITCH(01)	SL280UH110XV60C
25M60	SWITCH-ROLLOUT(01)	SL280UH110XV60C
42J32	TRANSFORMER(01)	SL280UH110XV60C
98L78	TUBING(01)	SL280UH110XV60C
36M22	WHEEL-BLOWER(01)	SL280UH110XV60C
11M65	WIRE-FLAME SENSOR(01)	SL280UH110XV60C

### **SL280UH135V60D**

32M17	ARM(01)	SL280UH135V60D
10087	BOARD-CIRCUIT(01)	SL280UH135V60D
28W59	BOX-CONTROL(01)	SL280UH135V60D
26W34	BREAKER-CIRCUIT(01)	SL280UH135V60D
69H12	CHOKE-POWER(01)	SL280UH135V60D
69M38	CONTROL-LIMIT(01)	SL280UH135V60D
70W05	DOOR CLIP KIT(01)	SL280UH135V60D
LB-74940B	FLAME SENSOR(01)	SL280UH135V60D
43H81	GROMMET(01)	SL280UH135V60D
68L52	HARNESS - WIRING(01)	SL280UH135V60D
27M11	HARNESS-WIRING(01)	SL280UH135V60D
27M25	HARNESS-WIRING(01)	SL280UH135V60D
19W61	IGNITOR(01)	SL280UH135V60D
49L97	MOUNT-MOTOR(01)	SL280UH135V60D
30W37	SCREW(01)	SL280UH135V60D
49L04	SIGHT GLASS(01)	SL280UH135V60D
49L98	SLEEVE(01)	SL280UH135V60D
51W15	SWITCH(01)	SL280UH135V60D
25M60	SWITCH-ROLLOUT(01)	SL280UH135V60D
42J32	TRANSFORMER(01)	SL280UH135V60D
98L78	TUBING(01)	SL280UH135V60D
11M65	WIRE-FLAME SENSOR(01)	SL280UH135V60D

### **SLP98DF070V36B**

33W32	BLOWER-COMB AIR(01)	SLP98DF070V36B
28W59	BOX-CONTROL(01)	SLP98DF070V36B



26W34	BREAKER-CIRCUIT(01)	SLP98DF070V36B
70W05	DOOR CLIP KIT(01)	SLP98DF070V36B
51M16	FITTING-BARB(01)	SLP98DF070V36B
LB-74940B	FLAME SENSOR(01)	SLP98DF070V36B
101551-05	HARNESS-WIRING(01)	SLP98DF070V36B
71M48	KIT-BLOWER(01)	SLP98DF070V36B
18M68	MOUNT-MOTOR(01)	SLP98DF070V36B
30W37	SCREW(01)	SLP98DF070V36B
49L04	SIGHT GLASS(01)	SLP98DF070V36B
51W15	SWITCH(01)	SLP98DF070V36B
42J32	TRANSFORMER(01)	SLP98DF070V36B
11M65	WIRE-FLAME SENSOR(01)	SLP98DF070V36B

### **SLP98DF090V36C**

33W32	BLOWER-COMB AIR(01)	SLP98DF090V36C
28W59	BOX-CONTROL(01)	SLP98DF090V36C
26W34	BREAKER-CIRCUIT(01)	SLP98DF090V36C
70W05	DOOR CLIP KIT(01)	SLP98DF090V36C
51M16	FITTING-BARB(01)	SLP98DF090V36C
LB-74940B	FLAME SENSOR(01)	SLP98DF090V36C
101551-05	HARNESS-WIRING(01)	SLP98DF090V36C
71M48	KIT-BLOWER(01)	SLP98DF090V36C
18M68	MOUNT-MOTOR(01)	SLP98DF090V36C
30W37	SCREW(01)	SLP98DF090V36C
49L04	SIGHT GLASS(01)	SLP98DF090V36C
51W15	SWITCH(01)	SLP98DF090V36C
42J32	TRANSFORMER(01)	SLP98DF090V36C
11M65	WIRE-FLAME SENSOR(01)	SLP98DF090V36C

### **SLP98DF090V48C**

32M17	ARM(01)	SLP98DF090V48C
33W32	BLOWER-COMB AIR(01)	SLP98DF090V48C
28W59	BOX-CONTROL(01)	SLP98DF090V48C
26W34	BREAKER-CIRCUIT(01)	SLP98DF090V48C
69H12	CHOKE-POWER(01)	SLP98DF090V48C
70W05	DOOR CLIP KIT(01)	SLP98DF090V48C
51M16	FITTING-BARB(01)	SLP98DF090V48C
LB-74940B	FLAME SENSOR(01)	SLP98DF090V48C
43H81	GROMMET(01)	SLP98DF090V48C
10155	HARNESS-WIRING(01)	SLP98DF090V48C
49L97	MOUNT-MOTOR(01)	SLP98DF090V48C
30W37	SCREW(01)	SLP98DF090V48C
49L04	SIGHT GLASS(01)	SLP98DF090V48C
49L98	SLEEVE(01)	SLP98DF090V48C
51W15	SWITCH(01)	SLP98DF090V48C
42J32	TRANSFORMER(01)	SLP98DF090V48C
11M65	WIRE-FLAME SENSOR(01)	SLP98DF090V48C

## SLP98DF090V60C

32M17	ARM(01)	SLP98DF090V60C
32M17	ARM(01)	SLP98DF110V60C
33W32	BLOWER-COMB AIR(01)	SLP98DF090V60C
33W32	BLOWER-COMB AIR(01)	SLP98DF110V60C
28W59	BOX-CONTROL(01)	SLP98DF090V60C
28W59	BOX-CONTROL(01)	SLP98DF110V60C
26W34	BREAKER-CIRCUIT(01)	SLP98DF090V60C
26W34	BREAKER-CIRCUIT(01)	SLP98DF110V60C
69H12	CHOKE-POWER(01)	SLP98DF090V60C
69H12	CHOKE-POWER(01)	SLP98DF110V60C
70W05	DOOR CLIP KIT(01)	SLP98DF090V60C
70W05	DOOR CLIP KIT(01)	SLP98DF110V60C
51M16	FITTING-BARB(01)	SLP98DF090V60C
51M16	FITTING-BARB(01)	SLP98DF110V60C
LB-74	FLAME SENSOR(01)	SLP98DF090V60C
LB-74	FLAME SENSOR(01)	SLP98DF110V60C
43H81	GROMMET(01)	SLP98DF090V60C
43H81	GROMMET(01)	SLP98DF110V60C
10155	HARNESS-WIRING(01)	SLP98DF090V60C
10155	HARNESS-WIRING(01)	SLP98DF110V60C
49L97	MOUNT-MOTOR(01)	SLP98DF090V60C
49L97	MOUNT-MOTOR(01)	SLP98DF110V60C
30W37	SCREW(01)	SLP98DF090V60C
30W37	SCREW(01)	SLP98DF110V60C
49L04	SIGHT GLASS(01)	SLP98DF090V60C
49L04	SIGHT GLASS(01)	SLP98DF110V60C
49L98	SLEEVE(01)	SLP98DF090V60C
49L98	SLEEVE(01)	SLP98DF110V60C
51W15	SWITCH(01)	SLP98DF090V60C
51W15	SWITCH(01)	SLP98DF110V60C
42J32	TRANSFORMER(01)	SLP98DF090V60C
42J32	TRANSFORMER(01)	SLP98DF110V60C
11M65	WIRE-FLAME SENSOR(01)	SLP98DF090V60C
11M65	WIRE-FLAME SENSOR(01)	SLP98DF110V60C

## SLP98UH070V36B

33W32	BLOWER-COMB AIR(01)	SLP98UH070V36B
28W59	BOX-CONTROL(01)	SLP98UH070V36B
26W34	BREAKER-CIRCUIT(01)	SLP98UH070V36B
70W05	DOOR CLIP KIT(01)	SLP98UH070V36B
51M16	FITTING-BARB(01)	SLP98UH070V36B
LB-74940B	FLAME SENSOR(01)	SLP98UH070V36B
101551-05	HARNESS-WIRING(01)	SLP98UH070V36B
71M48	KIT-BLOWER(01)	SLP98UH070V36B
18M68	MOUNT-MOTOR(01)	SLP98UH070V36B
30W37	SCREW(01)	SLP98UH070V36B
49L04	SIGHT GLASS(01)	SLP98UH070V36B

51W15	SWITCH(01)	SLP98UH070V36B
42J32	TRANSFORMER(01)	SLP98UH070V36B
11M65	WIRE-FLAME SENSOR(01)	SLP98UH070V36B

### **SLP98UH090V36C**

33W32	BLOWER-COMB AIR(01)	SLP98UH090V36C
28W59	BOX-CONTROL(01)	SLP98UH090V36C
26W34	BREAKER-CIRCUIT(01)	SLP98UH090V36C
70W05	DOOR CLIP KIT(01)	SLP98UH090V36C
51M16	FITTING-BARB(01)	SLP98UH090V36C
LB-74940B	FLAME SENSOR(01)	SLP98UH090V36C
101551-05	HARNES-WIRING(01)	SLP98UH090V36C
71M48	KIT-BLOWER(01)	SLP98UH090V36C
18M68	MOUNT-MOTOR(01)	SLP98UH090V36C
30W37	SCREW(01)	SLP98UH090V36C
49L04	SIGHT GLASS(01)	SLP98UH090V36C
51W15	SWITCH(01)	SLP98UH090V36C
42J32	TRANSFORMER(01)	SLP98UH090V36C
11M65	WIRE-FLAME SENSOR(01)	SLP98UH090V36C

### **SLP98UH090V48C**

32M17	ARM(01)	SLP98UH090V48C
33W32	BLOWER-COMB AIR(01)	SLP98UH090V48C
28W59	BOX-CONTROL(01)	SLP98UH090V48C
26W34	BREAKER-CIRCUIT(01)	SLP98UH090V48C
69H12	CHOKE-POWER(01)	SLP98UH090V48C
70W05	DOOR CLIP KIT(01)	SLP98UH090V48C
51M16	FITTING-BARB(01)	SLP98UH090V48C
LB-74940B	FLAME SENSOR(01)	SLP98UH090V48C
43H81	GROMMET(01)	SLP98UH090V48C
10155	HARNES-WIRING(01)	SLP98UH090V48C
49L97	MOUNT-MOTOR(01)	SLP98UH090V48C
30W37	SCREW(01)	SLP98UH090V48C
49L04	SIGHT GLASS(01)	SLP98UH090V48C
49L98	SLEEVE(01)	SLP98UH090V48C
51W15	SWITCH(01)	SLP98UH090V48C
42J32	TRANSFORMER(01)	SLP98UH090V48C
11M65	WIRE-FLAME SENSOR(01)	SLP98UH090V48C

### **SLP98UH090V60C**

32M17	ARM(01)	SLP98UH090V60C
33W32	BLOWER-COMB AIR(01)	SLP98UH090V60C
28W59	BOX-CONTROL(01)	SLP98UH090V60C
26W34	BREAKER-CIRCUIT(01)	SLP98UH090V60C
69H12	CHOKE-POWER(01)	SLP98UH090V60C

51M16	FITTING-BARB(01)	SLP98UH090V60C
43H81	GROMMET(01)	SLP98UH090V60C
101551-05	HARNES-WIRING(01)	SLP98UH090V60C
49L97	MOUNT-MOTOR(01)	SLP98UH090V60C
30W37	SCREW(01)	SLP98UH090V60C
49L04	SIGHT GLASS(01)	SLP98UH090V60C
49L98	SLEEVE(01)	SLP98UH090V60C
51W15	SWITCH(01)	SLP98UH090V60C
42J32	TRANSFORMER(01)	SLP98UH090V60C
11M65	WIRE-FLAME SENSOR(01)	SLP98UH090V60C

### **SLP98UH090V60C**

70W05	DOOR CLIP KIT(01)	SLP98UH090V60C
LB-74940B	FLAME SENSOR(01)	SLP98UH090V60C

### **SLP98UH110V60C**

32M17	ARM(01)	SLP98UH110V60C
33W32	BLOWER-COMB AIR(01)	SLP98UH110V60C
28W59	BOX-CONTROL(01)	SLP98UH110V60C
26W34	BREAKER-CIRCUIT(01)	SLP98UH110V60C
69H12	CHOKE-POWER(01)	SLP98UH110V60C
70W05	DOOR CLIP KIT(01)	SLP98UH110V60C
51M16	FITTING-BARB(01)	SLP98UH110V60C
LB-74940B	FLAME SENSOR(01)	SLP98UH110V60C
43H81	GROMMET(01)	SLP98UH110V60C
10155	HARNES-WIRING(01)	SLP98UH110V60C
49L97	MOUNT-MOTOR(01)	SLP98UH110V60C
30W37	SCREW(01)	SLP98UH110V60C
49L04	SIGHT GLASS(01)	SLP98UH110V60C
49L98	SLEEVE(01)	SLP98UH110V60C
51W15	SWITCH(01)	SLP98UH110V60C
42J32	TRANSFORMER(01)	SLP98UH110V60C
11M65	WIRE-FLAME SENSOR(01)	SLP98UH110V60C

### **SLP98UH135V60D**

11M65	WIRE-FLAME SENSOR(01)	SLP98UH135V60D
26W34	BREAKER-CIRCUIT(01)	SLP98UH135V60D
33W32	BLOWER-COMB AIR(01)	SLP98UH135V60D
42J32	TRANSFORMER(01)	SLP98UH135V60D
51W15	SWITCH(01)	SLP98UH135V60D
69H12	CHOKE-POWER(01)	SLP98UH135V60D
LB-74940B	FLAME SENSOR(01)	SLP98UH135V60D

### **AM30Q2**

37J56	BREAKER-CIRC(40)	AM30Q2
39H58	CAPACITOR(40)	AM30Q2
39H89	CAPACITOR(40)	AM30Q2
73J96	CAPACITOR(40)	AM30Q2
59C92	CAPACITOR-BLR MTR(40)	AM30Q2
59436	FILTER(40)	AM30Q2
31J81	FILTER(40)	AM30Q2
59K21	MODULE(40)	AM30Q2
21L90	MOTOR-BLOWER(40)	AM30Q2
21L92	MOTOR-BLOWER(40)	AM30Q2
21L93	MOTOR-BLOWER(40)	AM30Q2
28F01	MOTOR-BLOWER(40)	AM30Q2
37J24	MOTOR-BLOWER(40)	AM30Q2
37J25	MOTOR-BLOWER(40)	AM30Q2
45H33	MOTOR-BLOWER(40)	AM30Q2
86H66	MOTOR-BLOWER(40)	AM30Q2
53J75	PUMP(40)	AM30Q2
53J76	PUMP(40)	AM30Q2
49K94	THERMOSTAT(40)	AM30Q2
42J32	TRANSFORMER(40)	AM30Q2
16596	WHEEL-BLOWER(40)	AM30Q2
21708	WHEEL-BLOWER(40)	AM30Q2
21709	WHEEL-BLOWER(40)	AM30Q2
10G44	WHEEL-BLOWER(40)	AM30Q2

### **AM30Q3/4**

37J56	BREAKER-CIRC(90 70 105)	AM30Q3/4
39H58	CAPACITOR(90 70 105)	AM30Q3/4
39H89	CAPACITOR(90 70 105)	AM30Q3/4
73J96	CAPACITOR(90 70 105)	AM30Q3/4
59C92	CAPACITOR-BLR MTR(90 70 105)	AM30Q3/4
59436	FILTER(90 70 105)	AM30Q3/4
31J81	FILTER(90 70 105)	AM30Q3/4
64K78	FREEZESTAT KIT(90 70 105)	AM30Q3/4
73J77	KIT-CARTRIDGE(90 70 105)	AM30Q3/4
73J78	KIT-CARTRIDGE(90 70 105)	AM30Q3/4
73J79	KIT-CASING(90 70 105)	AM30Q3/4
73J81	KIT-CASING(90 70 105)	AM30Q3/4
59K21	MODULE(90 70 105)	AM30Q3/4
21L90	MOTOR-BLOWER(90 70 105)	AM30Q3/4
21L92	MOTOR-BLOWER(90 70 105)	AM30Q3/4
21L93	MOTOR-BLOWER(90 70 105)	AM30Q3/4
28F01	MOTOR-BLOWER(90 70 105)	AM30Q3/4
37J24	MOTOR-BLOWER(90 70 105)	AM30Q3/4
37J25	MOTOR-BLOWER(90 70 105)	AM30Q3/4
45H33	MOTOR-BLOWER(90 70 105)	AM30Q3/4
86H66	MOTOR-BLOWER(90 70 105)	AM30Q3/4
59L89	MOUNT-MOTOR(90 70 105)	AM30Q3/4
53J75	PUMP(90 70 105)	AM30Q3/4
53J76	PUMP(90 70 105)	AM30Q3/4

49K94	THERMOSTAT(90 70 105)	AM30Q3/4
42J32	TRANSFORMER(90 70 105)	AM30Q3/4
66J62	VALVE-CHECK(90 70 105)	AM30Q3/4
16596	WHEEL-BLOWER(90 70 105)	AM30Q3/4
21708	WHEEL-BLOWER(90 70 105)	AM30Q3/4
21709	WHEEL-BLOWER(90 70 105)	AM30Q3/4
10G44	WHEEL-BLOWER(90 70 105)	AM30Q3/4

### AM30Q4/5

73J82	"KIT-""O""RING"(90 120)	AM30Q4/5
37J56	BREAKER-CIRC(90 120)	AM30Q4/5
60F40	BUSHING(90 120)	AM30Q4/5
39H58	CAPACITOR(90 120)	AM30Q4/5
39H89	CAPACITOR(90 120)	AM30Q4/5
73J96	CAPACITOR(90 120)	AM30Q4/5
59C92	CAPACITOR-BLR MTR(90 120)	AM30Q4/5
59436	FILTER(90 120)	AM30Q4/5
31J81	FILTER(90 120)	AM30Q4/5
64K78	FREEZESTAT KIT(90 120)	AM30Q4/5
73J77	KIT-CARTRIDGE(90 120)	AM30Q4/5
73J78	KIT-CARTRIDGE(90 120)	AM30Q4/5
73J79	KIT-CASING(90 120)	AM30Q4/5
73J81	KIT-CASING(90 120)	AM30Q4/5
59K21	MODULE(90 120)	AM30Q4/5
21L90	MOTOR-BLOWER(90 120)	AM30Q4/5
21L92	MOTOR-BLOWER(90 120)	AM30Q4/5
21L93	MOTOR-BLOWER(90 120)	AM30Q4/5
28F01	MOTOR-BLOWER(90 120)	AM30Q4/5
37J24	MOTOR-BLOWER(90 120)	AM30Q4/5
37J25	MOTOR-BLOWER(90 120)	AM30Q4/5
45H33	MOTOR-BLOWER(90 120)	AM30Q4/5
86H66	MOTOR-BLOWER(90 120)	AM30Q4/5
53J75	PUMP(90 120)	AM30Q4/5
53J76	PUMP(90 120)	AM30Q4/5
49K94	THERMOSTAT(90 120)	AM30Q4/5
42J32	TRANSFORMER(90 120)	AM30Q4/5
66J62	VALVE-CHECK(90 120)	AM30Q4/5
16596	WHEEL-BLOWER(90 120)	AM30Q4/5
21708	WHEEL-BLOWER(90 120)	AM30Q4/5
21709	WHEEL-BLOWER(90 120)	AM30Q4/5
10G44	WHEEL-BLOWER(90 120)	AM30Q4/5

### AM61V

73J82	"KIT-""O""RING"(60C 36C 36B 24B)	AM61V
40K82	BOARD-CIRCUIT(60C 36C 36B 24B)	AM61V
37J56	BREAKER-CIRC(60C 36C 36B 24B)	AM61V
73J96	CAPACITOR(60C 36C 36B 24B)	AM61V
63K08	CAP-SEAL(60C 36C 24B)	AM61V
69H12	CHOKE-POWER(60C)	AM61V

59436	FILTER(60C 36C)	AM61V
97H07	FILTER(60C)	AM61V
97H06	FILTER-AIR(36B 24B)	AM61V
64K78	FREEZESTAT KIT(60C 36C 36B 24B)	AM61V
71M48	KIT-BLOWER(36C 36B 24B)	AM61V
99K70	KIT-CARTRIDGE(36B 24B)	AM61V
73J77	KIT-CARTRIDGE(60C 36C)	AM61V
73J79	KIT-CASING(36B 24B)	AM61V
73J81	KIT-CASING(60C 36C)	AM61V
59K21	MODULE(60C 36C 36B 24B)	AM61V
61M76	MODULE-MOTOR(36C 36B 24B)	AM61V
61M77	MODULE-MOTOR(60C)	AM61V
65M83	MOTOR-BLOWER(36C 36B 24B)	AM61V
65M84	MOTOR-BLOWER(60C)	AM61V
60M36	PRIORISTAT(60C 36C 36B 24B)	AM61V
99K69	PUMP(36B 24B)	AM61V
53J76	PUMP(60C 36C)	AM61V
67K19	RELAY(60C 36C 36B 24B)	AM61V
25J13	SWITCH(60C 36C 36B 24B)	AM61V
49K94	THERMOSTAT(60C 36C 36B 24B)	AM61V
29M71	TRANSFORMER(60C 36C 36B 24B)	AM61V
66J62	VALVE-CHECK(60C 36C 36B 24B)	AM61V
29K49	VENT-AIR BLEED(60C 36C 36B 24B)	AM61V
29K50	VENT-AIR BLEED(60C 36C 36B 24B)	AM61V
89J10	WHEEL-BLOWER(36C 36B 24B)	AM61V
36M22	WHEEL-BLOWER(60C)	AM61V